

- 1815 - Vsl \rightarrow Aprm Loading docks light Hdg: 282 Spd: 8.4
 1825 - Vsl clear Hale boggs bridge Hdg - 290 Spd 8.4
 1845 - Vsl \rightarrow Stable Mile 127 Hdg - 294 Spd - 8.0 kts
 1900 - Vsl \rightarrow Stable Mile 128 Hdg - 295 Spd - 8.6 Vkr. 19-2m
 1915 - Vsl \rightarrow Stable Mile 129 Hdg - 290 Spd - 8.2
 1930 - Vsl \rightarrow Stable Mile 135 Hdg - 290 Spd - 7.9 upc - 16.2m
 1945 - Vsl \rightarrow Lower Bay Barge Hdg - 260 Spd - 8.5 Vkr - 17.5m
 2000 - Vsl \rightarrow Stable Mile 137 Hdg - 255 Spd - 8.3 kts
 2015 - Vsl \rightarrow Stable Mile 141 Hdg - 282 Spd - 8.6 kts
 2030 - Vsl \rightarrow Stable Mile 143 Hdg - 290 Spd - 8.1 kts
 2045 - Vsl \rightarrow Stable Mile 145 Hdg - 296 Spd - 8.1 kts
 2050 - Vsl clear "GRAMMEY BRIDGE" Hdg - 245 Spd - 8.5 kts
 2115 - Vsl \rightarrow Stable Mile 151 Hdg 297 Spd - 8.3 kts

121201 - 30° 00' N 090° 45' W

- 2130 - Vsl \rightarrow Stable Mile 153 Hdg: 259 Spd - 7.2 kts
 2145 - Vsl \rightarrow Stable Mile 157 Hdg - 290 Spd - 6.6 kts
 2200 - Vsl \rightarrow @ College Bend Spd - 8.1 kts
 2215 - Vsl \rightarrow College pt Landing Lt Hdg 250 Spd - 8.1 kts

2226 : Fwd Tug "South Carolina" made fast port Bow M/D (TUGS AND

2228 : Aft Tug "Lawrence" made fast port Quarter breast of A/C (TUGS AND

2230 : Tug "Red Ferry" Assisting

2245 : Vessel parallel to Berth / Tugs pushing

2250 : First Line Ashore (Aft Spring) x2

2334 : Fwd Spring x2 made fast

2345 : 2 Lines (Doubleup) Breast made fast fwd

2 Lines (Doubleup) Breast made fast aft

26/03/2023

0015 : (4x) Stern Lines made fast.

0024 : ALL FAST

0026 : Aft Tug Cast off

0028 : Fwd Tug Cast off.

0036 : FWE / M-E on 30 mins notice / Con with DO

0040 : Assisting / pushing Tug Made Fast B/W 182 / Port Side
 (Margaret Cooper) stay on #7.

0130 [0100] FWE / M-E on 30 mins notice / Con with DO, FAST

0130 : Gangway Down / Pilot Away / Aft Tug on scene

1315 : Aft Tug Cast Off.

1500 : Fwd Tug Cast OFF.

27-03-2023

0150 : CALL Given to MASTER - INFORM VSL OUT OF PAIR

0155 : AGENT CALLED ALL TUGS

0210 : Master instructed to heave fwd lines

0220 : Let Go STBD Anchor / STAY ENG

0221 : First Tug on Scene for Assistance

0225 : Drop Port Anchor

0230 : Second Tug on Scene for assistance

0250 : Vessel Touched Barge STBD Side

0305 : POB

0315 - Tug Made fast port Bow (Tugs line)

0315-0355 - Picking up parked lines from Water / A/C Tug M/E

0356 : Tug Made fast STBD Side abreast of cu#1

0358 : Commence heaving up STBD \downarrow (15' in water)

0401 : STBD \downarrow clear / Ready for let go

0403 : Commence heaving port \downarrow (8' in water)

0430 : Port \downarrow clear / Ready for let go

0431 : Vessel proceeding to Grand view Stage

0455 : Let go Aft Tug from #6.

0455 : Forward Tug let go abreast cu#1 & re positioned on STBD Bow