

TIME	DAY	DATE	DECEMBER	TIME
0000	SAT	25	BLOW SOOT M.B. 21, 22 & 23	0000 0400
1600		25	OFF LINE M.B. # 21 AT 1700 HRS.	1600 2000
2000		25	BOTTOM BLOW DOWN M.B. 21 (20 mins)	1600 2000
2000		25	CHANGED BURNER M.B. # 23	2000 2400
0000	SUN	26	BLOW SOOT M.B. 22 & 23	0000 0400
0800		26	CHANGED BURNER M.B. 22	2000 2400
0800	MON.	27	BLOW SOOT M.B. 22 & 23	0000 0400
2000		27	CHANGED BURNER M.B. 23	2000 2400
0000	TUES.	28	BLOW SOOT M.B. 22 & 23	0000 0400
2000		28	CHANGED BURNER M.B. 22	2000 2400
0000	WED	29	BLOW SOOT M.B. 22 & 23	0000 0400
1600		29	CHANGED BURNER M.B. 23	2000 2400
2000	THURS.	30	BLOW SOOT M.B. 22 & 23	0000 0400
2000		30	CHANGED BURNER M.B. 22	2000 2400
0000	FRI	31	BLOW SOOT M.B. 22 & 23	0000 0400
0800		31	START SLOW FIRING M.B. 21 AT 0830 HRS	0800 1200
1600		31	M.B. 21 ON LINE AT 1815 HRS.	1600 2000
2000		31	CHANGED BURNER M.B. 23	2000 2400
2000		31	OFF LINE M.B. # 21 AT 2230 HRS BOTTOM (20mins)	2000 2400
1600	<p>January 2000 HAPPY NEW YEAR</p>			
1600	SAT	01	BLOW SOOT M.B. 22 & 23	0000 0400
2000		01	CHANGED BURNER M.B. # 22	2000 2400
0000	SUN	02	BLOW SOOT M.B. 22 & 23	0000 0400
2000		02	START SLOW FIRING M.B. 21 AT 1030 HRS	0800 1300
0000		02	ON LINE M.B. # 21 AT 1300 HRS	1600 2000
2000		02	CHANGED BURNER M.B. # 23	2000 2400
0000	MON.	03	BLOW SOOT M.B. 21, 22 & 23	0000 0400
2000		03	CHANGED BURNER M.B. # 22	2000 2400
0000	TUES.	04	BLOW SOOT M.B. 21, 22 & 23	0000 0400
1000		04	CLOCK RETARDED 1 HR AT 1200 HRS	0000 0400
1400		04	OFF LINE M.B. # 23 AT 1500 HRS	0800 1300
1400		04	BOTTOM BLOW DOWN M.B. # 23 (20mins)	0800 1300
0800		04	CHANGED BURNER M.B. # 21	2000 2400
0600	WED	05	BLOW SOOT M.B. 22 & 21	0000 0400
0000		05	CHANGED BURNER M.B. # 22	2000 2400

OLA
MILENYO
DOB MIL



2000 JANUARY

0-4 VIC MAC = ROSAL

4-8 CATOY

8-12 BOKARD

TIME



DAY	DATE		TIME	DAY	DATE
THURS	06	BLOW SOOT BLR. 21 & 22	0000 0400	TUE.	18
	06	START SKIMMING BLR 22 AT 13 ^(4 Hrs) 20 HRS	1200 1600		18
	06	STOP SKIMMING M.B. 22 AT 1720 HRS.	1600 2000		18
	06	CHANGED BURNER M.B. 21	2000 2400		18
FRI.	07	BLOW SOOT BLR 21 & 22	0000 0400		18
	07	CHANGED BURNER M.B. 22	2000 2400		18
SAT.	08	BLOW SOOT BLR. 21 & 22	0000 0400	WED.	19
	08	CHANGED BURNER M.B. 21	2000 2400		19
SUN	09	BLOW SOOT BLR. 21 & 22 / ADVANCED 1 HR.	0000 0400		19
	09	CHANGED BURNER M.B. 22	2000 2400		19
MON	10	BLOW SOOT BLR 21 & 22	0000 0400	THU.	20
	10	CHANGED BURNER M.B. 21	2000 2400		20
TUE	11	BLOW SOOT BLR 21 & 22	0000 0400	FRI.	21
	11	CHANGED BURNER M.B. 22	2000 2400	* 21	
WED	12	BLOW SOOT BLR 21 & 22	0000 0400		21
	12	START SLOW FIRING M.B. 23 AT 0930 hrs	0800 1200		21
	12	START SKIMMING M.B. 22 AT 0945 hrs	0800 1200		21
	12	CHANGED ^{1345 HRS} OVER SKIMMING FROM M.B. 22 to 21	1200 1600	SAT.	22
	12	STOP SKIMMING M.B. 21 AT 1620 HRS	1600 2000		22
	12	CHANGED BURNER M.B. 21	2000 2400	SUN	23
THU	13	BLOW SOOT BLR 21, 22, & 23	0000 0400		23
	13	CHANGED BURNER M.B. 22	2000 2400		23
FRI	14	BLOW SOOT BLR. 21, 22, & 23 / CLOCK RETARDED 1 HOUR	0000 0400		23
	14	OFF LINE BOILER 21 AT 1015 hrs	0800 1200	MON	24
	14	BOTTOM BLOW DOWN (15 MINS) M.B. 21	0800 1200		24
	14	CHANGED BURNER M.B. 23	2000 2400		24
SAT.	15	BLOW SOOT BLR 22 & 23	0000 0400		24
	15	CHANGED BURNER BLR. # 22.	2000 2400		24
SUN.	16	BLOW SOOT Blr. 22 & 23	0000 0400	TUE	25
*	16	CLOCK ADVANCED 1 HOUR AT 02:00 H.	0000 0400		25
	16	ON LINE M.B. # 21 AT 0400 HRS	0400 0800		25
	16	CHANGED BURNER M.B. 23	2000 2400		25
MON	17	BLOW SOOT BLR. 22, 23, & 24 @	0000 0400	WED.	26
	17	CHANGED BURNER M.B. 22	2000 2400		26

BONG - CATOY - ERIC
JANUARY 2000

TIME		DAY	DATE		107 TIME	
0000	0400	TUE.	18	BLOW SOOT BLR. 22 23, & 24 @	0000	0400
1200	1600		18	OFF LINE M.B. #24 0530 HRS.	0400	0800
1600	2000		18	BOTTOM BLOW DOWN M.B. 24 (20 mins.)	0400	0800
2000	2400		18	START SKIMMING M.B. 23 AT 1140 hrs. (4hrs)	0800	1200
0000	0400		18	STOPPED SKIMMING M.B. 23 AT 15:40 HRS.	1200	1600
2000	2400		18	CHANGED BURNER M.B. 23	2000	2400
0000	0400	WED.	19	BLOW SOOT M.B. 22 & 23 @	0000	0400
2000	2400		19	START SLOW FIRING M.B. 24 AT 0930 hrs	0800	1200
0000	0400		19	ON LINE M.B. #24 AT 1800 HRS.	1600	2000
2000	2400		19	CHANGED BURNER M.B. 22	2000	2400
0000	0400	THU.	20	BLOW SOOT M.B. 22, 23, & 24 @	0000	0400
2000	2400		20	CHANGED BURNER M.B. 23	2000	2400
0000	0400	FRI.	21	BLOW SOOT M.B. 22, 23, & 24 @	0000	0400
2000	2400	*	21	CLOCK RETARDED (1 HOUR) AT 02:00 HRS.	0000	0400
0000	0400		21	OFF LINE M.B. 22 AT 1000 HRS	0800	1200
0800	1200		21	BOTTOM BLOW DOWN M.B. 22 (20 MINS.)	0800	1200
0800	1200		21	CHANGED BURNER M.B. 24	2000	2400
1200	1600	(SAT.	22	BLOW SOOT M.B. 23 & 24 @	0000	0400
1600	2000		22	CHANGE THE BURNERS OF M.B. #23.	2000	2400
2000	2400	SUN	23	BLOW SOOT M.B. 23 & 24	0000	0400
0000	0400		23	CLOCK ADVANCED (1 HOUR) AT 02:00 HRS.	0000	0400
2000	2400		23	CHANGE BURNERS OF M.B. #24	2000	2400
0000	0400		23	START SLOW FIRING M.B. #22 AT 2230 HRS.	2000	2400
0000	0400	MON	24	BLOW SOOT M.B. 23 & 24	0000	0400
0800	1200		24	ON LINE M.B. 22 AT 06:20 HRS.	0400	0800
2000	2400		24	OFF LINE M.B. 24 AT 06:35 HRS.	0400	0800
0000	0400		24	BOTTOM BLOW DOWN M.B. 24 (15 MINS.)	0400	0800
2000	2400		24	CHANGE THE BURNERS OF M.B. #23	2000	2400
0000	0400	TUE	25	BLOW SOOT M.B. 22 & 23	0000	0400
0000	0400		25	START SKIMMING M.B. 23 AT 0225 hrs (4hrs)	0000	0400
0800	1200		25	STOPPED SKIMMING M.B. 23 AT 06:25 HRS.	0400	0800
2000	2400		25	CHANGE THE BURNERS OF M.B. #24	2000	2400
0000	0400	WED.	26	BLOW SOOT M.B. 22 & 23	0000	0400
0000	0400		26	START SKIMMING M.B. 22 AT 0220 hrs (4hrs)	0000	0400

JANUARY

TIME

DAY	DATE		TIME	DAY	DATE
WED.	26	STOPPED SKIMMING M.B. 22 AT 06:20 HRS. Changed over M.B. 23 (4 HOURS.)	0400 0800	THU	03
	26	STOP SKIMMING M.B. # 23 AT 10:00 HRS	0800 1200		03
	26	START SLOW FIRING M.B. 21 AT 10:52 HRS.	0800 1200		03
	26	ON LINE M.B. 21 AT 18:15 HRS.	1600 2000		03
	26	CHANGE BURNERS OF M.B. # 23	2000 2400	FRI	04
THU.	27	BLOW SOOT M.B. 21, 22 & 23	0000 0400		04
	27	CHANGE THE BURNERS OF M.B. # 22	2000 2400		04
FRI.	28	BLOW SOOT M.B. 21, 22 & 23	0000 0400		04
	* 28	CLOCK RETARDED (1 HOUR) AT 02:00	0000 0400	SAT	05
	28	# OFF LINE M.B. # 23 AT 1000 HRS	0200 1250		05
	28	BOTTOM BLOW DOWN M.B. # 23 (15 min.)	0800 1200	SUN	06
	28	CHANGE THE BURNERS OF M.B. # 21	2000 2400		06
SAT	29	BLOW SOOT M.B. 21 & 22	0000 0400	MON	07
	29	CHANGE THE BURNERS OF M.B. # 22	2000 2400		07
SUN	30	BLOW SOOT M.B. 21 & 22	0000 0400		07
	30	START SKIMMING M.B. 22 AT 0140 (4hrs)	0000 0400		07
	30	STOPPED SKIMMING M.B. 22 AT 05:40 HRS.	0400 0800	TUE	08
	30	CHANGE THE BURNERS OF M.B. 21	2000 2400		08
MON	31	BLOW SOOT M.B. 21 & 22	0000 0400		08
	31	CLOCK ADVANCED (1 HR) AT 02:00 HRS.	0200 0400	WED	09
	31	CHANGE THE BURNERS OF M.B. 22	2000 2400		09
 <h1 style="font-family: cursive;">February</h1> 					
TUE.	01	BLOW SOOT M.B. 21 & 22	0000 0400	THU	10
	01	CHANGE THE BURNERS OF M.B. # 21	2000 2400		10
WED	02	BLOW SOOT M.B. 21 & 22	0000 0400	FRI	11
	02	START SKIMMING M.B. 21 AT 02:15 hrs (4hrs)	0000 0400		11
	02	STOPPED SKIMMING M.B. 21 AT 06:15 HRS. CHANGED OVER TO M.B. 22. 2 HRS.	0400 0800		11
	02	STOPPED SKIMMING M.B. 22 AT 0800 HRS.	0400 0800		11
	02	START SLOW FIRING M.B. # 24 AT 1100 HRS	0600 1200	SAT	12
	02	ON LINE M.B. 24 AT 1800 HRS.	1600 2000		12
	02	CHANGE THE BURNERS OF M.B. # 22	2000 2400	SUN	13

FEBRUARY

TIME	DAY	DATE	DESCRIPTION	TIME	TIME
0400 0800	THU	03	BLOW SOOT M.B. 21, 22 & 24	0000	0400
0800 1200		03	START SKIMMING M.B. 22 AT 0220 hrs. (4hrs)	0000	0400
0800 1200		03	STOPPED SKIMMING M.B. 22 AT 06:20 HRS.	0400	0800
1600 2000		03	CHANGE THE BURNERS OF M.B. #21	2000	2400
2600 2400	FRI	04	BLOW SOOT M.B. 21, 22 & 24	0000	0400
0000 0400		04	OFF LINE M.B. #22 AT 0940 HRS.	0800	1200
2000 2400		04	BOTTOM BLOW DOWN 15 mins.	0800	1300
0000 0400		04	CHANGE THE BURNERS OF M.B. #24	2000	2400
0000 0400	SAT	05	BLOW SOOT M.B. 21 & 24	0000	0400
0800 1200		05	CHANGE THE BURNERS OF M.B. #21	2000	2400
0800 1200	SUN	06	BLOW SOOT M.B. 21 & 24	0000	0400
2000 2400		06	CHANGE THE BURNERS OF M.B. #24	2000	2400
0000 0400	MON	07	BLOW SOOT M.B. 21 & 24	0000	0400
2000 2400		07	START SKIMMING M.B. 24 AT 0145 hrs (4hrs)	0000	0400
0000 0400		07	ON LINE M.B. #24 AT 2020 HRS.	2000	2400
0000 0400		07	CHANGE THE BURNERS OF M.B. #21	2000	2400
0400 0800	TUE	08	BLOW SOOT M.B. 21 & 24	0000	0400
2000 2400		08	CHANGE THE BURNERS OF M.B. #24	2000	2400
0000 0400		08	START SLOW FILING M.B. #22 AT 2130 HRS	2000	2400
0800 0400	WED	09	BLOW SOOT M.B. 21 & 24	0000	0400
2000 2400		09	START SKIMMING M.B. 21 AT 0310 hrs (4 hrs)	0000	0400
		09	STOPPED SKIMMING M.B. 21 AT 07:10 HRS.	0400	0800
		09	ON LINE M.B. #22 AT 0940 HRS.	0800	1200
		09	CHANGE THE BURNERS OF M.B. 21	2000	2400
0000 0400	THU	10	BLOW SOOT M.B. 21, 22 & 24	0000	0400
2000 2400		10	CHANGE THE BURNERS OF M.B. #24	2000	2400
0000 0400	FRI	11	BLOW SOOT M.B. 21, 22 & 24	0000	0400
0000 0400		11	M.B. 22 OFF LINE AT 1010 HRS.	0800	1200
0400 0800		11	BLOW DOWN M.B. #22 (15 mins)	0800	1200
0400 0800		11	CHANGE THE BURNERS OF M.B. #21	2000	2400
0800 1200	SAT	12	BLOW SOOT M.B. 21 & 24	0000	0400
1600 2000		12	CHANGE THE BURNERS OF M.B. #24	2000	2400
2000 2400	SUN	13	BLOW SOOT M.B. 21 & 24	0000	0400



FEBRUARY



DAY	DATE	TIME	DAY	DATE
SUN	13	CHANGE THE BURNERS OF M.B.# 21	FRI	25
MON	14	BLOW SOOT M.B. 21 & 24		25
	14	CHANGE THE BURNERS OF M.B.# 24		25
TUE	15	BLOW SOOT M.B. 21 & 24		25
	15	CHANGE THE BURNERS OF M.B.# 21	SAT	26
WED	16	BLOW SOOT M.B. 21 & 24		26
	16	START SLOW FIRING M.B.# 23 AT 0912 HRS	SUN	27
	16	ON LINE M.B. 23 AT 17:55 HRS.		27
	16	CHANGE THE BURNERS OF M.B.# 24		27
THU	17	BLOW SOOT M.B. 21, 23 & 24		27
	17	CHANGE THE BURNERS OF M.B.# 23		27
FRI	18	BLOW SOOT M.B. 21, 23 & 24		27
	18	OFF LINE M.B.# 21 AT 1145 HRS.	MON	28
	18	BOTTOM BLOW DOWN M.B.# 21 15 MIN.		28
	18	CHANGE THE BURNERS OF M.B.# 24		28
SAT	19	BLOW SOOT M.B. 23 & 24		28
	19	CHANGED BURNERS M.B. 23 @		28
SUN	20	BLOW SOOT M.B. 23 & 24		28
	20	CLOCK 1 HR. ADVANCE AT 0200 HRS		28
	20	CHANGED BURNERS M.B. 24	TUE	29
MON	21	BLOW SOOT M.B. 23 & 24		29
	21	CHANGED BURNERS M.B. 23		
TUE	22	BLOW SOOT M.B.# 23 & 24		
	22	START SKIMMING M.B. 23 AT 0630 HRS (4 HRS)		
	22	STOPPED SKIMMING M.B. 23 AT 10:30 HRS. CHANGED OVER M.B. 24 (4 HRS.)		
	22	STOP SKIMMING M.B.# 24 AT 1430 HRS.	WED	01
	22	CHANGED BURNERS M.B. 24		01
WED	23	BLOW SOOT M.B. 23 & 24		01
	23	START SLOW FIRING M.B. 22 AT 09:10 HRS		01
	23	ON - LINE M.B. 22 AT 1750 HRS	THU	02
	23	CHANGED BURNERS M.B. 23 @		02
THU	24	BLOW SOOT M.B. 22, 23 & 24	FRI	03
	24	CHANGED BURNERS M.B. 22 @		03
				03

CONVERT
CENTRO
SPALL



TIME		DAY	DATE		III TIME	
2000	2400	FRI.	25	BLOW SOOT M.B. 22, 23 & 24	0000	0400
0000	0400		25	OFF LINE M.B. 24 AT 10:30 HRS.	0800	1200
2000	2400		25	BOTTOM BLOW DOWN M.B. 24 (15 MINS)	0800	1200
0000	0400		25	CHANGED BURNERS M.B. 23	2000	2400
2000	2400	SAT	26	BLOW SOOT M.B. # 22 & 23	0000	0400
0000	0400		26	CHANGED BURNERS M.B. 22.	2000	2400
0800	1200	SUN	27	BLOW SOOT M.B. # 22 & 23.	0000	0400
1600	2000		27	START SKIMMING M.B. 22 AT 06:30 HRS.	0400	0800
2000	2400		27	STOPPED SKIMMING M.B. 22 AT 10:30 HRS. CHANGED OVER M.B. 23 (4 HRS)	0800	1200
0000	0400		27	CHANGED OVER TO M.B. 22 AT 1800 (4hrs)	1600	2000
2000	2400		27	CHANGED BURNERS M.B. 23	2000	2400
0000	0400		27	Stopped Skimming M.B. 22 AT 22:30 HRS. changed over M.B. 23 (4 HRS)	2000	2400
0800	1200	MON	28	BLOW SOOT M.B. # 22 & 23	0000	0400
1200	1600		28	STOP SKIMMING M.B. # 23 AT 0230 HRS.	0000	0400
2000	2400		28	START SKIMMING M.B. 23 AT 0630 (4hrs)	0400	0800
0000	0400		28	STOPPED SKIMMING M.B. 23 AT 10:30 HRS.	0800	1200
2000	2400		28	START SKIMMING M.B. 23 AT 1800 Hrs (4Hrs)	1600	2000
0000	0400		28	CHANGED BURNERS M.B. 22.	2000	2400
0000	0400		28	STOPPED SKIMMING M.B. 23 AT 2200 HRS.	2000	2400
2000	2400	TUE.	29	BLOW SOOT M.B. # 22 & 23	0000	0400
0000	0400		29	CHANGED BURNERS M.B. 23	2000	2400
2000	2400			* — — — *		
0000	0400					
0400	0800					
0800	1200					
1200	1600	WED.	01	BLOW SOOT M.B. # 22 & 23.	0000	0400
2000	2400	CONVERT CUMMINS DRIVE	01	START SLOW FIRING M.B. 21 AT 09:30 HRS.	0800	1200
0000	0400		01	ON LINE M.B. 21. 1800 HRS.	1600	2000
0800	1200		01	CHANGED BURNERS M.B. 22.	2000	2400
1600	2000	THU.	02	BLOW SOOT M.B. # 21, 22 & 23	0000	0400
2000	2400		02	CHANGED BURNERS M.B. 23	2000	2400
0000	0400	FRI	03	BLOW SOOT M.B. # 21, 22 & 23	0800	1200
2000	2400		03	OFF LINE M.B. 21 AT 09:45 HRS.	0800	1200
			03	BOTTOM BLOW DOWN M.B. 21 (15 MINS.)	0800	1200

March 2000

MARCH

DAY	DATE		TIME		DAY
FRI.	03	CHANGED BURNERS M.B. 22.	2000	2400	MON.
SAT.	04	BLOW SOOT M.B. 22 & 23	0000	0400	
	04	CHANGED BURNERS M.B. 23.	2000	2400	TUE.
SUN.	05	BLOW SOOT M.B. # 22 & 23	0000	0400	
	05	SKIMMING M.B. 22 AT 09:30 HRS (4 HRS)	0800	1200	WED.
	05	STOP SKIMMING M.B. 22, SHIFT TO M.B. 23	1200	1600	
	05	STOP SKIMMING M.B. 23 AT 1730	1600	2000	
	05	CHANGED BURNERS M.B. 22.	2000	2400	
MON.	06	BLOW SOOT M.B. # 22 & 23	0000	0400	THU.
	06	SKIMMING M.B. 23 AT 0620 hrs (4 hrs)	0400	0800	
	06	STOPPED SKIMMING M.B. 23 10:20 HRS.	0800	1200	
	06	changed Burners M.B. 23.	2000	2400	
TUE.	07	BLOW SOOT M.B. # 22 & 23	0000	0400	FRI.
	07	CHANGED BURNERS M.B. 22.	2000	2400	
WED.	08	BLOW SOOT M.B. # 22 & 23	0000	0400	
	08	START SLOW FIRING M.B. 24 AT 09:10 HRS.	0800	1200	
	08	ON LINE M.B. 24 AT 17:55 HRS.	1600	2000	
	08	CHANGED BURNERS M.B. 23 @	2000	2400	
THU.	09	BLOW SOOT M.B. # 22, 23 & 24	0000	0400	SAT.
	09	START SKIMMING M.B. 22 AT 09:30 HRS. (6 HRS.)	0800	1200	SUN.
	09	STOP SKIMMING M.B. 22, SHIFT TO M.B. # 23	1200	1600	*
	09	CHANGED BURNERS M.B. 24	2000	2400	
	09	STOPPED SKIMMING M.B. 23 AT 21:30 HRS.	2000	2400	
FRI.	10	BLOW SOOT M.B. # 22, 23 & 24	0000	0400	
	10	OFF LINE M.B. 22 AT 09:30 HRS.	0800	1200	
	10	BOTTOM BLOW DOWN M.B. 22 (15 MINS.)	0800	1200	MON.
	10	CHANGED BURNERS M.B. 23.	2000	2400	
SAT.	11	BLOW SOOT M.B. # 23 & 24	0000	0400	
	11	changed Burners M.B. 24	2000	2400	
SUN.	12	BLOW SOOT M.B. # 23 & 24	0000	0400	
	12	CHANGED BURNERS M.B. 23	2000	2400	TUE.
MON.	13	BLOW SOOT M.B. # 23 & 24	0000	0400	
	13	START SKIMMING M.B. 24 AT 1830 hrs (4 hrs)	1600	2000	

March

113

TIME		DAY	DATE		TIME	
2000	2400	MON.	13	CHANGED BURNERS M.B. 24	2000	2400
0000	0400		13	STOPPED SKIMMING M.B. 24 AT 22:30 HRS.	2000	2400
2000	2400	TUE.	14	BLOW SOOT M.B. # 23 & 24	0000	0400
0000	0400		14	CHANGED BURNERS M.B. 23	2000	2400
0800	1200	WED.	15	BLOW SOOT M.B. # 23	0000	0400
1200	1600		15	START SLOW FIRING M.B. # 21 AT 1000 HRS.	0800	1200
1600	2000		15	ON LINE M.B. 21 AT 1800 HRS.	1600	2000
2000	2400		15	CHANGED BURNERS M.B. 24 @	2000	2400
0000	0400	THU.	16	BLOW SOOT M.B. # 21, 23 & 24	0000	0400
0400	0800		16	START SKIMMING M.B. 21 AT 09:30 HRS. (4 HRS.)	0800	1200
0800	1200		16	STOP SKIMMING M.B. # 21 AT 1330 HRS.	1200	1600
2000	2400		16	CHANGED BURNERS M.B. 23. @	2000	2400
0000	0400	FRI.	17	BLOW SOOT M.B. # 21, 23 & 24	0000	0400
2000	2400		17	CLOCK ONE (1) HR. BACKWARD AT 0200 HRS.	0000	0400
0000	0400		17	OFF LINE M.B. 21 AT 09:30 HRS.	0800	1200
0800	1200		17	BOTTOM BLOW DOWN M.B. 21 / 15 MINS)	0800	1200
1600	2000		17	CHANGED BURNERS M.B. 24 @.	2000	2400
2000	2400	SAT.	18	BLOW SOOT M.B. # 23 & 24	0000	0400
0000	0400		18	CHANGED BURNERS M.B. 23	2000	2400
0800	1200	SUN.	19	BLOW SOOT M.B. 23 & 24	0000	0400
1200	1600	*	19	CLOCK ADVANCED (1) HOUR AT 0200 HRS.	0000	0400
2000	2400		19	START SKIMMING M.B. 23 AT 0830hrs (4hrs)	0800	1200
2000	2400		19	STOPPED SKIMMING M.B. 23 AT 12:30 HRS.	1200	1600
0000	0400		19	CHANGED BURNERS M.B. 24	2000	2400
0800	1200		19	START SKIMMING M.B. 24 AT 2100 hrs (4hrs)	2000	2400
0800	1200	MON.	20	BLOW SOOT M.B. 23 & 24	0000	0400
2000	2400		20	STOPPED SKIMMING M.B. 24 AT 01:00 HRS.	0000	0400
0000	0400		20	START SKIMMING M.B. 23 AT 13:00 HRS. (4 HRS.)	1200	1600
2000	2400		20	STOPPED SKIMMING M.B. 23 AT 1700 HRS	1600	2000
0000	0400		20	CHANGED BURNERS OF M.B. 23	2000	2400
2000	2400	TUE.	21	BLOW SOOT M.B. 23 & 24	0000	0400
0000	0400		21	OFF LINE M.B. 24 AT 08:45 HRS	0800	1200
1600	2000		21	ON LINE M.B. 24 AT 1700 HRS.	1600	2000
			21	CHANGED BURNERS M.B. 24	2000	2400

DAY	DATE	TIME	DAY
WED.	22	BLOW SOOT M.B. 23 & 24	FRI.
	22	START SLOW FIRING M.B. 21 AT 0930 HRS	*
	22	ON LINE M.B. # 21 AT 1800 HRS.	
	22	CHANGED BURNERS M.B. 23	
	22	START SKIMMING M.B. 21 AT 2300 HRS (4 hrs)	
THU.	23	BLOW SOOT M.B. 21, 23, & 24	
	23	STOPPED SKIMMING M.B. 21 AT 03:00 HRS.	
	23	CHANGED BURNERS M.B. 24	
FRI.	24	BLOW SOOT M.B. 21, 23, & 24.	SAT.
*	24	CLOCK RETARDED (1 HOUR) AT 02:00 HRS.	
	24	OFF LINE BOILER 21 AT 1030 HRS	SUN.
	24	BOTTOM BLOW DOWN M.B. 21 (15 MINS)	*
	24	CHANGED BURNERS M.B. 23	
SAT.	25	BLOW SOOT M.B. 23 and 24 @.	MDN.
	25	CHANGED BURNERS M.B. 24	
SUN.	26	BLOW SOOT M.B. 23 AND 24	TUE.
*	26	CLOCK ADVANCED (1 HOUR) AT 02:00 HRS.	
	26	START SKIMMING M.B. 24 (4 HOURS)	
	26	STOPPED SKIMMING BOILER # 24 AT 1700 HRS	WED.
	26	CHANGED BURNERS M.B. 23	
MON.	27	BLOW SOOT M.B. 23 & 24	
	27	Start Skimming M.B. 23 AT 13:00 HRS. (4 HRS.)	
	27	Stopped Skimming M.B. 23 AT 1700 HRS.	
	27	CHANGED BURNERS M.B. 24	
TUE.	28	BLOW SOOT M.B. 23 & 24 @	THU.
	28	CHANGED BURNERS M.B. 23	
WED.	29	BLOW SOOT M.B. 23 & 24 @	
	29	Tested Firing M.B. 21 all Burners	FRI.
	29	START SLOW FIRING M.B. 21 AT 0930 HRS	
	29	START SLOW FIRING M.B. 22 AT 2145 HRS	
	29	ON-LINE M.B. 21 AT 2130 HRS	
THU.	30	BLOW SOOT M.B. 21, 23, & 24 @	SAT.
	30	ON LINE M.B. 22. AT 03:00 HRS.	
	30	CHANGED BURNERS M.B. 24	

			115	
TIME	DAY	DATE		TIME
0000	FRI.	31	BLOW SOOT M.B. 21, 22, 23, & 24	0000 0400
0800	*	31	CLOCK RETARDED (1 HR) AT 02:00 HRS.	0000 0400
1600		31	OFF LINE M.B. 22 AT 1020 HRS	0800 1200
2000		31	OFF LINE M.B. 21 AT 1050 HRS	0800 1200
2000		31	BOTTOM BLOW DOWN M.B. 22 15 MINS.	0800 1200
0000		31	BOTTOM BLOW DOWN M.B. 21 15 MINS.	0800 1200
0000		31	CHANGED BURNER M.B. 23	2000 2400
2000			* APRIL 2000 *	
0000	SAT.	01	BLOW SOOT M.B. 23 & 24	0000 0400
2000		01	CHANGED BURNERS M.B. 24	2000 2400
0800	SUN.	02	BLOW SOOT M.B. 23 & 24	0000 0400
0800	*	02	CLOCK ADVANCED (1 HOUR) AT 02:00 HRS.	0000 0400
2000		02	CHANGED BURNERS M.B. 23	2000 2400
2000	MDN.	03	BLOW SOOT M.B. 23 & 24 @	0000 0400
2000		03	CHANGED BURNERS M.B. 24	2000 2400
0000	TUE.	04	BLOW SOOT M.B. 23, & 24 @	0000 0400
0000		04	CHANGED BURNERS M.B. 23	2000 2400
1200		04	START SKIMMING M.B. 23 AT 2200 hrs (4)	2000 2400
1600	WED.	05	BLOW SOOT M.B. 23 & 24	0000 0400
2000		05	STOPPED SKIMMING M.B. 23 AT 02:00 HRS.	0000 0400
0000		05	START SLOW FIRING M.B. 22 AT 0930 hrs	0800 1200
1200		05	ON LINE M.B. 22 at 1800 hrs.	1600 2000
1600		05	CHANGED BURNERS M.B. 24	2000 2400
2000		05	START SKIMMING M.B. 23 AT 2130 hrs (6 hrs)	2000 2400
0000	THU.	06	BLOW SOOT M.B. 22, 23 & 24	0000 0400
2000		06	STOPPED SKIMMING M.B. 23 AT 03:30 HRS.	0000 0400
0000		06	CHANGED BURNERS M.B. 23	2000 2400
0000	FRI.	07	BLOW SOOT M.B. 22, 23, & 24	0000 0400
0800		07	OFF LINE M.B. 22 AT 1045 HRS.	0800 1200
2000		07	BOTTOM BLOW DOWN M.B. 22 (15 MINS.)	0800 1200
2000		07	CHANGED BURNERS M.B. 24	2000 2400
0000	SAT.	08	BLOW SOOT M.B. 23 & 24	0000 0400
2000		08	CHANGED BURNERS M.B. 23	2000 2400
2000				

APRIL 2000

DAY	DATE		TIME		DAY
SUN.	09	BLOW SOOT M.B. 23 & 24	0000	0400	WED.
	09	CHANGED BURNERS M.B. 24	2000	2400	
MON.	10	BLOW SOOT M.B. 23 & 24	0000	0400	
	10	BLACK OUT 0555 HRS.	0400	0800	
	10	ON LINE BLK # 23 0910 HRS.	0800	1200	
	10	ON LINE BLK # 24 0925 HRS.	0800	1200	
	10	START SLOW FIRING M.B. 22 AT 1000 HRS	0500	1200	
	10	ON LINE M.B. 22 AT 1500 HRS.	1200	1600	THU.
	10	CHANGED BURNERS M.B. 23	2000	2400	
TUE.	11	BLOW SOOT M.B. 22, 23 & 24	0000	0400	
	11	OFF LINE BLK # 22 0735 HRS ^{EXTINGUISH 2000} 20 MIN.	0400	0800	
	11	CHANGED BURNERS M.B. 24	2000	2400	FRI.
WED.	12	BLOW SOOT M.B. 23 & 24	0000	0400	
	12	ON LINE M.B. # 22 at 1030 HRS.	1600	2000	
	12	CHANGED BURNERS M.B. 23	2000	2400	SAT.
THU.	13	BLOW SOOT M.B. 22, 23, and 24	0000	0400	
	13	CHANGED BURNERS M.B. 24	2000	2400	SUN.
FRI.	14	BLOW SOOT M.B. 22, 23 & 24	0000	0400	
	14	OFF LINE M.B. 22 AT 1040 HRS	0800	1200	MON.
	14	BOTTOM BLOW DOWN 15 MINS	0500	1200	
	14	CHANGED BURNERS M.B. 23	2000	2400	TUE.
SAT.	15	BLOW SOOT M.B. 23 & 24 @	0000	0400	
	15	CHANGED BURNERS M.B. 24	2000	2400	WED.
SUN.	16	BLOW SOOT M.B. 23 & 24	0000	0400	
	16	CHANGED BURNER M.B. 23	2000	2400	
MON.	17	BLOW SOOT M.B. 23 & 24	0000	0400	
	17	START SKIMMING M.B. 23 AT 0030 (6 HRS)	0000	0400	THU.
	17	STOPPED SKIMMING M.B. 23 AT 06:30 HRS.	0400	0800	
	17	CHANGED BURNER M.B. 24	2000	2400	FRI.
TUE.	18	BLOW SOOT M.B. 23 & 24	0000	0400	
	18	OFF LINE M.B. 24 AT 1030 HRS.	0800	1200	
	18	ON LINE M.B. 24 AT 1450 HRS	1200	1600	SAT.
	18	START SKIMMING M.B. 23 AT 1700 HRS. (6 HRS)	1600	2000	
	18	CHANGE BURNER M.B. 23	2000	2400	

AT SEX

TIME		DAY	DATE		TIME	
0000	0400	WED.	19	BLOW SOOT M.B. 23 & 24	0000	0400
2000	2400		19	STOPPED SKIMMING M.B. 23 AT 0100 HRS	0000	0400
0000	0400		19	CONTINUE SKIMMING M.B. 23 AT 0130 (2 HRS)	0000	0400
0400	0800		19	STOPPED SKIMMING M.B. 23 AT 0330	0000	0400
0800	1200		19	START SLOW FIRING M.B.#21 AT 0930 HRS.	0800	1200
0800	1200		19	ON LINE M.B. 21 AT 18:10 HRS.	1600	2000
0500	1200		19	CHANGED BURNER M.B.#24	2000	2400
1200	1600	THU.	20	BLOW SOOT M.B. 21, 23 & 24	0000	0400
2000	2400		20	START SKIMMING M.B. 21 AT 0230 HRS (4 HRS)	0000	0400
0000	0400		20	STOPPED SKIMMING M.B. 21 AT 06:30 HRS.	0400	0800
0400	0800		20	CHANGED BURNER M.B.#21	2000	2400
2000	2400	FRI.	21	BLOW SOOT M.B. 21, 23 & 24	0000	0400
0000	0400		21	OFF LINE M.B.# 23 AT 1120 HRS. ^{BOTTOM BLOW} DOWN 20 MIN.	0800	1200
1600	2000		21	CHANGED BURNER M.B.#24	2000	2400
2000	2400	SAT.	22	BLOW SOOT M.B. 21 & 24	0000	0400
0000	0400		22	CHANGE BURNER M.B.#21	2000	2400
2000	2400	SUN.	23	BLOW SOOT M.B. 21 & 24	0000	0400
0000	0400		23	CHANGE BURNER M.B. 24	2000	2400
0800	1200	MON.	24	BLOW SOOT M.B. 21 & 24	0000	0400
0800	1200		24	CHANGE BURNER M.B. 21	2000	2400
2000	2400	TUE.	25	BLOW SOOT M.B. 21 & 24	0000	0400
0000	0400		25	CHANGED BURNER M.B. 24	2000	2400
2000	2400	WED.	26	BLOW SOOT M.B. 21 & 24	0000	0400
0000	0400		26	START SLOW FIRING M.B. 22 0930 HRS	0800	1200
2000	2400		26	ON LINE M.B. 22 AT 18:10 HRS.	1600	2000
0000	0400		26	CHANGE BURNER M.B. 21	2000	2400
0000	0400	THU.	27	BLOW SOOT M.B. 21, 22 & 24	0000	0400
0400	0800		27	CHANGED BURNER M.B. 24	2000	2400
2000	2400	FRI.	28	BLOW SOOT M.B. 21, 22 & 24	0000	0400
0000	0400		28	OFF LINE M.B. 24 10:15 HRS. ^{BOTTOM BLOW} DOWN 20 MIN.	0800	1200
0800	1200		28	CHANGED BURNER M.B. 22	2000	2400
1200	1600	SAT.	29	BLOW SOOT M.B. 21 & 22	0000	0400
1600	2000		29	START SLOW FIRING M.B. 23 AT 1600 HRS.	1600	2000
2000	2400					

DAY	DATE		TIME	DAY	
SAT.	29	CHANGED BURNER M.B. 21	2000 2400	MON.	10
		ON LINE M.B. 23 AT 1230 HRS.	2000 2400		11
SUN.	30	BLOW SOOT M.B. 21, 22 & 23	0000 0400		12
	30	START SKIMMING M.B. 21 AT 0345 (6 HRS)	0000 0400		13
	30	stopped skimming M.B. 21 at 0945 HRS	0800 1200		14
	30	CHANGED BURNER M.B. 22	2000 2400		15
MAY "2000"					
MON.	01	BLOW SOOT M.B. 21, 22 & 23	0000 0400	TUE.	16
	01	CHANGE BURNER M.B. 21	2000 2400		17
TUE	02	BLOW SOOT M.B. 21, 22 & 23	0000 0400		18
	02	OFF LINE M.B. 23 AT 05:50 HRS.	0400 0800		19
	02	BOTTOM BLOW DOWN M.B. 23 (15 MINS.)	0400 0800		20
	02	CHANGED BURNER M.B. 22	2000 2400		21
WED.	03	BLOW SOOT M.B. 21 & 22	0000 0400	WED.	22
	03	START SKIMMING M.B. 21 AT 0200 (6 HRS)	0000 0400		23
	03	STOPPED SKIMMING M.B. 21 AT 0800 HRS.	0400 0800		24
	03	Start firing M.B. 23 at 0940 HRS.	0800 1200		25
	03	ON Line M.B. 23 AT 1200 HRS.	1600 2000		26
	03	CHANGED BURNER M.B. 21	2000 2400		27
THU.	04	BLOW SOOT M.B. 21, 22 & 23	0000 0400	THU.	28
	04	CHANGED BURNER M.B. 22	2000 2400		29
FRI.	05	BLOW SOOT M.B. 21, 22 & 23	0000 0400	FRI.	30
	05	OFF LINE M.B. 23 AT 0945 HRS. BOTTOM BLOW DOWN 20 MINS.	0800 1200		31
	05	CHANGE BURNER M.B. 21	2000 2400		32
SAT.	06	BLOW SOOT M.B. 21 & 22	0000 0400	SAT.	33
	06	CHANGED BURNERS BLR. 22	2000 2400		34
SUN.	07	BLOW SOOT M.B. 21 & 22	0000 0400	SUN.	35
	07	START SKIMMING M.B. 21 AT 0300 (6 HRS)	0000 0400		36
	07	STOPPED SKIMMING BLR. 21 & CHANGED OVER TO BLR. 22 AT 0900 HRS.	0800 1200	MON.	37
	07	STOPPED SKIMMING BLR. 22 AT 1030 HRS & START DRAIN DOWN BLR. 24.	0800 1200		38
	07	START SKIMMING M.B. 22 AT 2100 HRS (6 HRS)	2000 2400	TUES.	39
	07	CHANGED BURNERS BLR. 21	2000 2400		40
					41
					42

TIME		DAY	DATE		TIME
2000	2400	MON.	08	BLOW SOOT M.B. 21 & 22	0000-0400
2000	2400		08	STOPPED SKIMMING M.B. 22 AT 0330 CHANGED OVER (6) TO M.B. 21 AT 0330	0000 0400
0000	0400		08	START SLOW FIRING BLR. 23 AT 0930 HRS.	0800 1200
0000	0400		08	STOPPED SKIMMING BLR. 21 AT 0950 HRS.	0800 1200
0800	1200		08	ON LINE M.B. 23 AT 1445 HRS.	0800 1200
2000	2400		08	START SKIMMING M.B. 21 AT 1630 HRS. (8 HOURS)	1600 2000
			08	CHANGED BURNERS BLR. 22	2000 2400
0000	0400	TUE.	09	BLOW SOOT M.B. 21, 22 & 23	0000 0400
2000	2400		09	STOPPED SKIMMING M.B. 21 AT 0030	0000 0400
0000	0400		09	START SKIMMING M.B. 22 AT 0330 (8 HRS)	0000 0400
0400	0800		09	OFF LINE M.B. 23 AT 07:15 HRS.	0400 0800
0400	0800		09	STOPPED SKIMMING BLR. 22 AT 1130 HRS.	0800 1200
2000	2400		09	CHANGED BURNERS BLR. 21	2000 2400
0000	0400	WED.	10	BLOW SOOT M.B. 21 & 22	0000 0400
0000	0400		10	START SKIMMING M.B. 21 AT 0315 HRS (6 HRS)	0000 0400
0400	0800		10	STOPPED SKIMMING BLR. 21 AT 0915 HRS.	0800 1200
0800	1200		10	START FIRING BLR. 23 AT 0940 HRS.	0800 1200
1600	2000		10	ON LINE M.B. 23 AT 18:00 HRS.	1600 2000
2000	2400		10	CHANGED BURNERS BLR. 22	2000 2400
0000	0400	THU.	11	BLOW SOOT M.B. 21, 22 & 23	0000 0400
2000	2400		11	CHANGED BURNERS BLR. 21	2000 2400
0000	0400	FRI.	12	BLOW SOOT M.B. 21, 22 & 23	0000 0400
0800	1200		12	OFF LINE BLR. 21 AT 1000 HRS. BOTTOM BLOW DOWN BLR. 21 20 MINS.	0800 1200
2000	2400		12	CHANGED BURNERS BLR. 22	2000 2400
0000	0400	SAT.	13	BLOW SOOT M.B. 22 & 23	0000 0400
2000	2400	*	13	CHANGED BURNERS M.B. 23	2000 2400
0000	0400	SUN.	14	BLOW SOOT M.B. 22 & 23	0000 0400
0000	0400		14	CHANGED BURNERS M.B. 22	2000 2400
0800	1200	MON.	15	BLOW SOOT M.B. 22 & 23	0000 0400
0800	1200		15	CHANGED BURNERS M.B. 23 @	2000 2400
2000	2400	TUES.	16	BLOW SOOT M.B. 22 & 23	0000 0400
2000	2400		16	START SLOW FIRING M.B. 24 AT 09:20 HRS.	0800 1200
			16	ON LINE M.B. 24 AT 1630 HRS.	1600 2000
			16	OFFLINE M.B. 22 AT 1640 HRS. BOTTOM (15) BLOW DOWN	1600 2000

DAY	DATE		TIME		DAY	DATE
WED.	17	BLOW SOOT BLR. 23 & 24	0000	0400	THU.	25
	17	START SLOW FIRING M.B. 21 (09:25)	0800	1200		25
	17	ON-LINE M.B. 21 AT 1800 HRS.	1600	2000		25
	17	CHANGED BURNERS M.B. 23	2000	2400	FRI.	26
THURS.	18	BLOW SOOT M.B. 21, 23 & 24	0000	0400		26
	18	CHANGED BURNERS M.B. 24 @	2000	2400		26
FRI.	19	BLOW SOOT M.B. 21, 23 & 24	0000	0400		26
	19	OFF LINE M.B. 23 AT 10:15 HRS.	0800	1200	SAT.	27
	19	BOTTOM BLOW DOWN, M.B. 23 (15 MINS)	0800	1200		27
	19	CHANGED BURNERS M.B. 21 @	2000	2400	SUN.	28
SAT.	20	BLOW SOOT M.B. 21 & 24	0000	0400		28
	20	CHANGED BURNERS M.B. 24 @	2000	2400	MON.	29
SUN.	21	BLOW SOOT M.B. 21 & 24	0000	0400		29
	21	START SKIMMING M.B. 21 AT 10:00 HRS.	0800	1200		29
	21	STOPPED SKIMMING M.B. 21 AT 1600 HRS.	1200	1600		29
	21	START SLOW FIRING M.B. 23 AT 1800 HRS.	1600	2000		29
	21	CHANGED BURNERS M.B. 21 @	2000	2400		29
	21	ON LINE M.B. 23 AT 23:15 HRS.	2000	2400		29
MON.	22	BLOW SOOT BLR. 21, 23 & 24	0000	0400		29
	22	CHANGED BURNERS M.B. 24 @	2000	2400	TUES.	30
TUES.	23	BLOW SOOT M.B. 21, 23 & 24	0000	0400		30
	23	OFF LINE M.B. 23 AT 0725 HRS	0400	0800	WED.	31
	23	BOTTOM BLOW DOWN (15 MINS)	0400	0800		31
	23	START SKIMMING M.B. 21 AT 10:30 HRS. (6 HRS)	0800	1200		31
	23	CHANGED BURNERS M.B. 21 @	2000	2400	THURS.	01
WED.	24	BLOW SOOT M.B. 21 & 24	0000	0400		01
	24	START SLOW FIRING M.B. 23 AT 10:40 HRS.	0800	1200		01
	24	START SKIMMING M.B. 21 AT 10:30 HRS. (6 HRS)	0800	1200	FRI.	02
	24	STOPPED SKIMMING M.B. 21 AT 1630 HRS.	1600	2000		02
	24	ON LINE M.B. 23 AT 1835 HRS	1600	2000		02
	24	CHANGED BURNERS M.B. 24 @	2000	2400	SAT.	03
THURS.	25	BLOW SOOT M.B. 21, 23 & 24	0000	0400		03
	25	START SKIMMING M.B. 23 AT 1000 HRS. (6 HRS)	0800	1200	SUN.	04
	25	STOPPED SKIMMING M.B. 23 AT 1600 HRS.	1200	1600		04

July

↑ ←

TIME		DAY	DATE		121 TIME		
2000	2400	THU.	25	CONTINUE SKIMMING M.B. 23 AT 1700 HRS (6 HRS)	1600	2000	
0800	1200		25	CHANGED BURNERS M.B. 21	2000	2400	
1600	2000		25	STOPPED SKIMMING M.B. 23 AT 23:00 HRS.	2000	2400	
2000	2400	FRI.	26	BLOW SOOT M.B. 21, 23 & 24	0000	0400	
0000	0400		26	OFF LINE M.B. 23 AT 10:25 HRS.	0800	1200	
2000	2400		26	BOTTOM BLOW DOWN M.B. 23 (15 MINS)	0800	1200	
0000	0400		26	CHANGED BURNERS M.B. 24 @	2000	2400	
0800	1200	SAT.	27	BLOW SOOT M.B. 21 & 24	0000	0400	
0800	1200		27	CHANGED BURNERS M.B. 21 @	2000	2400	
2000	2400	SUN.	28	BLOW SOOT M.B. 21 & 24	0000	0400	
0000	0400		28	CHANGED BURNERS M.B. 24 @	2000	2400	
2000	2400	MON.	29	BLOW SOOT M.B. 21 & 24	0000	0400	
0000	0400		29	START SKIMMING M.B. 24 AT 0500 HRS (6 HRS)	0400	0800	
0800	1200		29	STOPPED SKIMMING M.B. 24 AT 11:00 HRS.	0800	1200	
1200	1600		29	START FIRING M.B. 22 AT 1245 HRS.	1200	1600	
1000	2000		29	ON-LINE M.B. 22 AT 1700 HRS	1600	2000	
2000	2400		29	OFF-LINE M.B. 24 AT 17:15 HRS	1600	2000	
2000	2400		29	BOTTOM BLOW DOWN M.B. 24 (15 MINS.)	1600	2000	
0000	0400		29	CHANGED BURNERS M.B. 21 @	2000	2400	
2000	2400	TUES.	30	BLOW SOOT M.B. 21 & 22	0000	0400	
0000	0400		30	CHANGED BURNERS M.B. 22 @	2000	2400	
0400	0800	WED.	31	START SLOW FIRING M.B. 22 AT 09:35 HRS.	0800	1200	
0400	0800		31	ON LINE M.B. 23 AT 1500 HRS.	1200	1600	
0800	1200	JULY	31	CHANGED BURNERS M.B. 21 @	2000	2400	
2000	2400	THURS.	01	BLOW SOOT M.B. 21, 22 & 23	0000	0400	
0000	0400		01	CHANGED BURNERS M.B. 22.	2000	2400	
0800	1200	↑ ← JUNE 2000					
0800	1200	FRI.	2	BLOW SOOT M.B. 21, 22 & 23	0000	0400	
1600	2000		02	OFF LINE M.B. 21 AT 09:35 HRS.	0800	1200	
1600	2000		02	CHANGED BURNERS M.B. 23 @	2000	2400	
2000	2400	SAT.	03	BLOW SOOT M.B. 22 & 23	0000	0400	
0000	0400		03	CHANGED BURNERS M.B. 22.	2000	2400	
0800	1200	SUN.	04	BLOW SOOT M.B. 22 & 23	0000	0400	
1200	1600		04	START SKIMMING M.B. 23 AT 09:30 HRS. (6 HRS)	0800	1200	

DAY	122 DATE	JUNE 2000	TIME	DAY
SUN.	04	STOPPED SKIMMING M.B. 23 AT 1530 HRS.	1200 1600	MON.
	04	START SKIMMING M.B. 22 AT 1640 HRS (6 HRS)	1600 2000	
	04	CHANGED BURNERS M.B. 23	2000 2400	TUE.
	04	STOPPED SKIMMING M.B. 22 AT 22:40 HRS.	2000 2400	
MON.	05	BLOW SOOT M.B. 22 & 23	0000 0400	
	05	START SKIMMING M.B. 23 AT 0415 HRS (6 HRS)	0400 0800	
	05	STOPPED SKIMMING M.B. 23 AT 10:15 HRS.	0800 1200	WED.
	05	START SLOW FIRING M.B. 21 AT 09:00 HRS	0800 1200	
	05	ON LINE M.B. 21 AT 1445 HRS.	1200 1600	
	05	CHANGED BURNERS M.B. 22. @	2000 2400	
TUE.	06	BLOW SOOT M.B. 21, 22 & 23	0000 0400	THU.
	06	OFF LINE M.B. 23 AT 0725 HRS	0400 0800	
	06	BOTTOM BLOW DOWN M.B. 23 (20 MINS)	0800 1200	FRI.
	06	CHANGED BURNERS M.B. 21.	2000 2400	
WED.	07	BLOW SOOT M.B. 21 & 22	0000 0400	
	07	START SLOW FIRING M.B. 24 AT 09:10 HRS.	0800 1200	SAT.
	07	ON LINE M.B. 24 AT 1800 HRS	1600 2000	
	07	CHANGED BURNERS M.B. 22.	2000 2400	SUN.
THURS.	08	BLOW SOOT M.B. 21, 22 & 24	0000 0400	
	08	START SKIMMING M.B. 22 AT 10:30 HRS. (6 HRS)	0800 1200	
	08	STOPPED SKIMMING M.B. 22 CHANGED OVER TO M.B. 21 AT 1630 (6 HRS)	1600 2000	
	08	CHANGED BURNERS M.B. 21	2000 2400	MON.
	08	STOPPED SKIMMING M.B. 21 AT 22:30 HRS	2000 2400	
FRI.	09	BLOW SOOT M.B. 21, 22 & 24	0000 0400	
	09	OFF LINE M.B. 24 AT 10:15 HRS.	0800 1200	
	09	BOTTOM BLOW DOWN M.B. 24 (15 MINS)	0800 1200	
	09	CHANGED BURNERS M.B. 22	2000 2400	TUE.
SAT.	10	BLOW SOOT M.B. 21 & 22	0000 0400	
*	10	CHANGED BURNER M.B. 21	2000 2400	
SUN.	11	BLOW SOOT M.B. 21 & 22	0000 0400	WED.
	11	START SKIMMING M.B. 22 AT 13:30 HRS. (6 HRS)	1200 1600	
	11	STOPPED SKIMMING M.B. 22 AT 1930 HRS.	1600 2000	
	11	CHANGED BURNER M.B. 21	2000 2400	THU.

TIME		DAY	DATE	TIME	TIME
1200	1600	MON.	12	BLOW SOOT M.B. 21 AND 22 @	0000 0400
1600	2000		12	CHANGED BURNER M.B. 21	2000 2400
2000	2400	TUE.	13	BLOW SOOT M.B. 21 & 22	0000 0400
2000	2400		13	OFF LINE M.B. 21 AT 13:05 HRS.	1200 1600
0000	0400		13	ON LINE M.B. 21 AT 1630 HRS.	1600 2000
0400	0800		13	CHANGED BURNER M.B. 22	2000 2400
0800	1200	WED.	14	BLOW SOOT M.B. 21 & 22 @	0000 0400
0800	1200		14	Had slow firing M.B. 24 at 0930 hrs.	0800 1200
1200	1600		14	ON LINE M.B. 24 AT 1800 HRS.	1600 2000
2000	2400		14	CHANGED BURNER M.B. 21	2000 2400
0000	0400	THU.	15	BLOW SOOT M.B. 21, 22, AND 24	0000 0400
0400	0800		15	CHANGED BURNER M.B. 22	2000 2400
0800	1200	FRI.	16	BLOW SOOT M.B. 21, 22 and 24 @	0000 0400
2000	2400		16	OFF LINE M.B. 24 at 1020 HRS ^{BOTTOM} _{FLOW DOWN 15 MINS}	0800 1200
0000	0400		16	CHANGED BURNER M.B. 21	2000 2400
0800	1200	SAT.	17	BLOW SOOT M.B. 21 AND 22. @	0000 0400
1600	2000		17	CHANGED BURNER M.B. # 22	2000 2400
2000	2400	SUN.	18	BLOW SOOT M.B. 21 AND 22. @	0000 0400
0000	0400		18	START SKIMMING M.B. 22 0830 HRS (6 HRS)	0800 1200
0800	1200		18	STOPPED SKIMMING M.B. 22 AT 14:30 HRS.	1200 1600
1600	2000		18	CHANGED BURNER M.B. 21	2000 2400
2000	2400	MON.	19	BLOW SOOT M.B. 21 AND 22	0000 0400
2000	2400		19	START SKIMMING M.B. 22 AT 1200 HRS. (6 HRS.)	1200 1600
0000	0400		19	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO BLR. 21 AT 1800 HRS. (6 HRS.)	1600 2000
0800	1200		19	CHANGED BURNER M.B. 22	2000 2400
0800	1200		19	STOPPED SKIMMING M.B. 21 AT 2400 HRS	2000 2400
2000	2400	TUE.	20	BLOW SOOT M.B. 21 and 22 @	0000 0400
0000	0400		20	CHANGED BURNER M.B. 21	2000 2400
2000	2400		20	TEST FIRING M.B. 24 at 2100 HRS ALL BURNERS	2000 2400
0000	0400	WED.	21	BLOW SOOT M.B. 21 & 22.	0000 0400
1200	1600		21	START slow firing M.B. 24 at 0930 HRS.	0800 1200
1600	2000		21	ON LINE M.B. 24 AT 1815 HRS.	1600 2000
2000	2400		21	CHANGED BURNER M.B. 22	2000 2400
		THU.	22	BLOW SOOT M.B. 21, 22, AND 24	0000 0400

DAY	DATE	TIME	DAY
THU.	22	CHANGED BURNER M.B. 21	(SAT.
	22	SKIMMING M.B. 24 (6 HRS.) 2100 Hrs to 0300 Hrs.	
FRI.	23	BLOW SOOT M.B. 21, 22 & 24	
	23	STOPPED SKIMMING M.B. 24 AT 03:00 HRS.	
	23	OFF LINE M.B. 24 AT 10:55 HRS.	SUN.
	23	BOTTOM BLOW DOWN M.B. 24 (15 MINS)	
	23	CHANGED BURNER M.B. 22	
SAT.	24	BLOW SOOT M.B. 21 and 22.	
	24	CHANGED BURNER M.B. 21	
SUN.	25	BLOW SOOT M.B. 21 AND 22.	
	25	START SKIMMING M.B. 22 AT 14:00 HRS (6 HRS.)	
	25	STOPPED SKIMMING M.B. 22 AT 2000 Hrs.	MON.
	25	CHANGED BURNER M.B. 22	
MON.	26	BLOW SOOT M.B. 21 & 22 @	
	26	CHANGED BURNER M.B. 21	
TUE.	27	BLOW SOOT M.B. 21 & 22.	TUE.
	27	SKIMMING M.B. 22 (6 HRS.) 1000 Hrs. to 1600 Hrs.	
	27	STOPPED SKIMMING M.B. 22 AT 1600 HRS.	
	27	CHANGED BURNER M.B. 22	WED.
WED.	28	BLOW SOOT M.B. 21 & 22.	
	28	START FIRING M.B. 24 AT 09:05 HRS.	
	28	ON LINE M.B. 24 AT 1805 HRS.	
	28	CHANGED BURNER M.B. 21	
THU.	29	BLOW SOOT M.B. 21, 22, & 24	
	29	CHANGED BURNER M.B. 22	
FRI.	30	BLOW SOOT M.B. 21, 22, & 24	THU.
	30	OFF LINE M.B. 24 AT 1100 HRS BOTTOM BLOW DOWN (20 MINS)	
	30	START SKIMMING M.B. 22 AT 1400 HRS (8 HRS.)	
	30	CHANGED BURNER M.B. 21	
	30	STOPPED SKIMMING M.B. 22 AT 2200 HRS.	FRI.

TIME		DAY	DATE	(JULY 2000)	125 TIME	
2000	2400	SAT.	01	BLOW SOOT M.B. 21 & 22.	0000	0400
2000	2400		01	START SKIMMING M.B. 21 AT 1900 HRS. (4 HRS.)	1600	2000
0000	0400		01	CHANGED BURNER M.B. 22	2000	2400
0000	0400		01	STOPPED SKIMMING M.B. 21 at 2300 HRS. ^{CHANGED BURNER} M.B. 22 (4 HRS.)	2000	2400
0800	1200	SUN.	02	BLOW SOOT M.B. 21 & 22.	0000	0400
0800	1200		02	STOPPED SKIMMING M.B. 22 at 03:00 HRS. changed over to Blr. 21 (4 HRS.)	0000	0400
2000	2400		02	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 0700 HRS. (4 HRS.)	0400	0800
0000	0400		02	STOPPED SKIMMING M.B. 22 at 1150 HRS. CHANGED OVER TO M.B. 21 (4 HRS.)	0800	1200
2000	2400		02	STOPPED SKIMMING M.B. 21 AT 15:00 HRS. changed over to M.B. 22. (4 HRS.) @	1200	1600
0000	0400		02	CONTINUE SKIMMING M.B. 22 (4-HRS.)	1600	2000
1200	1600		02	CHANGED BURNER M.B. 21	2000	2400
1600	2000	MON.	03	BLOW SOOT M.B. 21 and 22 @	0000	0400
2000	2400		03	STOPPED SKIMMING M.B. 22 AT 12:00 HRS.	2000	2400
0000	0400		03	STOPPED SKIMMING M.B. 22 AT 0500 HRS.	0400	0800
2000	2400		03	CHANGED BURNER M.B. 22	2000	2400
0000	0400	TUE.	04	BLOW SOOT M.B. 21 & 22.	0000	0400
0800	1200		04	START SKIMMING M.B. 21 AT 1940 HRS. (6 HRS.)	1600	2000
1200	1600		04	CHANGED BURNER M.B. 21	2000	2400
2000	2400	WED.	05	BLOW SOOT M.B. 21 and 22. HRS.	0000	0400
0000	0400		05	STOPPED SKIMMING M.B. 21 at 0200 HRS. changed over to Blr. # 22. (4 HRS.)	0000	0400
0800	1200		05	STOPPED SKIMMING M.B. 22 AT 0800 HRS.	0400	0800
1600	2000		05	START FIRING M.B. 24 at 0910 HRS.	0800	1200
2000	2400		05	START FIRING M.B. 23 AT 14:40 HRS.	1200	1600
0000	0400		05	ON LINE M.B. 23 AT 1850 HRS.	1600	2000
2000	2400		05	CHANGED BURNER M.B. 22	2000	2400
0000	0400	THU.	06.	BLOW SOOT M.B. 21, 22, and 23.	0000	0400
0800	1200		06	START SKIMMING M.B. 22 AT 1700 HRS. (4 HRS.)	1600	2000
1200	1600		06	CHANGED BURNER M.B. 21	2000	2400
2000	2400		06	STOP SKIMMING M.B. 22 at 2100 HRS CHANGED OVER TO M.B. 23 (6 HRS.)	2000	2400
0000	2400	FRI.	07	BLOW SOOT M.B. 21, 22, and 23	0000	0400
			07	STOPPED SKIMMING M.B. 23 AT 03:00 HRS.	0000	0400
			07	OFF LINE M.B. 23 at 1100 HRS.	0800	1200
			07	BOTTOM BLOW DOWN 20 MINS.	0800	1200
			07	CHANGED BURNER M.B. 22	2000	2400

DAY	DATE	TIME	DAY
SAT.	08	BLOW SOOT M.B. 21 & 22	FRI.
	08	SKIMMING M.B. 22 AT 19:00 HRS (6 HRS)	SAT
	08	CHANGED BURNER'S M.B. 21	
SUN.	09	BLOW SOOT M.B. 21 & 22	
	09	STOPPED SKIMMING M.B. 22 AT 0100 HRS CHANGED OVER TO M.B. 21 (6 HRS.)	
	09	STOPPED SKIMMING M.B. 21 AT 07:00 HRS.	START
	09	START SKIMMING M.B. 22 AT 0830 HRS. (8 HRS)	
	09	STOPPED SKIMMING M.B. 22 AT 16:30 HRS.	
	09	SKIMMING M.B. 22 AT 19:00 HRS. (6 HRS)	
	09	CHANGED BURNER'S M.B. 22	MON.
	09	STOPPED SKIMMING M.B. 22 AT 2400 HRS.	
MON.	10	BLOW SOOT M.B. 21 & 22	TUE.
	10	CHANGED BURNER'S M.B. 21	
TUE.	11	BLOW SOOT M.B. 21 & 22	
	11	TESTED ALL BURNER'S M.B. 23	WED.
	11	CHANGED BURNER'S M.B. 22	
	11	START SKIMMING M.B. 22 AT 2030 HRS.	
WED	12	BLOW SOOT M.B. 21 & 22	
	12	STOPPED SKIMMING M.B. 22 AT 0030 HRS CHANGED OVER TO M.B. 21 (4 HRS)	THU.
	12	STOPPED SKIMMING M.B. 21 AT 04:30 HRS CHANGED OVER TO M.B. 22 (4 HRS.)	
	12	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 0830 HRS. (4 HRS)	
	12	STOPPED SKIMMING M.B. 21 AT 0915 HRS	
	12	START SLOW FIRING M.B. 23 AT 0900 HRS.	
	12	ON LINE M.B. 23 AT 18:00 HRS.	FRI.
	12	START SKIMMING M.B. 22 AT 1900 HRS (8 HRS)	
	12	CHANGED BURNER'S M.B. 21	
THU.	13	BLOW SOOT M.B. 21, 22 & 23	
	13	STOP SKIMMING M.B. 22 AT 0300 HRS.	SAT
	13	START SKIMMING M.B. 23 AT 06:00 HRS (6 HRS)	
	13	STOPPED SKIMMING M.B. 23 AT 1200 HRS.	
	13	CHANGED BURNER'S M.B. 22	
FRI.	14	BLOW SOOT M.B. 22, 21 & 23	SUN
	14	OFF LINE M.B. 23 AT 1050 HRS.	
	14	BOTTOM BLOW DOWN M.B. 23 (15 MIN)	

TIME		DAY	DATE		127 TIME	
2000	0400	FRI.	14	CHANGED BURNER'S M.B. 21	2000	2400
600	2000	SAT	15	BLOW SOOT M.B. 21 & 22	0000	0400
1000	2400		15	START SKIMMING M.B. 22 AT 17:00 HRS. (4 HRS.)	1600	2000
2000	0400		15	CHANGED BURNER'S M.B. 22	2000	2400
600	0400		15	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 2300 HRS. (4 HRS.)	2000	2400
400	0800	SUN	16	BLOW SOOT M.B. 21, & 22	0000	0400
0800	1200		16	STOPPED SKIMMING M.B. 21 AT 0300 HRS CHANGED OVER TO M.B. 22 (4 HRS.)	0000	0400
1600	2000		16	STOPPED SKIMMING M.B. 22 AT 07:00 HRS.	0400	0800
1600	2000		16	CHANGED BURNER'S M.B. 21	2000	2400
2000	2400	MON.	17	BLOW SOOT M.B. 21 & 22	0000	0400
2000	2400		17	CHANGED BURNER'S M.B. 22	2000	2400
2000	0400	TUE.	18	BLOW SOOT M.B. 21 & 22	0000	0400
2000	2400		18	CHANGED BURNER'S M.B. 21	2000	2400
2000	0400		18	TESTED ALL BURNER'S M.B. 23 AT 2100 HRS.	2000	2400
2300	1200	WED.	19	BLOW SOOT M.B. 21 & 22	0000	0400
2000	2400		19	START SLOW FIRING M.B. 23 AT 0930 HRS.	0800	1200
1000	2400		19	ON LINE M.B. 23 AT 17:50 HRS.	1600	2000
2000	0400		19	CHANGED BURNER'S M.B. 22	2000	2400
1000	0400	THU.	20	BLOW SOOT M.B. 21, 22, & 23	0000	0400
1400	0800		20	START SKIMMING M.B. 22 AT 06:00 HRS (6 HRS)	0400	0800
0800	1200		20	STOPPED SKIMMING M.B. 22 ^{UP TO} 1800 HRS.	0800	1200
0800	1200		20	STOPPED SKIMMING M.B. 22 AT 1800 HRS. CHANGED OVER TO M.B. 23 (8 HRS.)	1600	2000
0800	1200		20	CHANGED BURNER'S M.B. 21	2000	2400
1600	2000	FRI.	21	BLOW SOOT M.B. 21, 22 & 23	0000	0400
1600	2000		21	STOPPED SKIMMING M.B. 23 AT 0200 HRS.	0000	0400
1000	2400		21	OFF LINE M.B. 23 AT 1040 HRS. BOTTOM BLOW DOWN M.B. 23 (20 MINS.)	0800	1200
2000	0400		21	CHANGED BURNER'S M.B. 22	2000	2400
2000	0400	SAT	22	BLOW SOOT M.B. 21 & 22	0000	0400
1400	0800		22	START SKIMMING M.B. 22 AT 19:00 HRS (4 HRS)	1600	2000
0800	1200		22	CHANGED BURNER'S M.B. 21	2000	2400
2000	2400		22	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 2300 HRS. (4 HRS.)	2000	2400
2000	0400	SUN	23	BLOW SOOT M.B. 21 & 23	0000	0400
0800	1200		23	STOPPED SKIMMING M.B. 21 CHANGED OVER TO M.B. 22 AT 0300 HRS (4 HRS)	0000	0400
0800	1200				0000	0400

DAY	DATE		TIME	DAY	DATE
SUN.	23	STOPPED SKIMMING M.B. 22 07:00 HRS. CHANGED OVER M.B. 21 (4 HRS.)	0400 0800	TUE	01
	23	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 0930 HRS. (8-HRS)	0800 1200		01
	23	STOPPED SKIMMING M.B. 22 17:00 HRS.	1600 2000		01
	23	CHANGED BURNER'S M.B. 22	2000 2400		01
MON.	24	BLOW SOOT M.B. 21 & 22	0000 0400	WED.	02
	24	TESTED ALL BURNER'S M.B. 23 & 24	0800 1200		02
	24	CHANGED BURNER'S M.B. 21	2000 2400		02
TUE	25	BLOW SOOT M.B. 21 & 22	0000 0400		02
	25	CHANGED BURNER'S M.B. 22	2000 2400	THU.	03
WED.	26	BLOW SOOT M.B. 21 & 22	0000 0400		03
	26	START SLOW FIRING M.B. 24 AT 0915 HRS.	0800 1200	FRI.	04
	26	ON LINE M.B. 24 AT 17:55 HRS.	1600 2000		04
	26	CHANGED BURNER'S M.B. 21	2000 2400		04
THU.	27	BLOW SOOT M.B. 21, 22, & 24	0000 0400	SAT.	05
	27	CHANGED BURNER'S M.B. 24	2000 2400		05
FRI.	28	BLOW SOOT M.B. 21, 22 & 24	0000 0400		05
	28	OFF LINE M.B. 22 AT 1050 HRS. BOTTOM BLOW DOWN M.B. 22 (9X CLOSE-OPEN)	0800 1200		05
	28	CHANGED BURNER'S M.B. 21	2000 2400		05
SAT	29	BLOW SOOT M.B. 21 & 24	0000 0400	SUN.	06
	29	START SLOW FIRING M.B. 23 AT 17:55 HRS.	1600 2000		06
	29	ON LINE M.B. 23 AT 2400 HRS.	2000 2400	MON.	07
SUN	30	BLOW SOOT M.B. 21, 23, & 24	0000 0400		07
	30	START SKIMMING M.B. 21 AT 0830 HRS.	0800 1200	TUES.	08
	30	STOP SKIMMING M.B. 21 AT 1200 HRS. CHANGE OVER TO M.B. 23 (4 HRS.)	1200 1000		08
	30	STOPPED SKIMMING M.B. 24 19:00 HRS. CHANGED OVER M.B. 21 (4 HRS.)	1600 2000		08
	30	CHANGED BURNER'S M.B. 24	2000 2400	WED.	09
MON	31	BLOW SOOT M.B. 21, 23 & 24	0000 0400		09
	31	CHANGED BURNER'S M.B. 21	2000 2400		09
					09
					09
				THURS.	10
					10
					10
					10

TIME		DAY	DATE	AUGUST 2000	129	TIME
0	0800	TUE	01	BLOW SOOT M.B. 21, 23 & 24	0000	0400
00	1200		01	OFF LINE M.B. 23 AT 07:30 HRS.	0400	0800
0	2000		01	BOTTOM BLOW DOWN M.B. 23. (15 MINS.)	0400	0800
00	2400		01	CHANGED BURNER'S M.B. 24	2000	2400
00	0400	WED.	02	BLOW SOOT M.B. 21 & 24	0000	0400
00	1200		02	START SLOW FIRING M.B. 23 AT 0900 HRS.	0800	1200
00	2400		02	ON LINE M.B. 23 AT 18:15 HRS.	1600	2000
00	0400		02	CHANGED BURNER'S M.B. 21	2000	2400
0	2400	THU.	03	BLOW SOOT M.B. 21, 23, & 24	0000	0400
0	0400		03	CHANGED BURNER'S M.B. 24	2000	2400
0	1200	FRI.	04	BLOW SOOT M.B. 21, 23, & 24	0000	0400
0	2000		04	OFF LINE M.B. 23 AT 1045 HRS.	0800	1200
00	2400		04	CHANGED BURNER'S M.B. 21	2000	2400
00	0400	SAT.	05	BLOW SOOT M.B. 21 & 24	0000	0400
00	2400		05	CHANGING OF WATCH	1200	1600
00	0400		05	START SLOW FIRING M.B. 22 AT 1540 HRS.	1200	1600
00	1200		05	ON LINE M.B. 22 AT 22:00 HRS.	2000	2400
00	2400		05	OFF LINE M.B. 24 AT 22:20 HRS.	2000	2400
00	0400	SUN.	06	BLOW SOOT M.B. 21 & 22	0000	0400
0	2000		06	CHANGED BURNERS M.B. 21 @	2000	2400
00	2400	MON.	07	BLOW SOOT M.B. 21 & 22	0000	0400
00	0400		07	CHANGED BURNERS M.B. 22	2000	2400
00	1200	TUES.	08	BLOW SOOT M.B. 21 & 22	0000	0400
0	1000		08	TESTED ALL BURNERS M.B. 23	1200	1600
00	2000		08	CHANGED BURNERS M.B. 21	2000	2400
00	2400	WED.	09	BLOW SOOT M.B. 21 & 22	0000	0400
0	0400		09	START SLOW FIRING M.B. 23 AT 09:25 HRS.	0800	1200
0	2400		09	ON LINE M.B. 23 AT 1800 HRS.	1600	2000
			09	CHANGED BURNERS M.B. 22 @	2000	2400
			09	START SKIMMING M.B. 21 AT 2000 HRS. (8 HRS.)	2000	2400
		THURS.	10	BLOW SOOT M.B. 21, 22 & 23	0000	0400
			10	STOPPED SKIMMING M.B. 21 AT 0400 HRS.	0000	0400
			10	START SKIMMING M.B. 23 09:30 HRS. (4 HRS.)	0800	1200
			10	STOPPED SKIMMING M.B. 23 AT 1330 HRS.	1200	1600

DAY	130 DATE		TIME	TIME	DAY	DATE
THU.	10	CHANGED BURNERS M.B. 23 @	2000	2400	SAT.	19
	10	(START SKIMMING M.B. 23 AT 23:00 HRS. (8H))	2000	2400		19
FRI.	10	BLOW SOOT M.B. 21, 22 & 23	0000	0400	SUN.	20
	11	STOPPED SKIMMING M.B. 23 AT 09:00 HRS	0400	0800		20
	11	OFF LINE M.B. 21 10:40 HRS.	0800	1200	MON.	21
	11	BOTTOM BLOW DOWN M.B. 21 (15 MINS.)	0800	1200		21
	11	START FIRING M.B. 21 at 11:55 HRS	1600	2000		21
	11	start skimming M.B. 23 21:30 HRS. (6 HOURS)	2000	2400	TUES.	22
SAT	12	OFF LINE M.B. 24 AT 0015 HRS	0000	0400		22
	12	OFF LINE M.B. 22 AT 0035 HRS. BOTTOM BLOW DOWN M.B. 22 (15 MINS)	0000	0400		22
	12	BLOW SOOT M.B. 23 & 24	0000	0400		22
	12	STOPPED SKIMMING M.B. 23 at 05:00 HRS	0400	0800		22
	12	CHANGED BURNERS M.B. 23 @	2000	2400	WED.	23
SUN.	13	BLOW SOOT M.B. 23 & 24	0000	0400		23
	13	CHANGED BURNERS M.B. 24 @	2000	2400	THURS.	24
MON.	14	BLOW SOOT M.B. 23 & 24	0000	0400		24
	14	CHANGED BURNERS M.B. 23	2000	2400		24
TUES.	15	BLOW SOOT M.B. 23 & 24	0000	0400		24
	15	CHANGED BURNERS M.B. 24	2000	2400	FRI.	25
WED.	16	BLOW SOOT M.B. 23 & 24	0000	0400		25
	16	TESTED ALL BURNERS M.B. 22	0000	0400		25
	16	start slow firing M.B. 22 09:20 HRS.	0800	1200		25
	16	ON LINE M.B. 22 at 10:30 HRS.	1600	2000		25
	16	CHANGED BURNERS M.B. 23	2000	2400		25
	16	START SKIMMING M.B. 23 21:00 HRS. (8 HRS.)	2000	2400	SAT	26
THURS.	17	BLOW SOOT M.B. 22, 23 & 24	0000	0400		26
	17	STOPPED SKIMMING M.B. 23 at 05:00 HRS	0400	0800		26
	17	SKIMMING M.B. 23 10:00 HRS. (6 HRS.)	0800	1200		26
	17	STOPPED SKIMMING M.B. 23 at 17:00 HRS	1600	2000	SUN.	27
	17	CHANGED BURNERS M.B. 24 @	2000	2400		27
FRI.	18	BLOW SOOT M.B. 22, 23 & 24	0000	0400		27
	18	OFF LINE M.B. 22 11:15 HRS	0800	1200		27
	18	BOTTOM BLOW DOWN M.B. 22. (15 MINS)	0800	1200	MON.	28
	18.	CHANGED BURNERS M.B. 23	2000	2400		

TIME		DAY	DATE		131	TIME
2000	2400	SAT.	19	BLOW SOOT M.B. 23 & 24	0000	0400
2000	2400		19	CHANGED BURNERS M.B. 24 @	2000	2400
2000	0400	SUN.	20	BLOW SOOT M.B. 23 & 24	0000	0400
2400	0800		20	CHANGED BURNERS M.B. 23 @	2000	2400
2800	1200	MON.	21	BLOW SOOT M.B. 23 & 24	0000	0400
0800	1200		21	START SKIMMING M.B. 23 AT 1300 HRS. (4 HRS)	1200	1600
1600	2000		21	CHANGED BURNERS M.B. 24	2000	2400
2000	2400	TUES.	22	BLOW SOOT M.B. 23 & 24	0000	0400
2000	0400		22	TESTED ALL BURNERS M.B. 22	0000	0400
10000	0400		22	START SLOW FIRING M.B. 22. (08:25 HRS.)	0800	1200
2000	0400		22	OK Line M.B. 22. 18:10 HRS.	1600	2000
0400	0800		22	CHANGED BURNERS M.B. 23 @	2000	2400
2000	2400	WED.	23	BLOW SOOT M.B. 22, 23 & 24	0000	0400
2000	0400		23	CHANGED BURNERS M.B. 24 @	2000	2400
2800	2400	THURS.	24	BLOW SOOT M.B. 22, 23 & 24	0000	0400
2000	0400		24	START SKIMMING M.B. 23 AT 1400 HRS. (6 HRS)	1200	1600
2000	2400		24	STOPPED SKIMMING M.B. 23 AT 2000 HRS. CHANGED OVER M.B. 22 AT 2000 HRS. (6 HRS)	1600	2000
2000	0400		24	CHANGED BURNERS M.B. 22.	2000	2400
2000	2400	FRI.	25	BLOW SOOT M.B. 22, 23 & 24	0000	0400
2000	0400		25	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 24 AT 0200 HRS. (4 HRS.)	0000	0400
2000	0400		25	STOPPED SKIMMING M.B. 24 AT 0400 HRS. CHANGED OVER TO M.B. 23 AT 0400 HRS. (6 HRS.)	0400	0800
2800	1200		25	START SKIMMING M.B. 24 AT 0530, STOPPED AT 0730 HRS. CHANGED OVER M.B. 22 AT 0730 HRS. (6 HRS)	0730	0830
1600	2000		25	STOPPED SKIMMING M.B. 23 08:30 HRS.	0830	1300
2000	2400		25	CHANGED BURNERS M.B. 23 @	2000	2400
2000	2400	SAT	26	BLOW SOOT M.B. 22, 23 & (24)	0000	0400
2000	0400		26	OFF LINE M.B. 24 AT 0240 HRS. BOTTOM BLOW DOWN M.B. 24 (15 MINS.)	0000	0400
2400	2800		26	Start Skimming M.B. 23. 19:30 HRS.	1600	2000
2800	1200		26	CHANGED BURNERS M.B. 22. @	2000	2400
1600	2000	SUN.	27	BLOW SOOT M.B. 22 & 23	0000	0400
2000	2400		27	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 22 AT 0030 HRS. (5 HRS)	0000	0400
0000	0400		27	STOPPED SKIMMING M.B. 22 AT 0530 HRS.	0400	0800
0800	1200		27	CHANGED BURNERS M.B. 23 @	2000	2400
0800	1200	MON.	28	BLOW SOOT M.B. 22 & 23	0000	0400
2000	2400					

DAY	DATE		TIME		DAY	DATE
MON.	28.	CHANGED BURNERS M.B. 22	2000	2400	TUE.	05
TUES.	29.	BLOW SOOT M.B. 22 & 23	0000	0400		05
	29	CHANGED BURNERS M.B. 23	2000	2400		05
	29	START SKIMMING M.B. 23. 2000 HRS. (5 HRS.)	2000	2400		05
WED.	30	BLOW SOOT M.B. 22 & 23	0000	0400		05
	30	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 22 AT 0100 HRS. (5 HRS.)	0000	0400	WED.	06
	(30)	STOPPED SKIMMING M.B. 22. 0200 HRS.	0400	0800		06
	(30)	Start slow firing M.B. 21 09:35 HRS.	0800	1200		06
	(30)	ON LINE M.B. 21 AT 1200 HRS.	1600	2000		06
	(30)	CHANGED BURNERS M.B. 22. @	2000	2400		06
THURS.	31	BLOW SOOT M.B. 21, 22 & 23	0000	0400	THU.	07
	(31)	CHANGED BURNERS M.B. 23	2000	2400		07
	(31)	Start (skimming M.B. 22. (22:00 HRS.) (5 HRS.)	2000	2400		07

SEPTEMBER '00

	1					07
FRI.	01	BLOW SOOT M.B. 21, 22 & 23	0000	0400	FRI.	08
	01	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0300 HRS. (5 HRS.)	0000	0400		08
	01	STOPPED SKIMMING M.B. 23 AT 0800 HRS.	0400	0800		08
	01	OFF LINE M.B. 21 10:40 HRS.	0800	1200		08
	01	BOTTOM BLOW DOWN M.B. 21 (15 MIN.)	0800	1200		08
	01	CHANGED BURNERS M.B. 22.	2000	2400		08
	01	START SKIMMING M.B. 22. 2000 HRS. (6 HRS.)	2000	2400	SAT.	09
SAT.	02	BLOW SOOT M.B. 22 & 23	0000	0400		09
	02	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0200 HRS. (6 HRS.)	0000	0400		09
	02	STOPPED SKIMMING M.B. 23 AT 0800 HRS.	0400	0800		09
	02	CHANGED BURNERS M.B. 23	2000	2400	SUN.	10
	02	START SLOW FIRING M.B. 24 HRS.	2000	2400		10
SUN.	03.	Start. SLOW FIRING M.B. 21 AT 00:30 HRS.	0000	0400		10
	03	Blow Soot. M.B. 22 & 23	0000	0400		10
	03	ON LINE M.B. 21 AT 0600 HRS.	0400	0800		10
	03	CHANGED BURNERS M.B. 22	2000	2400		10
MON.	04	BLOW SOOT M.B. 21, 22 & 23 @	0000	0400	MON.	11
	04	CHANGED BURNERS M.B. 23	2000	2400		11
	04	START SKIMMING M.B. 23 AT 2300 (5 HRS.)	2000	2400		11

CHANGED
 &
 WATER

TIME		DAY	DATE		TIME	
2000	2400	TUE.	05	BLOW SOOT M.B. 21, 22, & 23	0000	0400
0000	0400		05	STOPPED SKIMMING M.B. 23 AT 04:00 HRS.	0000	0400
2000	2400		05	Tested firing ALL BURNERS M.B. 24	1200	1600
2000	2400		05	CHANGED BURNERS M.B. 22	2000	2400
0000	0400		05	START SKIMMING M.B. 23 @ 04:00 HRS. (6 HRS.)	2000	2400
0000	0400	WED.	06	BLOW SOOT M.B. 21, 22, & 23	0000	0400
0400	0800		06	STOPPED SKIMMING M.B. 23 AT 04:00 HRS. 20 MINS.	0000	0400
0800	1200		06	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 22 AT 0500 HRS. (5 HRS.)	0400	0800
1600	2000		06	STOPPED SKIMMING M.B. 22 AT 1000 HRS.	0800	1200
2000	2400		06	CHANGED BURNER M.B. 21	2000	2400
2000	0400	THU.	07	BLOW SOOT M.B. 21, 22, & 23	0000	0400
2000	2400		07	Start skimming M.B. 22. 01:00 HRS. (5 HOURS)	0000	0400
2000	2400		07	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0600 HRS. (8-HRS.)	0400	0800
			07	STOPPED SKIMMING M.B. 23 14:00 HRS.	1200	1600
			07	CHANGED BURNERS M.B. 22	2000	2400
2000	0400	FRI.	08	BLOW SOOT M.B. 21, 22, & 23 @	0000	0400
0000	0400		08	START SKIMMING M.B. 23 01:30 HRS. (10 HRS.)	0000	0400
0400	0800		08	STOPPED SKIMMING M.B. 23 AT 1000 HRS.	0800	1200
0800	1200		08	OFF LINE M.B. 21 AT 1025 HRS. BOTTOM	0800	1200
0800	1200		08	BLOW DOWN M.B. 21 FOR 15 MINS.	0800	1200
2000	2400		08	CHANGED BURNERS M.B. 23	2000	2400
2000	2400	SAT.	09	BLOW SOOT M.B. 22 & 23 @	0000	0400
2000	0400		09	CHANGED BURNERS M.B. 22	2000	2400
0000	0400		09	SKIMMING M.B. 22-23 @ (6 HRS)	2000	2400
0400	0800		09	START FIRING M.B. 24 2355	2000	2400
2000	2400	SUN.	10	BLOW SOOT M.B. 22 & 23	0000	0400
2000	2400		10	ON LINE M.B. 24 AT 0600 HRS.	0400	0800
0000	0400		10	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0730 HRS. (6 HRS.)	0400	0800
0000	0400		10	STOPPED SKIMMING M.B. 23 13:00 HRS. CHANGED OVER M.B. 22 (6 HOURS)	1000	1600
2400	0800		10	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 1900 HRS. (6 HRS.)	1600	2000
2000	2400		10	CHANGED BURNERS M.B. 23	2000	2400
0000	0400	MON.	11	BLOW SOOT M.B. 22, 23, & 24	0000	0400
0000	0400		11	STOPPED SKIMMING M.B. 23 01:00 HRS. CHANGED OVER M.B. 22 (6 HRS.)	0000	0400
0000	0400		11	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0700 HRS. (6 HRS.)	0400	0800

DAY	DATE	CONT'S	TIME		DAY	DATE
MON.	11	STOPPED SKIMMING M.B. 23 SKIMMING M.B. 23 18:00 HRS. STARTED SKIMMING M.B. 23 AT 10 HRS.	1200	1600	WED.	20
	11	CHANGED BURNERS M.B. 24	2000	2400		20
	11	STOPPED SKIMMING M.B. 23 AT 2300 HRS.	2000	2400	THU.	21
TUE.	12	BLOW SOOT M.B. 22, 23, & 24	0000	0400		21
	12	SKIMMING M.B. 23 00:30 HRS. STOPPED SKIMMING M.B. 23. 03:00 HRS.	0000	0400	FRI.	22
	12	OFF LINE M.B. 22 AT 0710 HRS. BOTTOM BLOW DOWN M.B. 22 (15 MINS.)	0400	0800		22
	12	CHANGED BURNERS M.B. 23	2000	2400		22
WED.	13	BLOW SOOT M.B. 23 & 24	0000	0400		22
	13	START FIRING M.B. 22 AT 1040 HRS.	0800	1200	SAT.	23
	13	ON LINE M.B. 22 AT 1800 HRS.	1600	2000		23
	13	CHANGED BURNERS M.B. 24	2000	2400	SUN.	24
THU.	14	BLOW SOOT M.B. 22, 23, & 24 @	0000	0400		24
	14	START SKIMMING M.B. 22 03:00 HRS. (10 HRS.)	0000	0400		24
	14	STOPPED SKIMMING M.B. 22 0815 HRS.	0800	1200	MON.	25
	14	CHANGED BURNERS M.B. 23	2000	2400		25
FRI.	15	BLOW SOOT M.B. 22, 23, & 24 @	0000	0400		25
	15	OFF LINE M.B. 24 AT 1055 HRS	0800	1200		25
	15	BOTTOM BLOW DOWN M.B. 24 FOR 20 MINS	0800	1200		25
	15	CHANGED BURNERS M.B. 22	2000	2400		25
	15	START SKIMMING M.B. 23 AT 2030 HRS	2000	2400	TUE.	26
SAT.	16	BLOW SOOT M.B. 22 & 23	0000	0400		26
	16	STOPPED SKIMMING M.B. 23 01:45 HRS.	0000	0400		26
	16	CHANGED BURNERS M.B. 23	2000	2400	WED.	27
SUN.	17	BLOW SOOT M.B. 22 & 23 @	0000	0400		27
	17	CHANGED BURNERS M.B. 22	2000	2400		27
MON.	18	BLOW SOOT M.B. 22 & 23	0000	0400		27
	18	START SLOW FIRING M.B. 24 12:55 HRS. @	1200	1600	THU.	28
	18	ON LINE M.B. 24 AT 1730 HRS.	1600	2000	FRI.	29
	18	CHANGED BURNERS M.B. 23	2000	2400		29
TUE.	19	BLOW SOOT M.B. 22, 23, & 24 @	0000	0400		29
	19	OFF LINE M.B. 24 AT 0725 HRS. BOTTOM BLOW DOWN M.B. 24 (15 MINS)	0400	0800		29
	19	CHANGED BURNERS M.B. 22	2000	2400		29
WED.	20	BLOW SOOT M.B. 22 & 23.	0000	0400		29
	20	START FIRING M.B. 24 AT 0925 HRS	0800	1200	SAT.	30

TIME	DAY	DATE	SEPTMBER 2000	TIME
00 1600	WED.	20	ON LINE M.B. 24 AT 1745 HRS.	1600 2000
00 2400		20	CHANGED BURNERS M.B. 23	2000 2400
00 2400	THU.	21	BLOW SOOT M.B. 22, 23, & 24	0000 0400
00 0400		21	CHANGED BURNERS M.B. 24	2000 2400
00 0400	FRI.	22	BLOW SOOT M.B. 22, 23, & 24 @	0000 0400
00 0800		22	OFF LINE M.B. 22 AT 0945 HRS. BOTTOM	0800 1200
00 2400		22	BLOW DOWN M.B. 22 FOR 20 MINS	0800 1200
00 0400		22	CHANGED BURNERS M.B. 23	2000 2400
300 1200	SAT.	23	BLOW SOOT M.B. 23 & 24	0000 0400
00 2000		23	CHANGED BURNERS M.B. 24	2000 2400
50 2400	SUN.	24	BLOW SOOT M.B. 23 & 24 @	0000 0400
00 0400		24	START SKIMMING M.B. 24 AT 1900 HRS (6 HRS)	1600 2000
00 0400		24	CHANGED BURNERS M.B. 23	2000 2400
300 1200	MON.	25	BLOW SOOT M.B. 23 & 24	0000 0400
00 2400		25	(STOPPED SKIMMING M.B. 24 01:00 HRS.)	0000 0400
00 0400		25	(SKIMMING M.B. 23 02:00 HRS. (6 HRS.))	0000 0400
300 1200		25	STOPPED SKIMMING M.B. 23 AT 0800 HRS.	0400 0800
300 1200		25	START SKIMMING M.B. 23 AT 1830 HRS.	1600 2000
00 2400		25	CHANGED BURNERS M.B. 24	2000 2400
00 2400	TUE.	26	BLOW SOOT M.B. 23 & 24 @	0000 0400
00 0400		26	STOPPED SKIMMING M.B. 23 08:30 HRS.	0000 0400
00 0400		26	CHANGED BURNERS M.B. 23	2000 2400
00 2400	WED.	27	BLOW SOOT M.B. 23 & 24 @	0000 0400
00 0400		27	START FIRING M.B. 22 AT 13:10 HRS.	0800 1200
00 2400		27	ON LINE M.B. 22 AT 1800 HRS.	1600 2000
00 0400		27	CHANGED BURNERS M.B. 24	2000 2400
00 1600	THU.	28	BLOW SOOT M.B. 22, 23, & 24 @	0000 0400
00 2000	FRI.	29	BLOW SOOT M.B. 22, 23, & 24 @	0000 0400
500 2400		29	OFF LINE M.B. 23 AT 1015 HRS. BOTTOM	0800 1200
00 0400		29	BLOW DOWN M.B. 23 FOR 20 MINS.	0800 1200
00 0800		29	START FIRING M.B. 23 AT 2005 HRS	2000 2400
00 2400		29	CHANGED BURNERS M.B. 24	2000 2400
00 0400		29	ON LINE M.B. 23 AT 23:45 HRS	2000 2400
300 1200	SAT.	30	OFF LINE M.B. 22 2400 HRS.	0000 0400

DAY	DATE		TIME		DAY	DATE
SAT.	30	BOTTOM BLOW DOWN M.B. 22 (75 MINS)	0000	0400	MON.	01
	30	BLOW SCOT. M.B. 23 & 24 @	0000	0400		01
	30	CHANGING OF WATCH	1200	1600	TUE	10
	30	CHANGED BURNERS M.B. 23	2000	2400		10
OCTOBER 2000						
SUN.	01	BLOW SCOT M.B. 23 & 24	0000	0400		10
	01	CHANGED BURNERS M.B. 24	2000	2400	WED.	11
MON.	02	BLOW SCOT. M.B. 23 & 24	0000	0400		11
	02	CHANGED BURNERS M.B. 23	2000	2400		11
TUE	03	BLOW SCOT M.B. 23 & 24	0000	0400		11
	03	CHANGED BURNERS M.B. 24	2000	2400	THU.	12
WED	04	BLOW SCOT M.B. 23 & 24	0000	0400		12
	04	START SLOW FIRING M.B. 22 AT 0935 HRS.	0800	1200		12
	04	ON LINE M.B. 22 1800 HRS.	1600	2000		12
	04	CHANGED BURNERS M.B. 23	2000	2400	FRI.	13
THU.	05	BLOW SCOT. M.B. 22, 23 & 24	0000	0400		13
	05	START SKIMMING M.B. 24 AT 0940 HRS. (6 HRS)	0800	1200		13
	05	STOPPED SKIMMING M.B. 24 AT 1540	1200	1600		13
	05	CHANGED BURNERS M.B. 22	2000	2400		13
FRI	06	BLOW SCOT M.B. 22, 23 & 24	0000	0400		13
	06	START SKIMMING M.B. 23 AT 0910 HRS. (6 HRS)	0800	1200	SAT.	14
	06	ON LINE M.B. 23 1225 HRS	1200	1600		14
	06	BLOW SCOT BLOW DOWN 15 MINS	1200	1600	SUN.	15
	06	STOPPED SKIMMING M.B. 23 AT 1510	1200	1600	SUN	15
	06	CHANGED BURNERS M.B. 23	2000	2400	MON.	16
SAT	07	BLOW SCOT M.B. 22 & 23	0000	0400		16
	07	CHANGED BURNERS M.B. 22	2000	2400		16
SUN	08	BLOW SCOT. M.B. 22 & 23	0000	0400		16
	08	START SKIMMING M.B. 23 AT 1000 HRS. (6 HRS)	0800	1200	TUE	17
	08	STOPPED SKIMMING M.B. 23 AT 1600 HRS.	1200	1600		17
	08	CHANGED BURNERS M.B. 23	2000	2400	WED	18
MON	09	BLOW SCOT M.B. 22 & 23	0000	0400		18
	09	START SKIMMING M.B. 23 AT 0915 HRS. (6 HRS)	0800	1200		18

TIME	DAY	DATE	TIME
0000 0400	MON.	09	STOPPED SKIMMING M.B. 23 AT 0515 HRS.
0000 0400		09	CHANGED BURNERS M.B. 22
1200 1600	TUE	10	BLOW 300T M.B. 22 & 23
2000 2400		10	OFF LINE M.B. 22 AT 0915 HRS.
		10	START FIRING M.B. 22 AT 1555 HRS.
		10	ON LINE M.B. 22 18:25 HRS.
0000 0400		10	CHANGED BURNERS M.B. 23
2000 2400	WED.	11	BLOW 300T M.B. 22 & 23
0000 0400		11	START SLOW FIRING M.B. 24 AT 0945 HRS.
2000 2400		11	ON LINE M.B. 24 17:55 HRS.
0000 0400		11	CHANGED BURNERS M.B. 22
2000 2400	THU.	12	BLOW 300T M.B. 22, 23, & 24
0000 0400		12	START SKIMMING M.B. 23 AT 1015 HRS. (8 HRS)
0800 1200		12	STOPPED SKIMMING M.B. 23 18:15 HRS.
1600 2000		12	CHANGED BURNERS M.B. 23
2000 2400	FRI.	13	BLOW 300T M.B. 22, 23, & 24
0000 0400		13	START SKIMMING M.B. 23 AT 0920 HRS. (8 HRS)
0800 1200		13	OFF LINE M.B. 24 AT 1040 HRS.
1200 1600		13	STOP & START SKIMMING AFTER 15 MINS. BOTTOM BLOW DOWN M.B. 24
2000 2400		13	STOPPED SKIMMING M.B. 23 17:20 HRS.
0000 0400		13	CHANGED BURNERS M.B. 22
0800 1200	SAT.	14	BLOW 300T M.B. 22 & 23
1200 1600		14	CHANGED BURNERS M.B. 23
1200 1600	SUN.	15	BLOW 300T M.B. 22 & 23
1200 1600	SUN.	15	CHANGED BURNERS M.B. 22
2000 2400	MON.	16	BLOW 300T M.B. 22 & 23
0000 0400		16	START SKIMMING M.B. 23 AT 0930 HRS. 8 HRS
2000 2400		16	STOPPED SKIMMING M.B. 23. 17:30 HRS. @
0000 0400		16	CHANGED BURNERS M.B. 23
0800 1200	TUE	17	BLOW 300T M.B. 22 & 23
1200 1600		17	CHANGED BURNERS M.B. 22
2000 2400	WED	18	BLOW 300T M.B. 22 & 23
0000 0400		18	START SLOW FIRING M.B. 24 AT 0910 HRS.
0800 1200		18	ON LINE M.B. 24 17:50 HRS.

DAY	DATE		TIME	DAY	DATE
WED.	18	CHANGED BURNER'S M.B. 23	2000 2400	FRI.	27
THU.	19	BLOW 200T M.B. 22, 23, & 24	0000 0400		27
	19	CHANGED BURNER'S M.B. 24	2000 2400		27
FRI.	20	BLOW 200T M.B. 22, 23, & 24	0000 0400	SAT	28
	20	START SKIMMING M.B. 23 06:00 HRS. (6 HRS.)	0400 0800	CHANGE WATCH	28
	20	OFF LINE M.B. 22 AT 1035 HRS.	0800 1200	***	28
	20	STOP & START SKIMMING AFTER 15 MINS. BOTTOM BLOW DOWN M.B. 22.	0800 1200	SUN.	29
	20	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 1200 HRS. 6-HRS.	0800 1200		29
	20	STOPPED SKIMMING M.B. 24 AT 1600 HRS. CHANGED OVER BLR. 23 (6 HRS.)	1600 2000		29
	20	CHANGED BURNER'S M.B. 23	2000 2400		29
	20	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 2400 HRS. (6-HRS)	2000 2400		29
SAT	21	BLOW 200T M.B. 23 & 24	0000 0400		29
	21	STOPPED SKIMMING M.B. 24 AT 0400 HRS.	0400 0800	MON.	30
	21	CHANGED BURNER'S M.B. 24	2000 2400		30
SUN	22	BLOW 200T M.B. 23 & 24	0000 0400		30
	22	CHANGED BURNER'S M.B. 23	2000 2400		30
MON.	23	BLOW 200T M.B. 23 & 24	0000 0400		30
	23	TANK FIRING M.B. 21	0000 0400		30
	23	START SKIMMING M.B. 23 AT 1800 HRS (6 hrs)	1600 2000	TUES.	31
	23	CHANGED BURNER'S M.B. 24	2000 2400		31
	23	STOPPED SKIMMING M.B. 24 AT 2400 HRS.	2000 2400		31
TUE	24	BLOW 200T M.B. 23 & 24	0000 0400		
	24	START SKIMMING M.B. 24 AT 0600 HRS (6 HRS)	0400 0800		
	24	STOPPED SKIMMING M.B. 24 AT 1000 HRS. & START DRAINING M.B. 21. ORDER BY 2ND ENGR.	0800 1200	WED.	01
	24	START AGAIN SKIMMING M.B. 24 AT 1100 HRS.	0800 1200		01
	24	STOPPED AGAIN SKIMMING M.B. 24 & DRAIN OPEN ON M.B. 21 & STOP DRAINING, START SKIMMING M.B. 23	0800 1200		01
	24	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 1800 (6 HRS)	1600 2000		01
	24	CHANGED BURNER'S M.B. 23	2000 2400		01
	24	STOPPED SKIMMING M.B. 24 AT 2400 HRS.	2000 2400	THURS	02
WED	25	BLOW 200T M.B. 23 & 24	0000 0400	J.A. E. BOY	02
	25	CHANGED BURNER'S M.B. 24	2000 2400		02
THU	26	BLOW 200T M.B. 23 & 24	0000 0400		02
	26	CHANGED BURNER'S M.B. 23	2000 2400		02
FRI	27	BLOW 200T M.B. 23 & 24	0000 0400	Jake Di Carpio "Bo-Dex"	02

OCTOBER

TIME	DAY	DATE	DESCRIPTION	TIME	TIME
2000-2400	FRI.	27	START SKIMMING M.B. 23 AT 10:00 HRS. (6-HRS)	0800	1200
0000-0400		27	STOPPED SKIMMING M.B. 23 (1600 HRS)	1200	1600
2000-2400		27	CHANGED BURNERS M.B. 24	2000	2400
0000-0400	SAT	28	BLOW SOOT M.B. # 23 & 24 *	0000	0400
0400-0800		28	CHANGED BURNERS M.B. 23	2000	2400
0800-1200		28	START SKIMMING M.B. 23 AT 2100 HRS (6 HRS)	2000	2400
0800-1200	SUN.	29	BLOW SOOT M.B. 23 & 24	0000	0400
0800-1200		29	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 24 AT 0300 HRS. (6-HRS)	0000	0400
1600-2000		29	STOPPED SKIMMING M.B. 24 AT 0900 HRS	0800	1200
2000-2400		29	START SKIMMING M.B. 23 AT 1100 HRS (6 HRS)	0800	1200
2000-2400		29	STOP SKIMMING M.B. #24 AT 1700 HRS.	1600	2000
2000-2400		29	CHANGED BURNERS M.B. 24	2000	2400
0400-0800	MON.	30	BLOW SOOT M.B. 23 & 24	0000	0400
2000-2400		30	START SKIMMING M.B. 23 AT 0830H (6 H)	0800	1200
0000-0400		30	STOPPED SKIMMING M.B. 23 AT 1430 HRS.	1200	1600
2000-2400		30	START SKIMMING M.B. 24 AT 1430 HRS. (6-HRS)	1200	1600
0000-0400		30	STOPPED SKIMMING M.B. 24 AT 2030 HRS	2000	2400
0000-0400		30	CHANGED BURNERS M.B. 23	2000	2400
1600-2000	TUES.	31	BLOW SOOT M.B. 23 & 24	0000	0400
2000-2400		31	CHANGED BURNERS M.B. 24	2000	2400
2000-2400		31	START SKIMMING M.B. 23 AT 2200 HRS (5 H)	2000	2400

NOVEMBER 2000

0400-0800					
0800-1200	WED.	01	BLOW SOOT M.B. 23 & 24	0000	0400
0800-1200		01	START FIRING M.B. #21 AT 0440 HRS	0400	0800
0800-1200		01	STOP SKIMMING M.B. #23 AT 0600 HRS	0400	0800
1600-2000		01	ON LINE M.B. #21 AT 1240 HRS.	1600	2000
2000-2400		01	CHANGED BURNERS M.B. 23	2000	2400
2000-2400	THURS	02	BLOW SOOT M.B. 21, 23 & 24	0000	0400
0000-0400		02	START SKIMMING M.B. 23 AT 1420 HRS (6-HRS)	1200	1600
2000-2400		02	STOPPED SKIMMING M.B. 23 AT 2020 & CHANGED OVER TO M.B. 24 (6 HRS)	2000	2400
0000-0400		02	CHANGED BURNERS M.B. 24	2000	2400
2000-2400		02	STOPPED SKIMMING M.B. 24 AT 2130 HRS	2000	2400
0000-0400					

Jake DiCarpio
"Bo-Dex"

NOVEMBER 2000

DAY	DATE		TIME	DAY	DATE
FRI.	03	BLOW SOOT M.B. 21, 23 & 24	0000 0400	FRI.	10
*	03	CLOCK RETARDED (1-HR) AT 2:00 HRS.	0000 0400		10
	03	OFF LINE M.B. 23 AT 11:15 HRS	0800 1200		10
	03	BOTTOM BLOW DOWN M.B. 23 (15 MINS)	0800 1200	SAT.	11
	03	START FIRING M.B. # 22 AT 1615 HRS	1600 2000		11
	03	ON LINE M.B. # 23 AT 1815 HRS.	1600 2000	SUN.	12
	03	OFF LINE M.B. # 21 AT 1830 HRS.	1600 2000	*	12
	03	BOTTOM BLOW DOWN 10 min	1600 2000		12
SAT.	04	BLOW SOOT M.B. 23 & 24	0000 0400		12
	04	CHANGED BURNERS M.B. 24	2000 2400		12
	04	START SKIMMING M.B. 24 AT 22 ¹⁰ H (6H)	2000 2400		12
SUN.	05	BLOW SOOT M.B. 23 & 24	0000 0400	MON.	13
*	05	CLOCK ADVANCE (1-HR) AT 02:00 HRS.	0000 0400		13
	05	STOP SKIMMING M.B. # 24 AT 0510 HRS	0400 0800		13
	05	START SKIMMING M.B. # 23 AT 0510 HRS	0400 0800	TUES.	14
	05	STOPPED SKIMMING M.B. 23 AT 1110 HRS	0800 1200		14
	05	START SKIMMING M.B. 23 AT 2030 HRS (6H)	2000 2400	WED.	15
MON.	06	BLOW SOOT M.B. 23 & 24	0000 0400		15
	06	STOPPED SKIMMING M.B. 23 AT 0230 HRS.	0000 0400		15
	06	CHANGED BURNER M.B. 24	2000 2400		15
TUES.	07	BLOW SOOT M.B. 23 & 24	0000 0400	THURS.	16
	07	CHANGED BURNERS M.B. 23	2000 2400		16
WED.	08	BLOW SOOT M.B. 23 & 24	0000 0400	FRI.	17
	08	START SLOW FIRING M.B. 21 AT 0900 HRS.	0800 1200	*	17
	08	ON LINE M.B. # 21 AT 1245 HRS.	1600 2000		17
	08	CHANGED BURNERS M.B. 24	2000 2400		17
THURS.	09	BLOW SOOT M.B. 21, 23 & 24	0000 0400		17
	09	CHANGED BURNERS M.B. 21	2000 2400	SAT.	18
FRI.	10	BLOW SOOT M.B. 21, 23 & 24	0000 0400		18
*	10	CLOCK RETARDED (1-HR) AT 02:00 HRS.	0000 0400	SUN.	19
	10	OFF LINE M.B. 24 AT 0920 HRS	0800 1200	*	19
	10	BOTTOM BLOW DOWN (15 MINS.)	0800 1200		19
	10	START FIRING M.B. 24 AT 1645 HRS.	1600 2000		19
					19

November

141

TIME	DAY	DATE	DESCRIPTION	TIME
0000 0400	FRI.	10	ON LINE M.B. # 24 AT 1250 HRS.	1600 2000
0000 0400		10	OFF LINE M.B. # 22 AT 1910 HRS.	1600 2000
0800 1200		10	BOTTOM BLOW DOWN FOR 10 MINS.	1600 2000
0800 1200	SAT.	11	BLOW SOOT M.B. 21 & 24	0000 0400
1600 2000		11	CHANGED BURNERS M.B. 21	2000 2400
1600 2000	SUN.	12	BLOW SOOT M.B. 21 & 24	0000 0400
1600 2000	*	12	CLOCK ADVANCE (1-HR) AT 0200 HRS.	0000 0400
1600 2000		12	START SKIMMING M.B. 24 AT 1330 HRS. (6 HRS)	1200 1600
0000 0400		12	STOP SKIMMING M.B. # 24 AT 1930 HRS.	1600 2000
2000 2400		12	START SKIMMING M.B. # 21 AT 1930 HRS.	1600 2000
2000 2400		12	CHANGED BURNERS M.B. 24	2000 2400
0000 0400	MON.	13	BLOW SOOT M.B. 21 & 24	0000 0400
0000 0400		13	STOPPED SKIMMING M.B. 21 AT 0130 HRS.	0000 0400
0400 0800		13	CHANGED BURNERS M.B. 21	2000 2400
0400 0800	TUES.	14	BLOW SOOT M.B. 21 & 24	0000 0400
0800 1200		14	CHANGED BURNERS M.B. 24	2000 2400
2000 2400	WED.	15	BLOW SOOT M.B. 21 & 24	0000 0400
0000 0400		15	START SLOW FIRING M.B. 23 AT 0915 H	0800 1200
0000 0400		15	ON LINE M.B. # 23 AT 1745 HRS.	1600 2000
2000 2400		15	CHANGED BURNERS M.B. 21	2000 2400
0000 0400	THURS.	16	BLOW SOOT M.B. 21, 23 & 24	0000 0400
2000 2400		16	CHANGED BURNERS M.B. 24	2000 2400
0000 0400	FRI.	17	BLOW SOOT M.B. 21, 23 & 24	0000 0400
0800 1200	*	17	CLOCK RETARDED (1-HR) AT 02:00 HRS.	0000 0400
1600 2000		17	OFF LINE M.B. 23 AT 0800 HRS.	0800 1200
2000 2400		17	BOTTOM BLOW DOWN (15 MINS.)	0800 1200
0000 0400		17	CHANGED BURNERS M.B. 21	2000 2400
2000 2400	SAT.	18	BLOW SOOT M.B. 21 & 24	0000 0400
0000 0400		18	CHANGED BURNERS M.B. 24	2000 2400
0000 0400	SUN.	19	BLOW SOOT M.B. 21 & 24	0000 0400
0800 1200	*	19	CLOCK ADVANCE (1-HR) AT 0200 HRS.	0000 0400
0800 1200		19	START SKIMMING M.B. # 21 AT 1600 HRS.	1600 2000
1600 2000		19	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 24 AT 2030 (4 HRS)	2000 2400
		19	CHANGED BURNERS M.B. 21	2000 2400

DAY DATE

NOVEMBER

TIME

DAY DA

DAY	DATE	DESCRIPTION	TIME	DAY	DA
MON.	20	BLOW SOOT M.B. 21 & 24	0000 0400	MON	27
	20	STOPPED SKIMMING M.B. 24 AT 0000 HRS.	0000 0400		27
	20	CHANGED BURNERS M.B. 24	2000 2400	TUE.	28
TUES.	21	BLOW SOOT M.B. 21 & 24	0000 0400		28
	21	CHANGED BURNERS M.B. 21	2000 2400		28
WED	22	BLOW SOOT M.B. 21 & 24	0000 0400	WED.	29
	22	START SLOW FIRING M.B. 22 AT 0920 H	0800 1200		29
	22	ON LINE M.B. # 22 AT 1740 HRS.	1600 2000		29
	22	CHANGED BURNERS M.B. 24	2000 2400		29
THURS.	23	BLOW SOOT M.B. 21, 22 & 24	0000 0400		29
	23	START SKIMMING M.B. 22 AT 0945 HRS (5H)	0800 1200		29
	23	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 1445 HRS. (5 HRS.)	1200 1600		29
	23	STOP SKIMMING M.B. # 21 AT 1045 HRS.	1600 2000	THU.	30
	23	CHANGED BURNERS M.B. 21	2000 2400		30
FRI.	24	BLOW SOOT M.B. 21, 22 & 24	0000 0400		30
*	24	CLOCK RETARDED (1-HR) AT 0200 HRS.	0000 0400		30
	24	START SKIMMING M.B. 21 AT 0520H	0400 0800		30
	24	OFF LINE M.B. 24 AT 0930 HRS	0800 1200		30
	24	BOTTOM BLOW DOWN M.B. 24 (20 MINS)	0800 1200		30
	24	STOPPED SKIMMING M.B. 21 AT 0930 HRS	0800 1200		30
	24	START SKIMMING M.B. 22 AT 1020 HRS (5)	0800 1200	FRI.	01
	24	STOPPED SKIMMING M.B. 22 AT 1500 HRS.	1200 1600	*	01
	24	CHANGED BURNERS M.B. 22	0800 1200		01
SAT.	25	BLOW SOOT M.B. 21 & 22	0000 0400		01
*	25	CHANGING OF WATCH * * *	1200 1600		01
	25	CHANGE THE BURNERS OF M.B. # 21	2000 2400	SAT.	02
SUN.	26	BLOW SOOT M.B. 21 & 22	0000 0400		02
	26	START SKIMMING M.B. 22 AT 1330 HRS (5 Hrs)	1200 1600	SUN.	03
*	26	CLOCK ADVANCE (1-HR) AT 0200 HRS.	0000 0400	*	03
	26	STOPPED SKIMMING M.B. 22 AT 1830 HRS.	1600 2000		03
	26	CHANGE THE BURNERS OF M.B. # 22	2000 2400	MON.	04
MON.	27	BLOW SOOT M.B. 21 & 22	0000 0400		04
	27	START SKIMMING M.B. 21 AT 1300 HRS (5 Hrs)	1200 1600	TUE.	05
	27	CHANGE SKIMMING FR. M.B. 21 TO M.B. 22 AT 1800 HRS. (5-HRS.)	1600 2000		05

NOVEMBER

TIME	DAY	DATE	DESCRIPTION	START	END
0000 0400	MON	27	CHANGE THE BURNERS OF M.B. #21	2000	2400
0000 0400		27	STOP SKIMMING M.B. #22 AT 2300 HRS.	2000	2400
2000 2400	TUE.	28	BLOW SOOT M.B. 21 & 22	0000	0400
0000 0400		28	START SLOW FIRING M.B. #23 AT 0845 HRS.	0800	1200
2000 2400		28	CHANGE THE BURNERS OF M.B. #22	2000	2400
0000 0400	WED.	29	BLOW SOOT M.B. 21 & 22	0000	0400
0800 1200		29	START FIRING M.B. 23 AT 1142 HRS.	0800	1200
1600 2000		29	ON LINE M.B. 23 AT 1745 HRS.	1600	2000
2000 2400		29	START SKIMMING M.B. 21 AT 1930 HRS. (4 HRS)	1600	2000
0000 0400		29	CHANGE THE BURNERS OF M.B. #21	2000	2400
0800 1200		29	STOP SKIMMING M.B. #21 AT 2330 HRS.	2000	2400
1200 1600		29	START SKIMMING M.B. #22 AT 2336 HRS.	2000	2400
1600 2000	THU.	30	BLOW SOOT M.B. 21, 22 & 23	0000	0400
2000 2400		30	STOP SKIMMING M.B. 22 AT 0330	0000	0400
0000 0400		30	START SKIMMING M.B. 23 AT 0330 (4 HRS)	0000	0400
0000 0400		30	STOPPED SKIMMING M.B. 23 AT 0730 HRS.	0400	0800
0400 0800		30	CHANGE THE BURNERS OF M.B. #22	2000	2400

DECEMBER

0800 1200	FRI.	01	BLOW SOOT M.B. 21, 22 & 23	0000	0400
1200 1600	*	01	CLOCK RETARDED 1 HOUR AT 0200 HRS	0000	0400
0800 1200		01	STOP M.B. #23 AT 0930 HRS.	0800	1200
0000 0400		01	BOTTOM BLOW DOWN FOR 15 MIN.	0800	1200
1200 1600		01	CHANGE THE BURNERS OF M.B. #21	2000	2400
2000 2400	SAT.	02	BLOW SOOT M.B. 21 & 22	0000	0400
0000 0400		02	CHANGE THE BURNERS OF M.B. #22	2000	2400
1200 1600	SUN.	03	BLOW SOOT M.B. 21 & 22	0000	0400
0000 0400	*	03	CLOCK ADVANCE (1-HR.) AT 0200 HRS.	0000	0400
1600 2000		03	CHANGE THE BURNERS OF M.B. #21	2000	2400
2000 2400	MON.	04	BLOW SOOT M.B. 21 & 22	0000	0400
0000 0400		04	CHANGE THE BURNERS OF M.B. #22	2000	2400
1200 1600	TUE.	05	BLOW SOOT M.B. 21 & 22	0000	0400
1600 2000		05	CHANGE THE BURNERS OF M.B. #21	2000	2400

December



DAY	DATE		TIME	DAY	DATE
WED.	06	BLOW SOOT M.B. 21 & 22	0000 040	MON.	1
	06	START SLOW FIRING M.B. #23 AT 0800 HRS	0800 1200		11
	06	ON LINE M.B. 23 AT 1735 HRS.	1600 2000		11
	06	CHANGE THE BURNERS OF M.B.# 22	2000 2400		11
	06	START SKIMMING M.B.#21 AT 2300 HRS.	2400 2400		11
THU.	07	BLOW SOOT M.B. 21 & 22 & 23	0000 040	TUE.	12
	07	STOPPED SKIMMING M.B. 21 AT 0400	0000 040		12
	07	START SKIMMING M.B. 22 AT 0400 (5 HRS)	0000 040		12
	07	STOP SKIMMING M.B.#22 AT 0900 HRS.	0800 1200	WED.	13
	07	CHANGE THE BURNERS OF M.B.# 21	2000 2400		13
FRI.	08	BLOW SOOT M.B. 21, 22 & 23	0000 040		13
	08	CLOCK RETARDED (1-HR) AT 0200 HRS.	0000 040		13
	08	OFF LINE M.B.# 23 AT 0045 HRS	0800 1200	THU.	14
	08	BOTTOM BLOW DOWN FOR 15 MIN.	0800 1200		14
	08	CHANGE THE BURNERS OF M.B.# 22	2000 2400		14
SAT.	09	BLOW SOOT M.B. 21 & 22	0000 040		14
	09	START SKIMMING M.B. 21 AT 1800 HRS. (4 HRS)	1600 2000		14
	09	CHANGE THE BURNERS OF M.B.# 21	2000 2400		14
	09	STOP SKIMMING M.B.# 21 AT 2200 HRS.	2000 2400	FRI.	15
	09	START SKIMMING M.B.# 22 AT 2200 HRS.	2000 2400	*	15
SUN.	10	BLOW SOOT M.B. 21 & 22	0000 040		15
	10	CLOCK ADVANCE 1 HOUR AT 0200 H.	0000 040		15
	10	STOP SKIMMING M.B. 22 AT 0200 HRS	0000 040		15
	10	START SKIMMING M.B. 21 AT 0200 HRS (4H)	0000 040		15
	10	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 0600 HRS. (4 HRS.)	0400 0800	SAT.	16
	10	STOP SKIMMING M.B.#22 AT 1000 HRS.	0800 1200		16
	10	START SKIMMING M.B.#21 AT 1000 HRS.	0800 1200	SUN.	17
	10	STOP SKIMMING M.B. 21 AND CHANGED TO M.B. 22 AT 1400 HRS.	1200 1600	*	17
	10	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 1800 HRS. (4 HRS.)	1600 2000		17
	10	STOP SKIMMING M.B.# 21 AT 2200 HRS.	2000 2400		17
	10	START SKIMMING M.B.# 22 AT 2200 HRS.	2000 2400		17
	10	CHANGE THE BURNERS OF M.B.# 22	2000 2400		17



December

147
TIME

DAY	DATE		TIME
MON.	11	BLOW SOOT M.B. 21 & 22	0000 0400
	11	STOPPED SKIMMING M.B. 22 AT 0200 HRS	0000 0400
	11	START SKIMMING M.B. 21 AT 0200 HRS (4 HRS)	0000 0400
	11	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 0600 HRS. (4 HRS)	0400 0800
	11	CHANGE THE BURNERS OF M.B. #21	2000 2400
TUE.	12	BLOW SOOT M.B. 21 & 22	0000 0400
	12	STOPPED SKIMMING M.B. 22 AT 0410 HRS.	0400 0800
	12	CHANGE THE BURNERS OF M.B. #22	2000 2400
WED.	13	BLOW SOOT M.B. 21 & 22	0000 0400
	13	START FIRING M.B. #23 AT 0900 HRS	0800 1200
	13	ON LINE M.B. 23 AT 1750 HRS.	1600 2000
	13	CHANGE THE BURNERS OF M.B. #21	2000 2400
THU.	14	BLOW SOOT M.B. 21, 22 & 23	0000 0400
	14	START SKIMMING M.B. 21 AT 0700 HRS. (2 HRS)	0400 0800
	14	STOP SKIMMING M.B. #21 AT 0900 HRS	0800 1200
	14	START SKIMMING M.B. #23 AT 0900 HRS.	0800 1200
	14	STOP SKIMMING M.B. #23 AT 1100 HRS.	0800 1200
	14	CHANGE THE BURNERS OF M.B. #22	2000 2400
FRI.	15	BLOW SOOT M.B. 21, 22 & 23	0000 0400
	15	CLOCK RETARDED (1 HR) AT 0200 HRS.	
	15	START SKIMMING M.B. 23 AT 0535 HRS.	0400 0800
	15	STOP SKIMMING M.B. #23 AT 0835 HRS.	0800 1200
	15	OFF LINE M.B. #21 AT 1010 HRS.	0800 1200
	15	BOTTOM BLOW DOWN 15 MINS.	0800 1200
	15	CHANGE THE BURNERS OF M.B. #23	2000 2400
SAT.	16	BLOW SOOT M.B. 22 & 23	0000 0400
	16	CHANGE THE BURNERS OF M.B. #22	2000 2400
SUN.	17	BLOW SOOT M.B. 22 & 23	0000 0400
	17	CLOCK ADVANCE 1 HOUR	0000 0400
	17	START SKIMMING M.B. 22 AT 0730 HRS. (4 HRS)	0400 0800
	17	STOP SKIMMING M.B. #22 AT 1130 HRS	0800 1200
	17	CHANGE THE BURNERS OF M.B. #23	2000 2400
	17	START FIRING M.B. #21 AT 2330 HRS.	2000 2400

DECEMBER

DAY	DATE		TIME	DAY	24
MON	18	BLOW SOOT M.B. 22 & 23	0000 0400	SUN	2
	18	ON LINE M.B. 21 AT 0600 HRS.	0400 0800		2
	18	START SKIMMING M.B. 22 AT 1730 HRS. (15 HRS)	2000 2000		2
	18	CHANGE THE BURNERS OF M.B. #22	2000 2400		2
	18	STOP SKIMMING M.B. #22 AT 2330 HRS.	2000 2400		2
	18	START SKIMMING M.B. #22 AT 2330 HRS.	2000 2400		2
TUE.	19	BLOW SOOT M.B. 21, 22 & 23	0000 0400		2
	19	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 22 AT 0530 HRS. (4 HRS)	0400 0800	MON	2
	19	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 0730 HRS. (4 HRS.)	0400 0800		2
	19	OFF LINE M.B. 21 AT 0730 HRS.	0400 0800		2
	19	STOP & START SKIMMING AFTER BOTTOM BLOW DOWN M.B. 21 (15 MINS.)	0400 0800	X-MAS	2
	19	STOPPED SKIMMING M.B. 23 & CHANGED OVER TO M.B. 22 AT 1130 HRS. (4 HRS.)	0800 1200		2
	19	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 23 AT 1530 HRS. (4 HRS.)	1200 1600		2
	19	CHANGE THE BURNERS OF M.B. #23	2000 2400		2
	19	STOP SKIMMING M.B. #23 AT 2130 HRS.	2000 2400		2
	19	START SKIMMING M.B. #22 AT 2130 HRS.	2000 2400		2
WED.	20	BLOW SOOT M.B. 22 & 23	0000 0400		2
	20	STOPPED SKIMMING M.B. 22 AT 0330 H	0000 0400	PLA	24
	20	START FIRING M.B. #21 AT 0930 HRS.	0800 1200		24
	20	ON LINE M.B. 21 AT 1800 HRS.	1600 2000		24
	20	CHANGE THE BURNERS OF M.B. #22	2000 2400		20
THU.	21	BLOW SOOT M.B. 21, 22 & 23	0000 0400		24
	21	CHANGE THE BURNERS OF M.B. #23	2000 2400		24
FRI.	22	BLOW SOOT M.B. 21, 22 & 23	0000 0400		24
*	22	CLOCK RETARDED (1 HOUR) AT 0200 HRS	0000 0400	WED	27
	22	OFF LINE M.B. #21 AT 1015 HRS.	0000 1200		27
	22	BOTTOM BLOW DOWN 15 MINS.	0800 1200		27
	22	CHANGE THE BURNERS OF M.B. #22	2000 2400		27
SAT.	23	BLOW SOOT M.B. 22 & 23	0000 0400	THU	28
	23	CHANGING OF WATCH	1200 1600		28
	23	CHANGED BURNERS M.B. 23	2000 2400	FRI	29
SUN	24	START FIRING M.B. #21 AT 0040 HRS	0000 0400	*	29
	24	BLOW SOOT M.B. 22 & 23	0000 0400		29
					29

TIME		DAY	DATE	DECEMBER 2000	149*	TIME
000	0400	SUN	24	ON LINE M.B. 21 AT 0730 HRS	0400	0800
100	0800		24	START SKIMMING M.B. 22 AT 0745 HRS (4 HRS)	0400	0800
1600	2000		24	STOPPED SKIMMING M.B. 22 & CHANGED OVER TO M.B. 21 AT 1145 HRS. (6-HRS.)	0800	1200
00	2400		24	STOP SKIMMING M.B. 21 AT 1745 HRS	1600	2000
00	2400		24	START SKIMMING M.B. 23 AT 1745 HRS (4H)	1600	2000
00	2400		24	CHANGED BURNER'S M.B. 22	2000	2400
100	0400		24	CONTINUE SKIMMING M.B. 23 (6-HRS. MORE)	2000	2400
400	0800	MON	25	BLOW SOOT M.B. 21, 22 & 23	0000	0400
100	0800		25	STOP SKIMMING M.B. 23 AT 0545	0400	0800
100	0800		25	START SKIMMING M.B. 22 AT 0545 (4 HRS)	0400	0800
100	0800	X-MAS	25	CONTINUE SKIMMING M.B. 22 (6-HRS. MORE)	0800	1200
800	1200		25	STOP SKIMMING M.B. # 22 AT 1545 HRS.	1200	1600
200	1600		25	START SKIMMING M.B. # 23 AT 1545 HRS.	1200	1600
00	2400		25	STOP SKIMMING M.B. 23 AT 1945 HRS	1600	2000
00	2400		25	START SKIMMING M.B. 21 AT 1945 HRS (4H)	1600	2000
000	2400		25	CHANGED BURNER'S M.B. 23	2000	2400
000	0400		25	STOPPED SKIMMING M.B. 21 & CHANGED OVER TO M.B. 22 AT 2345 HRS. (4 HRS.)	2000	2400
000	0400	TUE	26	BLOW SOOT M.B. 21, 22 & 23	0000	0400
100	1200		26	STOP SKIMMING M.B. # 22 AT 0345 HRS.	0000	0400
100	2000		26	START SKIMMING M.B. # 23 AT 0345 HRS.	0000	0400
100	2400		26	STOP SKIMMING M.B. 23 AT 0700 HRS	0400	0800
000	0400		26	OFF LINE M.B. 21 AT 0715 HRS	0400	0800
100	2400		26	BOTTOM BLOW DOWN 15 MINS.	0400	0800
100	0400		26	CHANGED BURNER'S M.B. 22	2000	2400
100	0400	WED	27	BLOW SOOT M.B. # 22 & 23	0000	0400
180	1200		27-	START SLOW FIRING M.B. 21 AT 0855 HRS.	0800	1200
300	1200		27	ON LINE M.B. 21 AT 1800 HRS	1600	2000
00	2400		27	CHANGED BURNER'S M.B. 23	2000	2400
100	0400	THU	28	BLOW SOOT M.B. # 21 , 22 & 23	0000	0400
200	1600		28	CHANGED BURNER'S M.B. 22	2000	2400
000	2400	FRI	29	BLOW SOOT M.B. 21, 22 & 23	0000	0400
100	0400	*	29	TIME BACKWARD 1 HR AT 0200 HRS.	0000	0400
100	0400		29	OFF LINE M.B. 23 AT 0910 HRS. BOTTOM BLOW DOWN M.B. 23 (15 MINS.)	0800	1200
			29	CHANGED BURNER'S M.B. 21	2000	2400