

Inadvertent ABS Activation While Airborne	
Brake Pedal vibration will be felt when ABS is active.	
1. ABS Switch.....	Press
2. ABS INOP Lamp	Confirm ON
3. Brakes	Check Brake Pressure
NOTE Reapplication (pumping of brakes) may be required to restore brake pressure.	
4. ABS Switch.....	Press
5. ABS ARMED Lamp	Confirm ON

Brakes Ineffective or Pulling to One Side	
When braking with ABS becomes ineffective or causes the aircraft to pull to one side.	
1. <u>Maintain directional control using rudder and steering.</u>	
2. <u>Brakes</u>	<u>Release</u>
3. <u>ALL INTERRUPT</u>	<u>PRESS and HOLD</u>
4. <u>Reapply Brake (Pump Brakes as required).....</u>	<u>Stop Normally</u>
NOTE ABS Functionality Unavailable.	