

172 Parts Catalog

Landing Gear




Figure 37. Nose Gear Installation