

07 Aug 17:39:08 UTC | [LOGIN \(/LOGIN.ASPX\)](/LOGIN.ASPX) | [REGISTER \(/MEMBERS/PERSON/REGISTER.HTM\)](/MEMBERS/PERSON/REGISTER.HTM)

CROSSWIND CALCULATOR

Runway number	21
Wind direction	220
Wind strength (kt)	14
Gust (if any)	
Crosswind component	2 kt

◆ 1998-2014 - IVAO (<mailto:hq@ivao.aero>) - All Rights Reserved

07 Aug 17:35:54 UTC | [LOGIN \(/LOGIN.ASPX\)](/LOGIN.ASPX) | [REGISTER \(/MEMBERS/PERSON/REGISTER.HTM\)](/MEMBERS/PERSON/REGISTER.HTM)

CROSSWIND CALCULATOR

Runway number	21
Wind direction	220
Wind strength (kt)	32
Gust (if any)	
Crosswind component	6 kt

[Calculate!](#)

◆ 1998-2014 - IVAO (<mailto:hq@ivao.aero>) - All Rights Reserved