

## density altitude calculator

To use the calculator, just click the type of units that you will be entering, then enter the altitude, temperature, altimeter setting and dew point. Then click the calculate button.

Elevation	<b>feet</b>	<b>meters</b> 7664
Air Temperature	<b>deg F</b>	<b>deg C</b> 22
Altimeter Setting	<b>inches Hg</b>	<b>mb</b> 30.04
Dew Point	<b>deg F</b>	<b>deg C</b> -11

Calculate    Reset

Density Altitude	10081	<b>feet</b>	3073	<b>meters</b>
Absolute Pressure	22.609	<b>inches Hg</b>	765.62	<b>mb</b>
Relative Density	73.67	<b>%</b>	73.67	<b>%</b>