EMERGENCY EGRESS PROCEDURE FOR WINDOWS ON 92d ICC's

- -MP-47 page will reflect <u>each window</u> by location for <u>each car</u>.
- -When performing the Egress Test on a window, the window is to be fully removed and then re-applied.
- -Inspectors are to inspect and renew rubbers <u>if</u> and when necessary. (It is <u>NOT</u> a wholesale change out).
- -If defects or repairs are required during the Egress Test, they <u>must</u> be documented in the MP47's.

LUBRICANT SILICONE SPRAY 16 OUNCES PER CAN 12 CANS

Account Reference Number: 37395505