


JT8D



- | | | | |
|-----|--------------------------------|-----|---|
| A-B | FAN INLET CASE | F-G | COMPRESSOR INTERMEDIATE CASE |
| B-C | FAN FRONT CASE | G-H | FAN DISCHARGE REAR OUTER DUCT |
| C-D | FAN REAR CASE | H-J | FAN DISCHARGE DIFFUSER OUTER DUCT |
| D-E | FAN EXIT CASE | J-K | FAN DISCHARGE COMBUSTION/TURBINE OUTER DUCT |
| E-F | FAN DISCHARGE FRONT OUTER DUCT | K-M | FAN DISCHARGE EXHAUST OUTER DUCT |

CASES, FLANGES AND DUCTS