



# ROBINSON ILLUSTRATED PARTS CATALOG

MODEL R44

FIGURE AND INDEX NUMBER	PART NUMBER	DESCRIPTION	PARTS AVAIL	USABLE ON CODE	QTY PER ASSY
MAIN ROTOR CONTROLS (MANUAL)					
7-19-1	C337-1	Jackshaft Assembly (Ref)			
2	NAS1149F0532P	Washer . . . . .	X		10
3	MS21042L5	Nut . . . . .	X		8
4	B330-16	Palnut . . . . .	X		9
5	NAS6605-25	Bolt . . . . .	X		1
6	C115-1	Spacer . . . . .	X		13
7	D173-1	Rod End . . . . .	X		13
8	C141-1	Washer . . . . .	X		4
9	NAS6605-26	Bolt . . . . .	X		1
10	B330-19	Palnut . . . . .	X		9
11	AN316-6R	Nut . . . . .	X		9
12	C121-3	Push-Pull Tube Assembly (Incl items 7, 10, 11, and 13) . .	X		1
13	-	Tube (Ref)			
14	A205-5	Fork Assembly (see also Figure 7-25) . . . . .	X		1
15	C320	Cyclic Stick Assembly (Ref)			
16	NAS6605-19	Bolt . . . . .	X		3
17	C121-5	Push-Pull Tube Assembly (Incl items 7, 10, 11, 18, and 43)	X		1
18	-	Tube (Ref)			
19	C198-1	Swashplate - Lower (Ref)			
20	C319-3	Torque Tube (Ref)			
21	NAS6605-16	Bolt . . . . .	X		2
22	NAS6604-16	Bolt . . . . .	X		1
23	NAS1149F0432P	Washer . . . . .	X		4
24	A130-8	Spacer . . . . .	X		1
25	NAS6605-46	Bolt . . . . .	X		1
26	A115-1	Spacer . . . . .	X		2
27	A101-4	Rod End . . . . .	X		2
28	AN316-5R	Nut . . . . .	X		2
29	C121-1	Push-Pull Tube Assembly (Incl items 4, 27, and 28) . . . . .	X		1
30	NAS6605-35	Bolt . . . . .	X		1
31	A143-1	Sleeve . . . . .	X		2
(Cont'd)					

X - Available as separate spares item  
 O - Available only as part of assembly