

MODEL 172 SERIES SERVICE MANUAL

PILOT AND COPILOT SEAT ASSEMBLY BEGINNING WITH 1980 MODELS

1. Seat Handle Pin
2. Spring
3. Seat Adjust Handle
4. Cushion
5. Cover
6. Grommet
7. Head Rest
8. Former Bracket
9. Former Assembly
10. Bracket
11. Clip
12. Pocket
13. Bolt and Spacer
14. Lock Cylinder
15. Frame
16. Bracket
17. Pin
18. Roller
19. Spring
20. Link
21. Clevis Pin
22. Lock Cylinder Control




Figure 3-8. Seat Installation (Sheet 7 of 11)