

DCA10IA001
Minneapolis, Minnesota
October 21, 2009
Northwest Airlines, Inc.
Airbus A-320-212, N374NW

Attachment 2



NWAA A320 Aircraft Operating Manual
A-320 Call system
(1 Page)

Calls System (Continued)


CALL to and from Flight Attendants

When a call is placed from the cockpit to the flight attendants:

- a pair of red lights illuminate at the selected flight attendant overhead area call panel,
- the word "CAPTAIN CALL" illuminates in red on the flight attendant indicating panel, and
- a high/low chime sounds from the cabin speaker for that station area.



FG23057C




DING
DONG
DING
DONG
DING
DONG (4 times)

Receiving a call from the flight attendants:


- sounds a buzzer in the cockpit and
- illuminates an amber flashing "ATT" in the CAB key on all three ACPs.

Caution: The buzzer is inhibited on takeoff below 1,500 ft and on approach below 800 ft (only the "ATT" light flashes).



FG23028C

The pilot can extinguish the flashing ATT light with the RESET pb located on the ACP. A reset automatically occurs after a short time if no action is taken.



FG23029C