

Figure 38. Stabilator Trim Mechanism Installation



	<del></del>	·	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		
Figure and Index Number	Part Number	Code	NOMENCLATURE	No. Req.	SERIAL NUMBERS AFFECTED
38-	20839 22678 24868 20955 21553 23029 21553 23014 24869 25402	Y X Z	DRAWING - Stabilator Trim Mechanism Installation DRAWING - Stabilator Trim Mechanism Installation DRAWING - Stabilator Trim Mechanism Installation DRAWING - Control System Installation		24-1 to 24-102 inclusive 24-103 to 24-2843 inclusive 24-2844 and up 24-2844 and up 24-4247, 24-4300 and up
-1 -2 -3 -4	20838-00 30176-03 452 374 452 385 452 383 20836-00 22887-00 21831-03	Z VXY Z	ARM ASSEMBLY - Stabilator tab actuator ARM ASSEMBLY - Stabilator tab actuator BEARING - Oilite (F-427) BEARING - Oilite (FF-520-15) BEARING - Rod end (24166-00) BELLCRANK ASSEMBLY - Stabilator tab control BELLCRANK ASSEMBLY - Stabilator tab control BEARING - Bellcrank assembly	1 1 2 2 1 1 1 2	·
-5	20834-00 20834-05 20834-05	AXY VXY	STOP - Trim tab screw, upper STOP - Trim tab screw, upper STOP - Trim tab screw, upper	1 1 1	24-1 to 24-3650 inclusive 24-3651 and up
-6 -7 -8	20834-02 20834-03 20834-02 20834-06 20834-07 20834-05 20800-00 20840-03	AXY AY AX X	STOP - Trim tab screw, lower DRUM - Stabilator trim tab control BRACKET ASSEMBLY - Control cable drum	1 1 1 1 1 1	24-1 to 24-2843 inclusive 24-2844 to 24-3650 inclusive 24-2844 to 24-3650 inclusive 24-3651 and up 24-3651 and up
-9 -10	452 376 756 217 756 217 756 218 20802-04 22864-00 80022-96 20485-02 23452-00	AY AY VXY Z XY XY	BEARING - Oilite (F-586)  SCREW AND STOP ASSEMBLY - Stabilator trim tab  SCREW AND STOP ASSEMBLY - Stabilator trim tab  SCREW AND STOP ASSEMBLY - Stabilator trim tab  SCREW - Stabilator trim tab control  SCREW - Stabilator trim tab control  BUSHING  BRACKET ASSEMBLY - Stabilator trim cable pulley  BRACKET ASSEMBLY - Stabilator trim cable pulley, left	2 1 1 1 2 2	24-1 to 24-3650 inclusive 24-105 to 24-2843 inclusive 24-2844 to 24-3650 inclusive 24-3651 and up
-13 -14 -15	23452-01 17089-00 21049-00 14843-47	VZ VXY	BRACKET ASSEMBLY - Stabilator trim cable pulley, right PIN STOP - Bolt BUSHING	1 1 2 2	
			<ul> <li>A - If screw and stop assembly 756 217 or 756 218 which incorporates a clevis pin for the stop attachment has been installed, order part for serial numbers 24-3651 and up.</li> <li>B - Used on PA-24-260 with serial numbers 24-3642, 24-4000 to 24-4246, 24-4248 to 24-4299 inclusive.</li> <li>V - Used on PA-24-260 airplanes only.</li> <li>X - Used on PA-24-180 airplanes only.</li> <li>Y - Used on PA-24-250 airplanes only.</li> <li>Z - Used on PA-24-400 airplanes only.</li> </ul>		

When ordering, always specify Part Number, Description and Serial Number of Aircraft



Figure and Index Number	Part Number	Code	NOMENCLATURE	No. Req.	SERIAL NUMBERS AFFECTED
38-16	20560-00	VXY	CLIP - Stabilator tab control, left	1	
00.10	20560-01	VXY	•	i	
	16722-02	Z	CLIP - Stabilator tab control, left	i	
	16722-03	z	CLIP - Stabilator tab control, right	ī	
- 17	14976-42	VXY	=	1	
	14976-63	Z	BUSHING	1	
<b>-</b> 18	14843-26	VXY		2	
- 19	481 621	С	PULLEY - (AN210-1B)	2	
	20534-00	l v l	PULLEY - Stabilator trim	2	24-4247, 24-4300 and up
-20	20946-00		CABLE ASSEMBLY - Stabilator trim tab control, rear	1	•
-21	21093-00	XY	CABLE ASSEMBLY - Stabilator trim tab control, front	1	
	21093-02	BVZ	CABLE ASSEMBLY - Stabilator trim tab control, front	1	
-22	14300-30	Α	CABLE ASSEMBLY - Stabilator trim tab control	1	
-23	452 019	1 1	BARREL - Turnbuckle (AN155-5S)	2	
-24	17442-03	XY	TEE ASSEMBLY - Stabilator trim indicator	1	
-25	480 682		PIN - Roll (#59-022-094-0750)	l	
	480 707	AVZ	PIN - Roll (#59-022-094-1000)	1	
-26	20623-00	1	PLATE - Rub	4	24-1 to 24-102 inclusive
-27	14843-33	XY	BUSHING	1	
-28	14843-34	VXY	BUSHING	3	
-29	20534-00	VXY	PULLEY	3	
-30	14183-03	XY	ROD - Threaded	1	
-31	86092-66	XY	ROD - Cable guard	2	
-32	80421-00	1 1	PULLEY	1	
-33	800 12-04		WASHER	1	
-34	80122-18		WASHER	2	
-35	20907-00		PULLEY - Stabilator trim crank (Aluminum)	l	
	25048-00	ΑZ	PULLEY - Stabilator trim crank (Plastic)	1	
ł	25048-02		PULLEY - Stabilator trim crank (Plastic)	1	
-36	20908-00		STEM - Stabilator trim crank	1	
-37	464 023		HANDLE ASSEMBLY - Stabilator trim crank	l l	
-38	20905-00		CHANNEL ASSEMBLY - Stabilator trim pulley	1	
-39	151 310		WIRE - Indicator, stainless steel	20'	
-40	481 621	XY	· ·	2	
	20534-00	VZ	PULLEY - Trim cable	2	
-41	24026-00	VZ	INDICATOR - Stabilator trim		
-42	24666-00	Z	PLACARD - Stabilator trim indicator	1	
	24875-00	V	PLACARD - Stabilator trim indicator	1	
-43	24023-02	VZ	BRACKET - Stabilator indicator tube	1	
-44	24024-03	VZ	BRACKET - Stabilator indicator	l	
-45	24025-02	VZ	TUBE - Stabilator indicator	1	
-46	20534-00		PULLEY	2	
			<ul> <li>A - Used when electric trim is installed.</li> <li>B - If electric trim is installed and 6 3/4" splice cable is not installed, order Part No. 14300-30 also.</li> <li>C - Used on PA-24-180, PA-24-250 and PA-24-260 with serial numbers 24-1 to 24-4246 inclusive, 24-4248 to 24-4299 inclusive, PA-24-400 with serial numbers 26-2 and up.</li> <li>V - Used on PA-24-260 airplanes only.</li> <li>X - Used on PA-24-180 airplanes only.</li> <li>Y - Used on PA-24-250 airplanes only.</li> <li>Z - Used on PA-24-400 airplanes only.</li> </ul>		
į			Y - Used on PA-24-250 airplanes only.		

When ordering, always specify Part Number, Description and Serial Number of Aircraft

PA - 24 - 180 PA - 24 - 250 PA - 24 - 260 PA - 24 - 400



Figure and Index Number	Part Number	Code	NOMENCLATURE	No. Req.	SERIAL NUMBERS AFFECTED
38-47	20903-00	XY	BRACKET - Pulley	2	
-48	24813-00	VZ	BRACKET - Pulley	2	
-49	23954-00 400 106	VZ VXY	TUBE - Cable guide BOLT - (AN4-11)	3	
37	402 310	Z	BOLT - (AN174-12)	1	
	407 565	z	WASHER - (AN960-416)	i	
]	404 101		NUT - (AN310-4)	1	
	424 051	ł	PIN - Cotter (AN380-2-2)	1	
-50	401 312	VXY		1	
	402 311 407 565	Z	BOLT - (AN174-12A) WASHER - (AN960-416)	1 1	
	404 888		NUT - (MS20365-428C)	1 1	
-51	401 270	VXY		1	
	402 315	Z	BOLT - (AN174-15)	1	
	407 565	Z	WASHER - (AN960-416)	l	
	404 835 404 101	VXY	NUT - (MS20364-1032C)	1 1	
	404 101 424 05 l	Z Z	NUT - (AN310-4) PIN - Cotter (AN380-2-2)	1 1	
-52	472 028	VZ	BULB - Indicator (#327-28V)	i	24-3642, 24-4000 to 24-4472 incl.,
				J .	26-2 and up
	472 054	V	BULB - Indicator (#330-14V)	1	24-4473 and up
-53 -54	484 308 42891-00	VZ	RECEPTACLE - Indicator bulb (#GB-5952-3LH-C-14) SPRING	1 1	
			V - Used on PA-24-260 airplanes only. X - Used on PA-24-180 airplanes only. Y - Used on PA-24-250 airplanes only. Z - Used on PA-24-400 airplanes only.		