NATIONAL TRANSPORTATION SAFETY BOARD

Office of Aviation Safety
Washington, D.C. 20594

May 31, 2017

Attachment 12 – American Airlines Evacuation Checklist

OPERATIONAL FACTORS/HUMAN PERFORMANCE

DCA17FA021

Evacuation

Condition: Evacuation is needed.

Note: Light override is available.

1 Parking brake. . . . . SET

2 Cabin altitude MODE SELECT . . . . . .MAN

3 CABIN ALTITIUDE MANUAL control. . . . . Hold in CLIMB

Note: Hold in CLIMB until the outflow valve indication shows fully open to depressurize the airplane.

4 FUEL CONTROL switches (both). . . . . CUTOFF

5 PA . . . . . **"This is the Captain. Evacuate. Evacuate. Evacuate."**

6 Evacuation COMMAND Switch (as installed) . . . . . .ON

7 ATC . . . . . .Notify

8 Engine and APU fire switches (all). . . . . .Override and pull

9 **If** an engine or APU fire warning occurs:

Related fire switch. . . . . Rotate to the stop and hold for 1 second

■ ■ ■ ■

Supplemental Information

If time permits, additional information is available in General Information page 2.8.