



**TECHNICAL RECONSTRUCTION ATTACHMENT**

**2013 Lexus EDR Report**

**Phoenix, Arizona**

**HWY21MH008**

(35 pages)

IMPORTANT NOTICE: Robert Bosch LLC and the manufacturers whose vehicles are accessible using the CDR System urge end users to use the latest production release of the Crash Data Retrieval system software when viewing, printing or exporting any retrieved data from within the CDR program. Using the latest version of the CDR software is the best way to ensure that retrieved data has been translated using the most current information provided by the manufacturers of the vehicles supported by this product.

## CDR File Information

User Entered VIN/Frame Number	JTHKD5BH1D21 [REDACTED]
User	S. O'Bryant #5501
Case Number	I21031311
EDR Data Imaging Date	07/07/2021
Crash Date	06/09/2021
Filename	JTHKD5BH1D21 [REDACTED].ACM.CDRX
Saved on	Wednesday, July 7 2021 at 11:50:10
Imaged with CDR version	Crash Data Retrieval Tool 21.1.1
Imaged with Software Licensed to (Company Name)	Arizona DPS
Reported with CDR version	Crash Data Retrieval Tool 21.1.1
Reported with Software Licensed to (Company Name)	Arizona DPS
EDR Device Type	Airbag Control Module
Event(s) recovered	Front/Rear (1), Side (2)

## Comments

Image Authority: Warrant #SW2021-081887

Type of image: Direct to module, in vehicle

Power supply: AC Power to adapter

Vehicle Cable Used: F00K108614

Adapter Used (if any): F00k108387, Serial to USB Adapter

Tires on Vehicle: 215/45R17

Recommended Tire Size:

People present: S. O'Bryant #5501, T Petersen #7075, J. Procnier #6285, D. Pereria NTSB

Other notes as appropriate: 2013 Lexus 200H

## Data Limitations

### CDR Record Information:

- Due to limitations of the data recorded by the airbag ECU, such as the resolution, data range, sampling interval, time period of the recording, and the items recorded, the information provided by this data may not be sufficient to capture the entire crash.
- Pre-Crash data is recorded in discrete intervals. Due to different refresh rates within the vehicle's electronics, the data recorded may not be synchronous to each other.
- Airbag ECU data should be used in conjunction with other physical evidence obtained from the vehicle and the surrounding circumstances.
- If any of the front passenger seat airbags, side airbags, or Curtain Shield Airbags have deployed, data will not be overwritten or deleted by the airbag ECU following that event. If none of the airbags have deployed, the data of that event may be overwritten by a following event even if other airbags (pretensioner, rear seat airbag, etc.) have deployed.
- If power supply to the airbag ECU is lost during an event, all or part of the data may not be recorded.
- "Diagnostic Trouble Codes" are information about faults when a recording trigger is established. Various diagnostic trouble codes could be set and recorded due to component or system damage during an accident.
- The airbag ECU records only diagnostic information related to the airbag system. It does not record diagnostic information related to other vehicle systems.
- The TaSCAN, Global Tech Stream, or Intelligent Tester II devices (or any other Toyota genuine diagnostic tool) can be used to obtain detailed information on the diagnostic trouble codes from the airbag system, as well as diagnostic information from other systems. However, in some cases, the diagnostic trouble codes of the airbag system recorded by the airbag ECU when the event occurred may not match the diagnostic trouble codes read out when the diagnostic tool is used.

### General Information:

- The data recording specifications of Toyota's airbag ECUs are divided into the following categories. The specifications for 12EDR or later are designed to be compatible with NHTSA's 49CFR Part 563 rule.  
- 00EDR / 02EDR / 04EDR / 06EDR / 10EDR / 12EDR / 13EDR / 15EDR / 17EDR / 19EDR

- The airbag ECU records data for all or some of the following accident types: frontal crash, rear crash, side crash, and rollover events. Depending on the installed airbag ECU, data for side crash and/or rollover events may not be recorded.
- This airbag ECU records pre-crash data and post-crash data.
  - If a single event occurs independently, the data for that event is recorded on a one-to-one basis.
  - If multiple events occur successively (within a period of approximately 500ms), the establishment of the recording trigger for the first event is defined as the "pre-crash recording trigger". Pre-crash data for the first event and post-crash data for each successive event is then recorded.
- The airbag ECU has two recording pages (memory maps) to store pre-crash data. Additionally, to store post-crash data, the airbag ECU has two recording pages for each accident type: two pages for frontal and rear crash, two pages for a side crash, and two pages for rollover event.
- The data recorded by the airbag ECU includes correlating information between each previously occurring event (i.e., information that clarifies the collision event sequence. This correlation information consists of the following items.
  - Time from Previous Pre-Crash TRG
  - Linked Pre-Crash Page
  - Time from Pre-Crash TRG
  - TRG Count
  - Previous Crash Type
- In frontal and rear collision events, the first point where a longitudinal cumulative delta-V of over 0.8 km/h (0.5 mph) is reached is regarded as time zero for the recorded data. In side impact collision and rollover events, the point in time at which the recording trigger is established is regarded as time zero for the recorded data.
- The recording trigger judgment threshold value differs depending on the collision type (i.e., frontal crash, rear crash, side crash, or rollover event).
- Some of the data recorded by the airbag ECU is transmitted to the airbag ECU from various vehicle control modules by the vehicle's Controller Area Network (CAN).
- In some cases, the airbag ECU part number printed on the ECU label may not match the airbag ECU part number that the CDR tool reports. The part number retrieved by the CDR tool should be considered as the official ECU part number.
- In frontal and rear collision events, the record time varies depending on the period during which a longitudinal cumulative delta-V of over 0.8 km/h (0.5 mph) is reached, and time series data is recorded for up to 250 ms. The record time described above is indicated as "Length of Delta-V". "Delta-V, Longitudinal" outside the record time is indicated by area shaded in the table, and not indicated in the graph.

**Data Element Sign Convention:**

The following table provides an explanation of the sign notation for data elements that may be included in this CDR report.

Data Element Name	Positive Sign Notation Indicates
Maximum Delta-V, Longitudinal	Forward
Delta-V, Longitudinal	Forward
Lateral Acceleration for Frontal/Rear Crash, Floor Sensor	Left to Right
Lateral Acceleration, Side Satellite Sensor 1	Left to Right
Lateral Acceleration, Side Satellite Sensor 2	Left to Right
Lateral Acceleration, Side Satellite Sensor 3	Left to Right
Lateral Acceleration, Side Satellite Sensor 4	Left to Right
Lateral Acceleration for Side Crash, Floor Sensor	Left to Right
Roll Angle Peak	Clockwise Rotation
Roll Angle at the Time of TRG	Clockwise Rotation
Roll Rate	Clockwise Rotation
Lateral Acceleration for Rollover, Floor Sensor	Left to Right
Longitudinal Acceleration, VSC Sensor	Forward
Yaw Rate	Left Turn
Steering Input	Left Turn

**Data Definitions:**

- The "ON" setting for the "Freeze Signal" indicates a state in which the non-volatile memory can not be overwritten or deleted by the airbag ECU. After "Freeze Signal" has been turned ON, subsequent events will not be recorded.
- "Recording Status" indicates a state in which all recorded event data has been written into the non-volatile memory, or a state in which this process was interrupted and not fully written into the non-volatile memory. If "Recording Status" is "Incomplete", recorded event data may not be valid.
- If the "Occupant Size Classification, Front Passenger" displays "Child" or "Not Occupied", "Side Air Bag Deployment, Time to Deploy" and "Pretensioner Deployment, Time to Fire" may indicate a time even if deployment did not occur on the for following part no's:
  - 89170-07280, 35400, 35410, 35470, 42660, 0R120, 0R080, 0R081, 0R150
- "Engine RPM" indicates the number of engine revolutions, not the number of motor revolutions. The recorded value has an upper limit of 12,800 rpm. Resolution is 100 rpm and the value is rounded down and recorded. For example, if the actual engine speed is 799 rpm, the recorded value will be 700 rpm.
- If the electric vehicle is using a calculated/virtual engine RPM for drivetrain control, "Engine RPM" may be recorded, but should not be used during data analysis.
- The upper limit for the recorded "Vehicle Speed" value is 200 km/h (125mph). Resolution is 1km/h (0.6mph) and the value is rounded down and recorded. The accuracy of the "Vehicle Speed" value can be affected by various factors. These include, but not limited, to the following.
  - Significant changes in the tire's rolling radius
  - Wheel lock and wheel slip
- "Accelerator Pedal" has two recording specifications. Both the recorded value increases as the driver depresses the accelerator.
  - Percentage of accelerator pedal depressed (recorded as 0-100(%)).
  - Output voltage of accelerator pedal module (recorded as 0-5(V)).
- If M/T transmission vehicle of some limited model, "Shift Position" may display "Drive" regardless of the actual shift position.
- Depending on the type of occupant sensor installed in the vehicle, one of the following three recording formats for "Occupant Size Classification,

Front Passenger" will be utilized.

- Occupied / Not Occupied

- AM50 / AF05 / Child / Not Occupied

- AM50 / AF05 / Child or Not Occupied

- "Cruise Control Status" indicates whether the cruise control system is actuated or not. OFF indicates that the cruise control system is not actuated, but can also indicate that the vehicle is not equipped with the system.
- "Air Bag Warning Lamp, On/Off", "Ignition Cycle, Crash", "Seat Track Position Switch, Foremost, Status, Driver", "Occupant Size Classification, Front Passenger", "Safety Belt Status, Driver", "Safety Belt Status, Front Passenger", "Frontal Air Bag Suppression Switch Status, Front Passenger", and "RSCA Disable Switch" indicate the state approximately 1 second before time zero. They may not always indicate the state at the moment of collision.
- The upper and lower limits for the recorded value of "Motor RPM" is 17,500 rpm and -7,500 rpm respectively. Resolution is 100 rpm and the value is rounded down and recorded.
- "Brake Oil Pressure" has an upper limit of 12.14 Mpa. In the case of the vehicle that has not VSC system, "0 Mpa" or "Invalid" may be displayed.
- "Longitudinal Acceleration, VSC Sensor" has upper and lower limits for the recorded value of 8.973 m/s<sup>2</sup> and -8.973 m/s<sup>2</sup> respectively. This acceleration sensor does not sense collisions.
- "Sequential Shift Range" displaying "Undetermined" indicates the shift range is undetermined or was not being used.
- Some vehicles will not be equipped with all "Drive Mode" types indicated in the "Drive Mode" table. If some or all drive modes are not applicable to vehicle, "OFF" or "Invalid" may be displayed. The item in the "Drive Mode" table may not match the name of switch or indicator that equipped the vehicle.
- The upper and lower limits for the recorded value of "Steering Input" is 375 deg and -375 deg respectively. Resolution is 1.5 deg and the value is rounded down and recorded.
- Resolution of the "Air Bag Warning Lamp ON Time Since DTC was Set" is 15 minutes, and the value is rounded down and recorded.
- "Delta-V, Longitudinal" indicates the change in forward speed after time zero. This does not refer to vehicle speed, and it does not include the change in speed during the period from the start of the actual collision to establishment of the time zero.
- "Location of Side Satellite Sensor" shows the outline of a typical sensor position. Sensory location can be confirmed using the repair manual.
- "Time from Previous Pre-Crash TRG" indicates the time between the establishment of an event's pre-crash recording trigger to the establishment of a more recent event's pre-crash recording trigger. The upper limit for the recorded value is 16,381 milliseconds. In the event of establishment of the first pre-crash recording trigger after the ignition is switched ON, the upper limit value(max value) is recorded.
- "TRG Count" indicates a calculated value of the number of times recording triggers have been established for all crash types. The sequence in which each event occurred can be verified from the "TRG Count". The smaller the "TRG Count" value, the older the data. The upper limit for the recorded value is 65,533 times. When more than one event reaches the upper limit, the actual "TRG Count" may be greater than what is displayed for that event.
- "Linked Pre-Crash Page" is used to link 'paged" pre-crash data with 'paged" post-crash data. When old pre-crash data is overwritten by new pre-crash data, the "Linked Pre-Crash Page" value may record a page number that is not actually linked.
- Resolution of the "Time from Pre-Crash to TRG" is 50 [ms], and the value is rounded up and recorded.
- "Roll Angle at the Time of TRG" and "Roll Angle Peak" do not represent the actual roll angle of the vehicle. These values are used internally by the airbag ECU for sensing a rollover.

05013\_ToyotaS00std\_r028

### System Status at Time of Retrieval

ECU Part Number	89170-76210
EDR Generation	13EDR
Complete File Recorded	Yes
Freeze Signal	ON
Freeze Signal Factor	Side Airbag Deployment, Left Side
Diagnostic Trouble Codes Exist	No
Ignition Cycle .Download (times)	17434
Multi-event, number of events (times)	2 or greater
Time from event 1 to 2 (s)	0.878
Time from Previous Pre Crash TRG (msec)	885
Latest Pre-Crash Page	0
Contains Unlinked Pre-Crash Data	No

### Event Record Summary at Retrieval

Events Recorded	TRG Count	Crash Type	Time (msec)	Pre-Crash & DTC Data Recording Status	Event & Crash Pulse Data Recording Status
Most Recent Event	6	Side Crash	0	Complete (Page 0)	Complete (Side Page 0)
1st Prior Event	5	Side Crash	-878	Complete (Page 1)	Complete (Side Page 1)
2nd Prior Event	4	Front/Rear Crash	-913	Complete (Page 1)	Complete (Front/Rear Page 0)


**System Status at Event (Most Recent Event, TRG 6)**

Recording Status, Side Crash Info.	Complete
Crash Type	Side Crash
TRG Count (times)	6
Previous Crash Type	Side Crash
Time from Pre-Crash TRG (msec)	0
Linked Pre-Crash Page	0
Side Airbag Deployment, Time to Deploy (If Equipped) (msec)	3
Side Curtain Airbag Deployment, Time to Deploy (If Equipped) (msec)	3
Pretensioner Deployment, Time to Fire (msec)	3
Rear Window Airbag Deployment, Time to Deploy (msec)	SNA

**Lateral Crash Pulse (Most Recent Event, TRG 6 - table 1 of 2)**

Recording Status, Time Series Data	Complete
Recorded Side	Left Side
Time from TRG to Next Sample (msec)	0
Location of Side Satellite Sensor 1	Front Door
Location of Side Satellite Sensor 2	B-Pillar
Location of Side Satellite Sensor 3	Not Equipped
Location of Side Satellite Sensor 4	C-Pillar
Location of Floor Sensor	Airbag ECU
Clipping Time of Lateral Acceleration, Side Satellite Sensor 1 (msec)	No
Clipping Time of Lateral Acceleration, Side Satellite Sensor 2 (msec)	No
Clipping Time of Lateral Acceleration, Side Satellite Sensor 3 (msec)	SNA
Clipping Time of Lateral Acceleration, Side Satellite Sensor 4 (msec)	No
Clipping Time of Lateral Acceleration, Floor Sensor (msec)	No


**Side Satellite Sensor 1**



**Deployment Time Marker Key**

1	Driver/Passenger Pretensioner
2	Side Airbag
3	Rear Window Airbag Deployment Time

Side Satellite Sensor 2




Deployment Time Marker Key

1	Driver/Passenger Pretensioner
2	Side Airbag
3	Rear Window Airbag Deployment Time




**Side Satellite Sensor 3**



**Deployment Time Marker Key**

1	Side Curtain Airbag
---	---------------------


Side Satellite Sensor 4



Deployment Time Marker Key

1	Side Curtain Airbag
---	---------------------

**Floor Sensor**



**Deployment Time Marker Key**

1	Driver/Passenger Pretensioner
2	Side Airbag
3	Rear Window Airbag Deployment Time
4	Side Curtain Airbag

**Lateral Crash Pulse (Most Recent Event, TRG 6 - table 2 of 2)**

Time (msec)	Lateral Acceleration, Side Satellite Sensor 1 (m/sec <sup>2</sup> )	Lateral Acceleration, Side Satellite Sensor 2 (m/sec <sup>2</sup> )	Lateral Acceleration, Side Satellite Sensor 3 (m/sec <sup>2</sup> )	Lateral Acceleration, Side Satellite Sensor 4 (m/sec <sup>2</sup> )	Lateral Acceleration for Side Crash, Floor Sensor (m/sec <sup>2</sup> )
-24	0.0	0.0	SNA	0.0	-7.7
-20	0.0	0.0	SNA	0.0	-5.7
-16	19.2	0.0	SNA	0.0	-3.8
-12	0.0	0.0	SNA	0.0	-5.7
-8	-38.3	0.0	SNA	0.0	-5.7
-4	0.0	0.0	SNA	0.0	-3.8
0	153.2	0.0	SNA	0.0	-1.9
4	498.0	28.7	SNA	0.0	17.2
8	210.7	129.3	SNA	28.7	49.8
12	-114.9	86.2	SNA	57.5	93.9
16	38.3	143.7	SNA	57.5	93.9
20	95.8	100.6	SNA	86.2	80.4
24	19.2	57.5	SNA	76.6	82.4
28	153.2	71.9	SNA	95.8	65.1
32	76.6	100.6	SNA	86.2	24.9
36	0.0	43.1	SNA	86.2	93.9
40	-76.6	28.7	SNA	105.3	114.9
44	-57.5	86.2	SNA	95.8	103.4
48	0.0	57.5	SNA	114.9	114.9
52	-19.2	57.5	SNA	95.8	95.8
56	19.2	28.7	SNA	95.8	95.8
60	57.5	28.7	SNA	95.8	82.4
64	76.6	57.5	SNA	76.6	78.5
68	57.5	57.5	SNA	76.6	69.0

**DTCs Present at Time of Event (Most Recent Event, TRG 6)**

Recording Status, Diagnostic	Complete
Ignition Cycle Since DTC was Set (times)	1
Airbag Warning Lamp ON Time Since DTC was Set (min)	60
Diagnostic Trouble Codes	None

**Pre-Crash Data, 1 Sample (Most Recent Event, TRG 6)**

Recording Status, Pre-Crash/Occupant	Complete
Time from Pre-Crash to TRG (msec)	500
TRG Count when Pre-crash TRG was Established (times)	6
Safety Belt Status, Driver	ON
Safety Belt Status, Front Passenger	OFF
Occupant Size Classification, Front Passenger	Not Occupied
Frontal Airbag Suppression Switch Status, Front Passenger	SNA
RSCA Disable Switch	SNA
Seat Track Position Switch, Foremost, Status, Driver	No
Airbag Warning Lamp, On/Off	OFF
Ignition Cycle ,Crash (times)	17433

### Pre-Crash Data, -5 to 0 seconds (Most Recent Event, TRG 6)

Time (sec)	-5	-4.5	-4	-3.5	-3	-2.5	-2	-1.5	-1	-0.5	0 (TRG)
Vehicle Speed (MPH [km/h])	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	3.1 [5]	26.1 [42]	3.7 [6]
Accelerator Pedal, % Full (%)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	51.5	90.0	0.0	0.0
Percentage of Engine Throttle (%)	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid
Engine RPM (RPM)	0	0	0	0	0	0	0	0	900	1,000	800
Motor RPM (RPM)	0	0	0	0	0	0	0	0	400	3,100	700
Service Brake, ON/OFF	ON	ON	ON	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
Brake Oil Pressure (Mpa)	0.14	0.14	0.14	0.14	0.14	0.14	0.00	0.00	0.00	0.00	0.00
Longitudinal Acceleration, VSC Sensor (m/sec <sup>2</sup> )	0.072	0.072	0.072	0.072	0.072	0.072	0.072	1.795	3.374	-3.589	0.431
Yaw Rate (deg/sec)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	-0.98	61.00	61.00
Steering Input (degrees)	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-13.5	-34.5	15.0	-241.5
Shift Position	D	D	D	D	D	D	D	D	D	D	D
Sequential Shift Range	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined
Cruise Control Status	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, PWR	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, ECO	ON	ON	ON	ON	ON	ON	ON	ON	ON	OFF	OFF
Drive Mode, Sport	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, Snow	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, EV	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

Fuel Injection Quantity (mm3/st)	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid
----------------------------------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------

**System Status at Event (1st Prior Event, TRG 5)**


Recording Status, Side Crash Info.	Complete
Crash Type	Side Crash
TRG Count (times)	5
Previous Crash Type	Front/Rear Crash
Time from Pre-Crash TRG (msec)	7
Linked Pre-Crash Page	1
Side Airbag Deployment, Time to Deploy (If Equipped) (msec)	No
Side Curtain Airbag Deployment, Time to Deploy (If Equipped) (msec)	No
Pretensioner Deployment, Time to Fire (msec)	No
Rear Window Airbag Deployment, Time to Deploy (msec)	SNA



**Lateral Crash Pulse (1st Prior Event, TRG 5 - table 1 of 2)**

Recording Status, Time Series Data	Complete
Recorded Side	Right Side
Time from TRG to Next Sample (msec)	3
Location of Side Satellite Sensor 1	Front Door
Location of Side Satellite Sensor 2	B-Pillar
Location of Side Satellite Sensor 3	Not Equipped
Location of Side Satellite Sensor 4	C-Pillar
Location of Floor Sensor	Airbag ECU
Clipping Time of Lateral Acceleration, Side Satellite Sensor 1 (msec)	No
Clipping Time of Lateral Acceleration, Side Satellite Sensor 2 (msec)	No
Clipping Time of Lateral Acceleration, Side Satellite Sensor 3 (msec)	SNA
Clipping Time of Lateral Acceleration, Side Satellite Sensor 4 (msec)	No
Clipping Time of Lateral Acceleration, Floor Sensor (msec)	No


**Side Satellite Sensor 1**



**Deployment Time Marker Key**

1	Driver/Passenger Pretensioner
2	Side Airbag
3	Rear Window Airbag Deployment Time


Side Satellite Sensor 2



Deployment Time Marker Key

1	Driver/Passenger Pretensioner
2	Side Airbag
3	Rear Window Airbag Deployment Time


**Side Satellite Sensor 3**



**Deployment Time Marker Key**

1	Side Curtain Airbag
---	---------------------


Side Satellite Sensor 4



Deployment Time Marker Key

1	Side Curtain Airbag
---	---------------------

Floor Sensor



Deployment Time Marker Key

1	Driver/Passenger Pretensioner
2	Side Airbag
3	Rear Window Airbag Deployment Time
4	Side Curtain Airbag

**Lateral Crash Pulse (1st Prior Event, TRG 5 - table 2 of 2)**

<b>Time (msec)</b>	<b>Lateral Acceleration, Side Satellite Sensor 1 (m/sec^2)</b>	<b>Lateral Acceleration, Side Satellite Sensor 2 (m/sec^2)</b>	<b>Lateral Acceleration, Side Satellite Sensor 3 (m/sec^2)</b>	<b>Lateral Acceleration, Side Satellite Sensor 4 (m/sec^2)</b>	<b>Lateral Acceleration for Side Crash, Floor Sensor (m/sec^2)</b>
-21	0.0	0.0	SNA	19.2	-9.6
-17	-19.2	0.0	SNA	-9.6	0.0
-13	0.0	0.0	SNA	19.2	0.0
-9	0.0	57.5	SNA	57.5	1.9
-5	38.3	28.7	SNA	-28.7	-3.8
-1	38.3	28.7	SNA	86.2	1.9
3	0.0	43.1	SNA	67.0	-9.6
7	0.0	-14.4	SNA	47.9	-15.3
11	-38.3	-14.4	SNA	47.9	0.0
15	0.0	43.1	SNA	0.0	5.7
19	0.0	14.4	SNA	0.0	-11.5
23	0.0	-28.7	SNA	-9.6	-9.6
27	0.0	-28.7	SNA	0.0	-1.9
31	0.0	0.0	SNA	-76.6	-9.6
35	-19.2	14.4	SNA	-67.0	-3.8
39	19.2	14.4	SNA	-28.7	-9.6
43	19.2	0.0	SNA	0.0	-11.5
47	0.0	0.0	SNA	9.6	1.9
51	0.0	0.0	SNA	28.7	3.8
55	0.0	14.4	SNA	9.6	1.9
59	19.2	14.4	SNA	0.0	3.8
63	19.2	14.4	SNA	0.0	9.6
67	19.2	28.7	SNA	9.6	11.5
71	0.0	0.0	SNA	9.6	5.7

**DTCs Present at Time of Event (1st Prior Event, TRG 5)**

Recording Status, Diagnostic	Complete
Ignition Cycle Since DTC was Set (times)	1
Airbag Warning Lamp ON Time Since DTC was Set (min)	60
Diagnostic Trouble Codes	None

**Pre-Crash Data, 1 Sample (1st Prior Event, TRG 5)**

Recording Status, Pre-Crash/Occupant	Complete
Time from Pre-Crash to TRG (msec)	100
TRG Count when Pre-crash TRG was Established (times)	4
Safety Belt Status, Driver	ON
Safety Belt Status, Front Passenger	OFF
Occupant Size Classification, Front Passenger	Not Occupied
Frontal Airbag Suppression Switch Status, Front Passenger	SNA
RSCA Disable Switch	SNA
Seat Track Position Switch, Foremost, Status, Driver	No
Airbag Warning Lamp, On/Off	OFF
Ignition Cycle ,Crash (times)	17433

### Pre-Crash Data, -5 to 0 seconds (1st Prior Event, TRG 5)

Time (sec)	-4.6	-4.1	-3.6	-3.1	-2.6	-2.1	-1.6	-1.1	-0.6	-0.1	0 (TRG)
Vehicle Speed (MPH [km/h])	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	3.1 [5]	3.7 [6]
Accelerator Pedal, % Full (%)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	51.5	90.0	96.0
Percentage of Engine Throttle (%)	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid
Engine RPM (RPM)	0	0	0	0	0	0	0	0	0	900	900
Motor RPM (RPM)	0	0	0	0	0	0	0	0	0	400	400
Service Brake, ON/OFF	ON	ON	ON	ON	ON	ON	ON	OFF	OFF	OFF	OFF
Brake Oil Pressure (Mpa)	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.00	0.00	0.00	0.00
Longitudinal Acceleration, VSC Sensor (m/sec^2)	0.072	0.072	0.072	0.072	0.072	0.072	0.072	0.072	1.795	3.374	8.973
Yaw Rate (deg/sec)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	-0.98	2.93
Steering Input (degrees)	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-13.5	-34.5	-39.0
Shift Position	D	D	D	D	D	D	D	D	D	D	D
Sequential Shift Range	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined
Cruise Control Status	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, PWR	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, ECO	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
Drive Mode, Sport	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, Snow	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, EV	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF




Fuel Injection Quantity (mm3/st)	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid
----------------------------------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------

### System Status at Event (2nd Prior Event, TRG 4)

Recording Status, Front/Rear Crash Info.	Complete
Crash Type	Front/Rear Crash
TRG Count (times)	4
Previous Crash Type	No Event
Time from Pre-Crash TRG (msec)	0
Linked Pre-Crash Page	1
Frontal Airbag Deployment, Time to 1st Stage Deployment, Driver (msec)	No
Frontal Airbag Deployment, Time to 1st Stage Deployment, Front Passenger (msec)	No
Pretensioner Deployment, Time to Fire, Driver (msec)	No
Pretensioner Deployment, Time to Fire, Front Passenger (msec)	No
Frontal Airbag Deployment, Time to 2nd Stage, Driver (msec)	N/A
Frontal Airbag Deployment, Time to 2nd Stage, Front Passenger (msec)	N/A
Active Head Restraint, Time to Deploy, Driver (msec)	SNA
Active Head Restraint, Time to Deploy, Front Passenger (msec)	SNA
Side Curtain Airbag Deployment, Time to Deploy, Driver (msec)	No
Side Curtain Airbag Deployment, Time to Deploy, Passenger (msec)	No
Side Airbag Deployment, Time to Deploy, Driver (msec)	SNA
Side Airbag Deployment, Time to Deploy, Passenger (msec)	SNA
Rear Window Airbag Deployment, Time to Deploy (msec)	SNA

**Longitudinal/Lateral Crash Pulse (2nd Prior Event, TRG 4 - table 1 of 2)**


Recording Status, Time Series Data	Complete
Time from Time Zero to TRG (msec)	28.0
Length of Delta-V (msec)	160
Max. Longitudinal Delta-V (MPH [km/h])	23.8 [38.3]
Time, Maximum Delta-V, Longitudinal (msec)	142.0
Power Supply Status at Max. Delta-V	ON
Clipping Time of Longitudinal Delta-V (msec)	No
Clipping Time of Lateral Acceleration, Floor Sensor (msec)	No



**Deployment Time Marker Key**

1	Driver Airbag Deployment Time
2	Passenger Airbag Deployment Time
3	Driver/Passenger Pretensioner
4	Driver 2nd Stage Airbag Deployment Time
5	Passenger 2nd Stage Airbag Deployment
6	Driver/Passenger AHR
7	Driver CSA
8	Passenger CSA
9	Rear Window Airbag Deployment Time
10	Driver SAB
11	Passenger SAB

Lateral Acceleration for frontal/rear crash, Floor Sensor



Deployment Time Marker Key

1	Driver Airbag Deployment Time
2	Passenger Airbag Deployment Time
3	Driver/Passenger Pretensioner
4	Driver 2nd Stage Airbag Deployment Time
5	Passenger 2nd Stage Airbag Deployment
6	Driver/Passenger AHR
7	Driver CSA
8	Passenger CSA
9	Rear Window Airbag Deployment Time
10	Driver SAB
11	Passenger SAB

**Longitudinal/Lateral Crash Pulse (2nd Prior Event, TRG 4 - table 2 of 2)**

<b>Time (msec)</b>	<b>Longitudinal Delta-V (MPH [km/h])</b>	<b>Lateral Acceleration for Frontal/Rear Crash, Floor Sensor (m/sec^2)</b>	<b>Power Supply Status</b>
0	0.0 [0.0]	0.0	ON
10	1.9 [3.0]	-13.4	ON
20	3.4 [5.5]	0.0	ON
30	5.7 [9.1]	0.0	ON
40	9.3 [14.9]	-9.6	ON
50	12.7 [20.4]	1.9	ON
60	15.8 [25.4]	-9.6	ON
70	18.0 [29.0]	-5.7	ON
80	19.9 [32.0]	-5.7	ON
90	21.3 [34.2]	3.8	ON
100	22.1 [35.6]	9.6	ON
110	22.6 [36.4]	3.8	ON
120	23.3 [37.5]	3.8	ON
130	23.5 [37.8]	3.8	ON
140	23.7 [38.1]	1.9	ON
150	23.8 [38.3]	1.9	ON
160	23.8 [38.3]	-1.9	ON
170	0.0 [0.0]	0.0	ON
180	0.0 [0.0]	0.0	ON
190	0.0 [0.0]	0.0	ON
200	0.0 [0.0]	0.0	ON
210	0.0 [0.0]	0.0	ON
220	0.0 [0.0]	0.0	ON
230	0.0 [0.0]	0.0	ON
240	0.0 [0.0]	0.0	ON
250	0.0 [0.0]	0.0	ON

**DTCs Present at Time of Event (2nd Prior Event, TRG 4)**

Recording Status, Diagnostic	Complete
Ignition Cycle Since DTC was Set (times)	1
Airbag Warning Lamp ON Time Since DTC was Set (min)	60
Diagnostic Trouble Codes	None

**Pre-Crash Data, 1 Sample (2nd Prior Event, TRG 4)**

Recording Status, Pre-Crash/Occupant	Complete
Time from Pre-Crash to TRG (msec)	100
TRG Count when Pre-crash TRG was Established (times)	4
Safety Belt Status, Driver	ON
Safety Belt Status, Front Passenger	OFF
Occupant Size Classification, Front Passenger	Not Occupied
Frontal Airbag Suppression Switch Status, Front Passenger	SNA
RSCA Disable Switch	SNA
Seat Track Position Switch, Foremost, Status, Driver	No
Airbag Warning Lamp, On/Off	OFF
Ignition Cycle ,Crash (times)	17433

### Pre-Crash Data, -5 to 0 seconds (2nd Prior Event, TRG 4)

Time (sec)	-4.6	-4.1	-3.6	-3.1	-2.6	-2.1	-1.6	-1.1	-0.6	-0.1	0 (TRG)
Vehicle Speed (MPH [km/h])	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	0 [0]	3.1 [5]	3.7 [6]
Accelerator Pedal, % Full (%)	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	51.5	90.0	96.0
Percentage of Engine Throttle (%)	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid
Engine RPM (RPM)	0	0	0	0	0	0	0	0	0	900	900
Motor RPM (RPM)	0	0	0	0	0	0	0	0	0	400	400
Service Brake, ON/OFF	ON	ON	ON	ON	ON	ON	ON	OFF	OFF	OFF	OFF
Brake Oil Pressure (Mpa)	0.14	0.14	0.14	0.14	0.14	0.14	0.14	0.00	0.00	0.00	0.00
Longitudinal Acceleration, VSC Sensor (m/sec^2)	0.072	0.072	0.072	0.072	0.072	0.072	0.072	0.072	1.795	3.374	8.973
Yaw Rate (deg/sec)	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	-0.98	2.93
Steering Input (degrees)	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-1.5	-13.5	-34.5	-39.0
Shift Position	D	D	D	D	D	D	D	D	D	D	D
Sequential Shift Range	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined	Undetermined
Cruise Control Status	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, PWR	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, ECO	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
Drive Mode, Sport	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, Snow	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Drive Mode, EV	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

Fuel Injection Quantity (mm3/st)	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid	Invalid
--	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------



## Hexadecimal Data

Data that the vehicle manufacturer has specified for data retrieval is shown in the hexadecimal data section of the CDR report. The hexadecimal data section of the CDR report may contain data that is not translated by the CDR program. The control module contains additional data that is not retrievable by the CDR system.

PIDs	PID	Data
	00	BC 60 00 01
	01	00
	03	37 36 32 31 30 30 30 30 30 30 30 30 30 30 30 30 30 30 30 30 30
		30 30
		30
	04	FF FF FF FF
	05	01
	06	17
	0A	01
	0B	00
	20	80 00 00 01
	21	02 9F
	40	00 00 00 01
	60	FF FF F0 01
	61	02 05 E8 00 C8 C0 05 00 02 80 02 80 03 55 03 55 00 00 00 00 05 00
		05 00 19 00 00 00 00 00 C0 00
	62	A5 02 03 75 44 1A 80 01 80 04
	63	55 24 44 19 10 10 00 00 11 11 11 11 10 00 00 00 00 00 00 00 00
		05 2A 06 00 00 00 00 00 00 00 67 B4 00 00 55 50 00 00 00 00 00 00
		00 00 00 09 0A 08 00 00 00 00 00 00 00 06
	64	55 04 44 19 10 10 00 00 11 11 11 11 11 10 00 00 00 00 00 00 00
		00 05 06 00 00 00 00 00 00 00 00 00 67 B4 C0 55 54 00 00 00 00 00 00
		00 00 00 00 09 09 00 00 00 00 00 00 00 04
	65	55 00 01 00 04 00 00 00 00 00 00 00 00 00 00 00 00 00 00
	66	55 00 01 00 04 00 00 00 00 00 00 00 00 00 00 00 00 00
	67	55 E4 00 00 04 FE FE FE FE FE 55 FD FD FF FE FF FE FF FE FF FE 03
		FE
	68	00 00
		00
	69	00 38 11 00 00 3F F5 3F EC 3F DF 3F CA 3F B6 3F A4 3F 97 3F 8C 3F
		84 3F 7F 3F 7C 3F 78 3F 77 3F 76 3F 75 3F 75 00 00 00 00 00 00 00
		00 00 00 00 00 00 00 00 00 00 00 00 3F 75 01 1C
	6A	00 00
		00 00
		00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
	6B	55 10 00 00 06 03 FE 00 FE 55 00 00 00 01 00 FE 00 08 1A 0B FA 02
		05 01 08 04 00 FC FD 00 FF 01 03 04 03 00 00 00 00 00 00 00 00
		00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
	6C	55 04 07 00 05 FE FE FE FE 55 13 00 01 00 00 FE FE 00 00 02 00 00
		00 00 00 01 FF FF 00 00 00 FF FF FF 00 00 00 00 00 00 00 00 00
		00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
	6D	00 00 00 00 00 00 00 02 09 06 0A 07 04 05 07 03 02 06 04 04 02 02
		04 04 00 00 00 00 00 00 00 00 03 06 06 09 08 0A 09 09 0B 0A 0C 0A
		0A 0A 08 08 00 FE 01 FE 01 FE 01 FE 01 FE
	6E	00 00 00 FC FE FE FD 01 01 FD FF 02 02 00 FF FF 00 00 00 FF FF FF
		FE 00 FE 01 FE FA 03 F7 F9 FB FB 00 00 01 00 08 07 03 00 FF FD FF
		00 00 FF FF 00 FE 01 FE 01 FE 01 FE 01 FE
	6F	00 00
		00 00
		00 00 00 00 00 00 00 00 00
	70	00 00
		00 00
		00 00 00 00 00 00 00 00 00
	71	00 00
		00 00
	72	00 00
		00 00
		00 00
	73	03 03 03 03 03 03 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
		00 00 00 00 00 00 00 00 00 FE 7D 7D 01 01 01 01 01 01 19 2F CE 06
		FE FE FE FE FE FE FE FE FE FE FE FE 00 00 00
	74	03 03 03 03 03 03 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

```
      00 00 00 00 00 00 00 00 00 00 FE 06 01 01 01 01 01 01 01 19 2F 7D
      FE FE FE FE FE FE FE FE FE FE FE FE 00 00 00
80    00 00 00 01
A0    0C 00 1F 81
A5    00 02 00 02 00 02 00 02 00 02 00 02 00 02 00 02 00 02 00 00 00 00
      4B 4B 4B 4B 4B 4B 4B 4B 4F 6A 52 14 14 14 14 14 14 14 40 14 14
      FE FE FE FE FE FE FE FE FE FE FE FE
A6    00 02 00 02 00 02 00 02 00 02 00 02 00 02 00 02 00 02 00 02 00 02
      4B 4B 4B 4B 4B 4B 4B 4B 4B 4F 4F 14 14 14 14 14 14 14 14 40 40
      FE FE FE FE FE FE FE FE FE FE FE FE
B4    04 03 02 03 03 02 01 F7 E6 CF CF D6 D5 DE F3 CF C4 CA C4 CE CE D5
      D7 DC 01 FE
B5    05 00 00 FF 02 FF 05 08 00 FD 06 05 01 05 02 05 06 FF FE FF FE FB
      FA FD 01 FE
B6    00 07 00 00 05 FF 05 03 03 FE FB FE FE FE FF FF 01 00 00 00 00 00
      00 00 00 00 03 FE
B7    00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
      00 00 00 00 00 00
B8    03 FF 03 FF 03 FF 03 FF 03 FF 03 FF 03 FF 03 FF 03 F7 03 E9 00 0A 03 5F
B9    03 FF 03 FF 03 FF 03 FF 03 FF 03 FF 03 FF 03 FF 03 FF 03 F7 03 E9 03 E6
```

## **Disclaimer of Liability**

The users of the CDR product and reviewers of the CDR reports and exported data shall ensure that data and information supplied is applicable to the vehicle, vehicle's system(s) and the vehicle ECU. Robert Bosch LLC and all its directors, officers, employees and members shall not be liable for damages arising out of or related to incorrect, incomplete or misinterpreted software and/or data. Robert Bosch LLC expressly excludes all liability for incidental, consequential, special or punitive damages arising from or related to the CDR data, CDR software or use thereof.