

Call sign D5NJ9 Gross tonnage 30040 Net tonnage 13312 tonnes, and Deadweight 50, 760.4 tonnes, and Block coefficient 78.9 at summer full load draught

Draught at which	the manoeuvring
data were	obtained

Loaded	Ballast		
Trial/Estimated	Trial/Estimated		
11.0 m forward	8.1 m forward		
11.0 maft	8.6 m af		

Type of rudder(s) SEMI BA	LLANCE	
Maximum rudder angle	35	0
Time hard-over to hard-over	25	
with one power unit with two power units	15	S
Minimum speed to maintain		
course propeller stopped	3	knots
Rudder angle for neutral effect	0	

=	Thruster	kW (HP)	Time delay for full thrust	Turning rate at zero speed	Time delay to reverse full thrust	Not effective above speed
		т	HRUSTER EF	FECT at tria	conditions	
effect_	u		(1 shace	kle = <u>27.5</u>	m/	fathoms)
ped	3	knots				-
aln			Starboa	ard 1	2 10.5	M/MIN
nits	25 15	The second secon	Port	1		SM/MIN
	25		The state of the s			

ANCHOR CHAIN

No. of

shackles

Max. rate of


heaving


(min/shackle)

Type of engine 6550	B&W JMC-C	120.3RPM Type of propa	iller 1X4	
	Rpm/pitch setting	Speed (knots)		
Engine order		Loaded	Ballast	
Full sea spaed	117	14.5	15.5	
Full ahead	85	10.6	11.5	
Half ahead	75	9.3	10.2	
Slow ahead	67	8.1	9.0	
Dead slow ahead	38	3.6	4.5	
Dead slow astern	38	Critical revolutions Minimum rpm	47.58 rpn 2 3.0 knots	
Slow astern	67	Time limit astern Time limit at min revs Emergency full ahead		
Half astern	75	Stop to full astern Astern power 100	1 15	
Full astern	85	Max. no of consecutive start		

DOODHI CION DADTICILI ADC

DRAUGHT INCREASE (LOADED)				0)	
Estimated Squat Effect			Heel Effect		
Under keel clearance		Ship's speed (knots)	Max bow/stern squat estimated (m)	Heel angle (degree)	Draft increase (m)
OPEN IN		5	0.2	2	0.5
	m	10	0.8	4	1.1
		15	1.8	8	2.2
CONFINED I	m	5	0.4	12	3.3
		10	1.6	16	4.4







Life Saving Signals





International search and rescue communication signals based on SOLAS requirements



International ICAO
Code of Signals visual Signal I require assistance I require medical assistance Proceeding in this direction Note: Use International Code of Signal by means of lights or flags or by laying out the symbol on the deck or ground with items which have a high contrast to the background. Air to Surface Direction Signals Surface to Air Replies







Notes On Helicopter Operations WINCHING OPERATIONS With winchman on cable: ... Port bow, if rescue is aft or • Follow his instructions - he is in charge. strop until it has been

e Secure lines attached to appliances near the

winching or shine lights at the helicopter.

is forward. A beam wind is

Earth the winch cable. Put both arms and head through loop in strop. rescue area and illuminate at strop under the armpits and leading up in front of the face. Pull toggle down as far as possible. Fly a flag to indicate wind
 direction. Illuminate at night.
 When ready look up, lift one arm to horizontal and give thumbs up sign. Transmit on radio whilst direction, liluminate at night.

 The ship's crew should earth the rope and then haul in slack as the winch cable is payed out. Slack rope should be carefully coiled on deck and NOT MADE FAST. When the strop reaches deck level follow the procedure for winching operations. Ships crew should pay out rope as the winching operation proceeds.

HIGH LINE WINCHING OPERATIONS

In adverse weather the cable may be lowered

with a rope extension fixed to the strop.

This poster is a selective guide to be used in conjunction with the SOLAS Regulations and other National and International official publications

O 2003: MARITIME PROGRESS LTD.

Wear rubber gloves to handle and earth winch cable.

 Put arms beside body. When alongside helicopter follow instructions from the crew.

Ref 1058W