Factual Report – Attachment 17 CAE Lear 35A Checklists

OPERATIONAL FACTORS

CEN17MA183

PF Pilot Flying. The pilot responsible for controlling the aircraft. Performs tasks and responds to checklist challenges.		
PM Pilot Monitoring. Reads checklist challenges.		
♦ Through flight items		
Upon entering the cockpit, the following switch positions should be verified before starting any check.		
PM PF		
Start-Gen Switches OFF Gear Switch DOWN Fuel Jettison OFF		
Accomplish flow pattern checks, then use the BEFORE STARTING ENGINES checklist as a done list.		
BEFORE STARTING ENGINES		
Cabin Air Damper Knob/Switch AS DESIRED Emergency Exit AISLE CLEARED/HANDLE UNOBSTRUCTED Oxygen Masks/Valves/Pressure 100% CHECKED Circuit Breakers CHECKED Control Look STOWED Seat Belts/Harness/Seats SECURED/ADJUSTED Flight Controls CHECKED Audio Panel CHECKED Audio Panel CHECKED Avionics Master OFF Fuel Computers ON Pemergency Batteries CHECKED/AND ON Batteries CHECKED/AND ON GPU (if desired) CONNECTED/28 VDC Inverters CHECKED/AND ON In Normal/Out Defog Knob (if installed) IN Anti-Skid ON Pemergency Air (1,800 PSI min) CHECKED Hydraulic Pressure (1,000 PSI min) CHECKED Parking Brake PULL/CHECKED NOTE: Do not push handle downward. Hydraulic Pump Switch OFF		
♦ Warning LightsTESTED		
▶ Landing Gear Switch/Warning		
Fire Detect System		
Fuel Balance/Quantities		
Fuel Counter. ZERO		
Jet Pumps		
Standby Pumps		
♦ Crossflow/XFER-FILL/FUS VAL Switches CLOSE/OFF/CLOSE		
If External Power Not Used START ONE ENGINE		
Continued on next page		

PM PF	
Warning System Checks	
▶ No Smoking/Seat Belt Sign. ON Cabin Air OFF	
Pressurization AUTO/ALTITUDE/RATE SET	
Temp Controls	
▶ Bleed Air Switches	
Emer Pressurization Switches (if installed)	
▶ TOLD Data/Bugs	
lce Detect Lights	
▶ Emergency GyroUNCAGED	
CVR (If Installed). TEST	
Drag Chute Handle STOWED	
Trim/Pitch, Roll, Yaw/Switch	
Autopilot	
Yaw Dampers	
▶ Emer Lt Switch (if installed) TESTED/ARMED	
Avionics/Avionics Master	
RadarSTANDBY	
▶ Radio Altimeter	
GPWSTESTED	
TCAS TESTED AND ON	
STARTING ENGINES	
▶ Passengers/Baggage BRIEFED/SECURED	
Cabin Door TWO HANDLES FORWARD/LIGHT OUT	
▶ L/R Fuel CmptrsON/Lights Out	
▶ L/R Fuel CmptrsON/Lights Out	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE	
▶ L/R Fuel Cmptrs. ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ▶ Rotating Beacon ON	
▶ L/R Fuel Cmptrs. ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ▶ Rotating Beacon ON External Lighting AS REQUIRED	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ₱ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF	
▶ L/R Fuel Cmptrs. ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ▶ Rotating Beacon ON External Lighting AS REQUIRED	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ₱ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ▶ Air Conditioning/Aux Heat FAN or OFF ▶ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ▶ Parking Brake SET	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ▶ Air Conditioning/Aux Heat FAN or OFF ▶ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ▶ Parking Brake SET ▶ Hydraulic Pump Switch OFF	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ▶ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ▶ Parking Brake SET ▶ Hydraulic Pump Switch OFF ▶ Engines START	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ▶ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ▶ Parking Brake SET ▶ Hydraulic Pump Switch OFF ▶ Engines START ▶ Starter Disengagement CHECKED	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ₱ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ₱ Parking Brake SET ₱ Hydraulic Pump Switch OFF ₱ Engines START ₱ Starter Disengagement CHECKED ₱ Engine Instruments CHECKED	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ₱ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ₱ Parking Brake SET ₱ Hydraulic Pump Switch OFF ₱ Engines START Starter Disengagement CHECKED ₱ Engine Instruments CHECKED ₱ GPU DISCONNECTED	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ₱ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ₱ Parking Brake SET ₱ Hydraulic Pump Switch OFF ₱ Engines START ₱ Starter Disengagement CHECKED ₱ Engine Instruments CHECKED ₱ GPU DISCONNECTED ₱ Generators/DC Volts and Amps ON/CHECKED	
▶ L/R Fuel Cmptrs ON/Lights Out ▶ Batteries CHECKED FOR MIN VOLTAGE ▶ Inverters ON ♦ Air Conditioning/Aux Heat FAN or OFF ₱ Rotating Beacon ON External Lighting AS REQUIRED Thrust Levers CUTOFF ₱ Parking Brake SET ₱ Hydraulic Pump Switch OFF ₱ Engines START ₱ Starter Disengagement CHECKED ₱ Engine Instruments CHECKED ₱ GPU DISCONNECTED ₱ Generators/DC Volts and Amps ON/CHECKED	

Continued from previous page

Learjet 35/36 Operating Handbook For Training Purposes Only May 2012

N-2

N-1

Learjet 35/36 Operating Handbook For Training Purposes Only May 2012

BEFORE TAXI

	DEI ONE IAM		
	PM PF		
	Fuel Control Governors		
٠	Windshield HeatPURGED		
٠	Anti-SkidON/LIGHTS EXTINGUISHED		
	Spoileron/Spoilers		
	Flaps (8° or 20°)		
٠	Hydraulic Pressure/Low Hydraulic Light		
٠	LightingON/AS REQUIRED		
٠	Coffee/Oven		
٠	Circuit Breakers CHECKED IN		
٠	Parking BrakeRELEASED		
	TAXI		
٠	Brakes and Steering		
	Thrust Reversers		
	Flight ControlsCHECKED		
٠	Flight Instruments NO FLAGS/ALT/HEADING/VERIFIED		
٠	NAV Equipment/RadiosON/SET		
٠	Spoilers/Flaps/Trim RETRACTED/8° or 20° SET/CHECKED		
٠	Pressurization CHECKED		
	Cabin Air NORM OR ON		
	Anti-Ice Systems		
١	Cabin Check		
	BEFORE TAKEOFF		
٠	Crew Briefing		
٠	Fuel BalanceCHECKED		
٠	Cabin AirNORM OR ON		
٠	Anti-lce		
٠	Radar		
٠	Transponder		
٠	Dee Howard Thrust Reversers ARMED		
	RUNWAY LINE-UP		
٠	Pitot Heat		
	Air IgnitionON		
	Stall WarningsON		
	Parking Brake		
	Landing/Taxi LightsON		
	Recognition/Strobe Lights ON		
7	Steer Lock OFF		
٠	Warning Lights		
TAKEOFF			
ı	Nosewheel Steering		
7	Nosewheel Steering		
	OF AIRSPEED		

ΑH	IEK	TAKEOFF	

PM	PF	
Landing Gear	UP	
Yaw Damp PRI or SEC	ENGAGED	
Flaps	UP	
Dee Howard Thrust Reversers (prior to 200 KIAS).		
Anti-Ice Systems	AS REQUIRED	
Air Ignition	AS REQUIRED or OFF	
Landing/Taxi Lights	OFF	
Pressurization		
Autopilot APPR Light	OUT	
Hydraulic Pressure		
Angle-of-Attack Sensors	CROSS CHECK	
CLIMB		
At 10,000 ft:		
No Smoking/Seat Belt Sign	AS REQUIRED	
At 18,000 ft or Transition Altitude:		
Altimeters		
Cool/Fan Switch (if applicable)		
Emer Press Switches (if installed)	NORMAL	
Recognition Light	OFF	
Leaving FL 250:		
Crew Masks	Y. QUICK DON POSITION	
At FL 350:	, .	
Cool/Fan Switch (with FCN 89-1)	FAN or OFF	
Above FL 410 (450 Pressurization System):		
Crew/Passenger Oxygen Masks		
CRUISE		
Pressurization	MONITORED	
Engine Instruments		
Autopilot		
Windshield Heat		
Fuel Management		
DESCENT	WONITORED	
Wshld Heat/Wshld Defog/Aux Defog		
Pressurization		
Anti-lce Systems	AS REQUIRED	
FL 180/TRANSITION LEVEL		
Altimeters	SET/CROSS CHECK	
Air Conditioner	AS DESIRED	
Hydraulic Pressure		
Recognition Light		
TOLD Card/Bugs		
Cabin		
Seat Belt/No Smoking Sign		
willering eigni		

Learjet 35/36 Operating Handbook For Training Purposes Only May 2012

N-3

N-4

Learjet 35/36 Operating Handbook For Training Purposes Only May 2012

APPROACH

PM	PF			
Circuit Breakers Aeronca Thrust Reversers Hydraulic/Emergency Air Pressure Radio/Barometric Altimeters Fuel Balance. Avionics Crew Briefing/Bugs	TESTED CHECKED MINS SET/CROSS CHECK CHECKED SET FOR APPROACH			
BEFORE LANDIN	IG			
Spoilers	RETRACTED			
Flaps	AS DESIRED (8° OR 20°)			
Landing Gear	DOWŃ			
Engine Sync	OFF			
Anti-Skid	. ON/LIGHTS EXTINGUISHED			
Landing/Taxi Lights				
Dee Howard Thrust Reversers (below 200 KIA				
Cabin				
Flaps				
Hydraulic Pressure				
Air Ignition				
Autopilot				
Yaw Damper (FC200)	DISENGAGED			
LANDING				
After Touchdown:				
Spoilers	EXTENDED			
Brakes				
Thrust Reversers or Drag Chute	AS DESIRED			
Below 45 Kts:				
Nosewheel Steering	AS REQUIRED			
GO-AROUND				
Autopilot	DISENGAGED			
Thrust Levers				
Spoiler Switch				
Flaps				
Landing Gear Switch				
Climb	APPROACH CLIMB SPEED			
When Clear of Obstacles:				
Airspeed	V _{RFF} + 30			
Flaps	INLI			

Learjet 35/36 Operating Handbook For Training Purposes Only May 2012

N-5

N-6

AFTER LANDING/CLEARING RUNWAY

PM	PF
Anti-Ice Systems	AS REQUIRED
Air Ignition	
Stall Warnings	OFF
Landing/Taxi Lights	
Cabin Air.	
Recognition/Strobe Lights	
Unnecessary Avionics/Radar	
UNS	
Transponder	
Spoilers	
Flaps	
Hydraulic Pressure	
Trims	
Dee Howard Thrust Reversers	
Dee noward mildst neversers	UFF
SHUT DOWN	
Chocks/Parking Brake	AS REQUIRED
Anti-Ice Systems	OFF
Emer Power/Standby Gyro	
Panel Switches/Avionics	
Crossflow	CLOSED
Fus Tank XFER-FILL	OFF
Fus Valve	
Emergency Lights (if installed)	
Coffee and Oven	
Thrust Levers	
External Lighting	OFF
Inverters	
Generators	
Hydraulic Pressure (if applicable)	
Batteries	
Control Lock.	
QUICK TURNAROUND	
(ONE OR NO ENGINE SHUTDOW	
Cabin Door-Closed and Locked	
No Smoking/Seat Belt Switch	
Cool Fan/Aux Heat Switches	OFF OR FAN
Engine (if shut down)	START
Start-Gen Switch	GEN
DC Volts/Amps	CHECKED
Starter Disengagement	CHECKED
Current Limiters	CHECKED
Circuit Breakers	IN
Avionics	
Coffee/Oven Switches	AS REQUIRED
Anti-Ice Systems	AS REQUIRED
,	

Learjet 35/36 Operating Handbook For Training Purposes Only May 2012