

# APPENDIX A SECTION A7 (ENGINE STRUTS



STRUT ASSEMBLY DIAGRAM


## TORQUE BULKHEAD STRUT AID SPAR ATTACH FITTINGS -DIAGONAL BRACE WING LOWER SKIN WING FRONT SPAR DIAGONAL BRACE: ATTACH FITTING EXTENSIVE DAMAGE 3rd Generation" Fuse Pins (SN S) SEPARATED AT REAR ENGINE BULKHEAD - SIDE BRACE Strut-to-Wing Connections AFT SECTION SEPARATED AT WING CONNECT SIDE BRACE ATTACHMENT UPPER LINK (DUCTILE FRACTURE) NS/ 222, REAR ENGINE MOUNT STRUT MIDSPAR FITTINGS - MIDSPAR FUSE PINS -WING LOWER SURFACE STRUT NO. 1 SIDE BRACE UPPER SPAR-MIDSPAR FITTING-M.B.D FORWARD ENGINE MOUNT BULKHEAD FWD





A7.4


UPPER LINK FITTING DETACHED FROM FUSE BOLT ATTACHED TO FUSE BOLT UPPER LIKK UNDERWING FITTING INTALL MIDSPAR FITTING UPPER LINK INTACT UPPER SPAR FITTING H DETACHED FUSE BOLT (TYP) Strut-to-Wing Connections FUSE BOLT DIAGONAL BRACE FTG WING FUSE BOLT STRUT. 1  $\overline{\Xi}$ FUSEBOLT DIAGONAL BRACE FAIRING -DIAGONAL BRACE-UPPER LINK LOWER SPAR FITTING


/ (DETACHED) STRUT ASSEMBLY FUSE BOLT FUSE BOLT-

















UPPER LINK FITTING (INIACI) DETACHED FROM FUSE BOLT ATTACHED TO FUSE BOLT  $\widehat{\Xi}$ UNDERWING FITTING MIDŚPAR FITTING JPPER LINK (INTACT) UPPER SPAR FITTING DETACLÍED FUSE BOLT (TYP) Strut-to-Wing Connections FUSE BOLTS DIAGONAL BRACE FTG WING (VII) (INTACT) STRUT 3 FUSE BOLT FUSE BOLT DIAGONAL BRACE DIAGONAL BRA'CE-FAIRING. UPPER LINK LOWER SPAR FITTING STRUT ASSEMBLY FUSE BOLT. FUSE BOLT-





SIDE BRACE ATTACHMENT







#### MIDSPAR FITTING







#### Strut To Wing Attachment Position 3




Strut To Wing Attachment Position 4


### ENGINE TO STRUT ATTACHMENT FORWARD AND REAR ENGINE MOUNT

## x - Engine Mount Bulkhead and Fittings Attached to Strut

		ENGINE POSITION			
STRUCTURE	FIGURE	1	2	3	4
FORWARD ENGINE MOUNT	A	X	1	1	X
REAR ENGINE MOUNT	В	X	2	х	2/3

- 1. Assembly seperated from strut and attached to fan case.
- 2. Attached to turbine exhaust case.





WING / STRUT ATTACHMENT AND SEE

TFITTINGS RECOVEREJ       STRUT1     STRUT2     STR       C876     C884     C1       C876     C884     C1       C876     C884     C1       C876     C884     C186       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X       X     X     X	A C815
MIDSPAR FITTING INBOARD  UNDERWING FITTING OUTBOARD  FUSE BOLT MIDSPAR INBOARD  FUSE BOLT UPPER LINK FITURE  FUSE BOLT UPPER LINK WING  FUSE BOLT UPPER LINK STRUT  CONE BOLT (ORWARD MOUNT)  LOWER SPAR FITTING STRUT  LOWER SPAR FITTING STRUT  TANGENTIAL LINKS  THRUST LINK  THRUST LINK  THRUST LINK  THRUST LINK  THRUST LINK  THRUST YOKE  WOTE: TARGET NUMBER AS INDICATED  X NOTE: TARGET NUMBER AS INDICATED	TOTAL TOSABED

A7.21