

## NATIONAL TRANSPORTATION SAFETY BOARD

Office of Aviation Safety Washington, D.C. 20594

September 2, 2016

**Attachment 15 – Engine Fire Checklist - Boeing** 

## OPERATIONAL FACTORS

**DCA15FA185** 

777 Flight Crew Operations Manual

## [] FIRE ENG L, R

Condition: Fire is detected in the engine. 1 A/T ARM switch (affected side) . . . . . . Confirm . . . . . . . OFF 2 Thrust lever (affected side) . . . . . Confirm . . . . . . . Idle 3 FUEL CONTROL switch (affected side) . . . . . Confirm . . . . . . CUTOFF 4 Engine fire switch (affected side) . . . . . Confirm . . . . . . . Pull 5 **If** the FIRE ENG message stays shown: Engine fire switch (affected side) . . . . . . . Rotate to the stop and hold for 1 second If after 30 seconds, the FIRE ENG message stays shown: Engine fire switch (affected side) . . . . . . . . . Rotate to the other stop and hold for 1 second 6 APU selector (if APU available) . . . . . . . . . START, then ON 7 Transponder mode selector . . . . . . . . TA ONLY 8 Plan to land at the nearest suitable airport. 9 Do **not** accomplish the following checklist:

**▼** Continued on next page **▼** 

**AUTOTHROTTLE** 

## 777 Flight Crew Operations Manual

	▼	FIRE ENG L, R continued ▼
10 Choose	e one:	
∳Landi	ng usin	ng flaps <b>20</b> :
	GND P	ROX FLAP OVRD switch OVRD
	Note:	Use flaps 20 and VREF 20 for landing and flaps 5 for go-around.
	►►Go	o to step 11
◆Landi <b>allov</b>	_	ng flaps <b>30 (if performance</b>
	Note:	Use flaps 30 and VREF 30 for landing and flaps 20 for go-around.
		••••
11 Check	list Co	mplete Except Deferred Items
		Deferred Items
Descent	Checkl	ist
Recall .		
Notes .		Checked
Autobrak	æ	
Landing	data	VREF 20, Minimums
Approach	n briefir	ng Completed
Approach	1 Chec	klist
Altimete	rs	· · · · · · · · · · · · · · · · · · ·
Landing	Checkl	ist
0 11	. 1	

 $\textbf{Copyright} \\ @ \textbf{Boeing. Reprinted with permission of The Boeing Company. } \textbf{Content not subject to EAR.}$ 

Landing gear . . . . . . . . . . . DOWN

Flaps......**20**